



User's Manual Installation and Operation Guidelines

SiteBoss™ 550 Remote Site Manager

Version 2.03.040

Asentria Corporation
1200 North 96th Street
Seattle, Washington, 98103
U.S.A.
Tel: 206.344.8800
Fax: 206.344.2116
www.asentria.com

SiteBoss™ 550 Remote Site Controller

Installation and Operation Guidelines

Manual Rev. A
for Firmware Version 2.03.040 _STD
Release date: March 13, 2008

Changes In This Version of the User Manual

- Added the [Static Route Settings](#) menu to the [Network Settings](#) section, and a further detail [Static Routes](#) section in the Features chapter.
- Added the [DSL Settings](#) and [VPN Settings](#) menus to the [Network Settings](#) section.
- Added I/O 1Port mode ESBUS option and description to the [Serial Port Settings](#) section.
- Added the Default Route Enable option to the [Wireless Modem Settings](#) section and a description of this option in the [Wireless Modem](#) chapter.
- Added a section describing the installation, configuration, and operation of the optional [ADSL modem](#).
- Added product graphics for the back panels of both the S550-2 and S550-6 products.

© 2008 Asentria Corporation. All rights reserved.

The content of this manual is provided for informational use only, and is subject to change without notice. Examples, data, and names used in this manual are examples and fictitious unless otherwise noted. No part of this document may be reproduced or electronically transmitted without permission from Asentria Corporation. SiteBoss 550, S550, AlarmManager, and EventSensor are trademarks of Asentria Corporation.

Table of Contents

Quick Start	1
What's Included	1
Hardware Needed	1
Information Needed	1
Connecting	1
Cables and Power	1
Power Requirements	1
Accessing the Command Line	3
Network Setup	3
Setup	3
Testing Network Connectivity	3
SNMP Trap Setup	4
Setup	4
Testing SNMP Traps	4
What is a SiteBoss 550	5
The Basics	5
Communication Methods	5
Data Storage	5
Remote Access	6
Serial Monitoring (Data Events)	6
Event Notification	6
Audit Log	6
Parts Identification	6
Features and Accessories	6
LEDs, Ports, DIP Switches and Buttons	7
Getting Connected	10
Power Up Sequence	10
Default Passwords	10
The Status Screen	10
Setup Menu	12
Overview	12
Option Types	12
Web Interface	13
Main Setup Menu	13
Network Settings	14
Serial Settings	24
Modem Settings	26
User Profile Settings	28
Alarm/Event Definitions	32
Action Definitions	41
General Settings	42
Event Log Settings	43
Audit Log Settings	44
Scripting Settings	45
Features and How To Use Them	46
Upgrading the S550	46
Setting Keys	47
Telnet/TCP Connections	48
VLANS	49
Secure Shell (SSH) and Secure FTP (SFTP)	50
Quick Start: SSH into the unit	50
SFTP CDR out of the unit	50
Reestablishing authenticity of the SFTP host	51
Configuring authentication	52
Configuring a login banner for SSH	52

Menu changes	52
Default Router	53
Static Routes.....	54
IP Address Restrictions	55
IP Routing.....	56
SNMP Trap Capture.....	57
SNMP Informs	58
Configuration.....	58
Passthrough.....	59
Data Events	60
Configuring Data Alarm Equations.....	62
Data Alarm Macros	63
Action List.....	65
Asentria Alarms	67
EventSensor™ Configuration Setup	69
Contact Closure Setup.....	69
Temperature Sensor Setup.....	70
Humidity Sensor Setup	71
Analog Voltage Sensor Setup.....	72
Relay Output Setup.....	74
Relays as Alarm Action.....	75
Customizable Command Prompts	76
Scripting	77
Configuration	77
Script Management	77
Script Settings	80
Script List	80
Manage Script Files	81
Script Programming Guide.....	82
Scripting FAQ	82
OmniLua Function List	83
Command Reference	101
User Interface Commands.....	101
Setup Commands	101
System Commands	102
Wireless Modem.....	103
Installation.....	103
Setup.....	103
Setting Keys.....	103
Setup Menu.....	104
Operation.....	104
Status Commands	105
Troubleshooting Commands.....	105
ADSL Modem.....	106
Installation.....	106
Description of ADSL.....	106
Configuration	106
Activation	107
DSL Status.....	109
Connectivity	109
Deactivation	109
ADSL specifications.....	109
DSL Routing.....	110
DSL Glossary	111
Battery Module	113
Setup.....	113
Operation.....	113
Appendices.....	114
User Rights Table	114
Control Characters	115
Internal Modem Guidelines.....	116
Canadian Department of Communications.....	117

Quick Start

What's Included

This chapter is a brief guide to help get your SiteBoss 550 (S550) up and running quickly.

Hardware Needed

- Asentria SiteBoss 550
- 15VDC power adaptor (Included if AC power option)
- DC power source (if DC power option)
- Computer with DB9 RS-232 Serial port and terminal emulation software
- Ethernet cable
- RJ45 M-M unshielded serial cable and RJ45/DB9 straight thru adapter (Included)
- PC running AlarmManager software -- may be obtained from <http://www.asentria.com/docsandsoftware/productManuals.aspx> or Asentria Technical Support (for SNMP trap receiving purposes)

Information Needed

- IP address(es) to assign to the S550
- Subnet mask
- Default router IP or gateway router IP address if on a WAN (Optional)
- IP address of the PC running Asentria AlarmManager (for SNMP trap receiving purposes)

Connecting

Cables and Power

1. Connect the RJ-45 serial cable and DTE adaptor together, and connect to serial port I/O2 of the S550 and the COM1 of a PC or laptop running any terminal emulator.
2. Connect the attached ground wire securely to an appropriate earth ground (this is essential).
3. Connect an Ethernet cable, if available, into the RJ-45 jack labeled ETH1.
4. Connect the power supply to the unit (see Power Requirements section).

Power Requirements

The S550 is configured with one of two types of power connectors: AC or DC.

If configured for AC, the unit uses a barrel connector for connecting to the 15VDC power adaptor shipped with the unit.

If configured for DC, the unit is configured with a 4-pin Molex connector for use with a DC power source. The unit is shipped with the cables and instructions for direct connection to a DC power source. The instructions are shown below, in case they are missing from the box.

» Note: This instruction sheet describes connection of the provided -48V wiring harness kit to the source power supply. This unit should be assembled and installed by a qualified technician who can ensure the power source is an isolated, SELV (Safety Extra Low Voltage) circuit. There are two versions of the harness using different wiring colors as shown below.

» Note: Because the S550 is generally considered to be "permanently connected", safety standards require that an appropriate disconnect device shall be provided as part of the building installation. The -48VDC input should be protected by an external 2A Slow Blow Fuse conforming to CSA/UL 248-14, IEC 60127-4/2, at the power supply or within the building circuitry as appropriate. The input DC power current limiting fuse circuit is provided for by the end user, and is required for unit operation in compliance with safety agency approvals.

One example of a compliant fuse for the -48V input is a Littelfuse 239P series, 2 amp fuse with a 250 VDC minimum voltage rating and interrupt rating 10,000 amps at 125 VAC, 0.7 to 0.8 power factor and 100 amps at 125VAC, 0.7-0.8 power factor.



CONTENTS:

Please inventory the package contents and ensure you have the following items pertaining to the -48VDC Power Option:

1. A cable harness consisting of 2 black or red and 2 white or blue wires connected to a white nylon "molex" connector.
2. A bare white nylon housing.
3. 5 crimp-on contacts.

-48VDC CONNECTION:

The -48VDC power supply option has 4 input connections. This gives the user the ability to connect this unit to an auxiliary -48VDC power source. Note: The dark area on the diagram represents the latching mechanism on the housing.



DANGER! FIRE HAZARD!
DO NOT LEAVE AN UNCONNECTED WIRE EXPOSED!
DO NOT CONNECT THE UNIT TO ANY OTHER EQUIPMENT UNTIL YOU KNOW THE UNIT POWERS UP CORRECTLY!

Option A: Connect the supplied harness assembly to your -48VDC voltage source:

1. Ensure the unit is not connected to any peripheral equipment.
NOTE: Peripheral Equipment connections may cause a short circuit of your -48V supply if the power connections are reversed! Do not connect peripheral equipment connections until you know the unit is operational by observing the front panel Power LED.
2. Strip the ends of the wires.
3. Using wire nuts (not supplied), connect the stripped wires to the power source. The black (red) wires connect to ground or the most Positive connection on the voltage source. The white (blue) wires connect to -48VDC or the most Negative connection on the voltage source.

Option B: Use the supplied kit to make a wire harness:

1. You will need a crimping tool that crimps standard Molex type 18-24 AWG Mini-Fit Terminals (Molex Part Number: 39-00-0060, Engineering Series 5556).
2. Crimp the supplied terminals to your cable connections.
3. Insert the crimped terminals into the supplied white nylon housing. Orient the housing so the latching mechanism is up and you are looking into the large end of the housing. See diagram above. Insert the 2 Ground or Most Positive leads into the upper and lower compartments on the left side of the connector, e.g. the same positions as the black wires on the supplied harness assembly. Insert the 2 -48VDC or Most Negative leads into the upper and lower compartments on the right side of the connector, e.g. the same positions as the white leads on the supplied harness assembly.
4. Connect the completed assembly into the power input receptacle at the rear of the unit.

Accessing the Command Line

1. Connect to I/O2 with a serial terminal emulation program at 19200 baud, 8N1.
2. Enter **STATUS** or **?** and press <Enter>. You will be presented with a status screen similar to the following.

```
SiteBoss 550 2.03.040 STD      Serial # : 5500000096
Site Name : 550-5500000096
Date      : THU 03/13/08      1: 19200,8N1 I/O 1
Time      : 11:21:11         2: 19200,8N1 I/O 2
Modem     : Yes
Eth 1     : STATIC
IP Add    : 0.0.0.0
MAC Add   : 00:10:A3:60:01:56
Eth 2     : STATIC
IP Add    : 0.0.0.0
MAC Add   : 00:10:A3:60:01:57

COMPLETE
>
```

When the status screen appears, the unit is successfully connected and ready for use.

Network Setup

Setup

1. Access the setup menu by typing **SETUP** and pressing <ENTER>.
2. Select the Network Settings branch.
3. Select A) Ethernet Settings and select the Ethernet interface that corresponds to the one on the back panel that you plugged your network cable into (ETH1).
4. Enter an IP address, subnet mask and--if necessary--a router address.
5. Toggle NAT on/off as desired.
6. If using this Ethernet interface for a VLAN connection, select this option to configure any of six VLAN connections. See the [VLAN section](#) in the Features chapter for details on how to configure.
7. Press <ESC> to go back one level in the menu tree, or <CTRL + C> to exit the setup menu and return to the command prompt.

Testing Network Connectivity

1. Verify that the network router is available to the unit by typing the command **PING IP_address**. A router is always a good candidate to test pings on. The following screenshot is an example of a successful ping test.

```
ping 192.168.100.59
PING 192.168.100.59 (192.168.100.59): 56 data bytes
64 bytes from 192.168.100.59: icmp_seq=0 ttl=128 time=8.0 ms
64 bytes from 192.168.100.59: icmp_seq=1 ttl=128 time=0.7 ms
64 bytes from 192.168.100.59: icmp_seq=2 ttl=128 time=1.8 ms
64 bytes from 192.168.100.59: icmp_seq=3 ttl=128 time=0.8 ms
64 bytes from 192.168.100.59: icmp_seq=4 ttl=128 time=0.7 ms
64 bytes from 192.168.100.59: icmp_seq=5 ttl=128 time=0.7 ms

--- 192.168.100.59 ping statistics ---
6 packets transmitted, 6 packets received, 0% packet loss
round-trip min/avg/max = 0.7/1.7/8.0 ms
```

2. Press <CTRL + C> to stop the ping testing. If <CTRL + C> is not pressed, the unit will continue pinging attempts indefinitely.
3. If there is an error message or no response from the router, first check the network settings and connection, then consult your System Administrator or Asentria Technical Support.
4. Using a Telnet client, connect to the IP address assigned to the unit.

SNMP Trap Setup

If you will be using your S550 to send SNMP traps, this section will help you ensure it is set up correctly.

Setup

1. Configure the network settings as described in the previous section.
2. Select the Network Settings then SNMP Settings sub-menu.
3. Verify the SNMP Community name is correct for your network.
4. Switch to the Actions Definitions menu and enter the host name or IP address of the computer to receive the traps into the field, "Hostname/IP Address 1".
5. Press <CTRL + C> to exit the Setup menu and return to the command prompt.
6. On the computer that will be receiving the SNMP traps, start AlarmManager or your preferred SNMP trap manager.

Testing SNMP Traps

1. Using a Telnet client, connect to the IP address assigned to the unit.
2. Enter the command **DOTRAP** from the S550 command prompt.
3. Verify that the trap manager receives the test trap.
4. If there is an error message or no response from the router, first check the network settings and connection, then consult your System Administrator or Asentria Technical Support.

What is a SiteBoss 550

The Basics



Fig 1: S550-2

The SiteBoss 550 is a versatile mid-range system used for monitoring and control of remote equipment sites. The S550 provides remote monitoring of serial devices, equipment I/O, and environmental conditions at these remote sites and forwards notification when conditions fall outside limits. On-board I/O provides serial, Ethernet, and dialup connectivity. The S550-2 (11-inch) and S550-6 (17-inch) models provide two or six expansion slots respectively to allow addition of various communications and monitoring interfaces (Expansion Cards).

Communication Methods

The S550 has a diverse selection of communication methods available for different applications. The following methods can be used to either access the command processor or provide a pass-through connection to devices attached to the serial ports. All methods of connecting to the unit can be secured via password for protection of data and hardware.

- RS-232 serial
- Telnet
- Standard modem serial
- Security callback modem serial
- SSH

Data may be retrieved from or through the S550 by any of the following methods:

- Serial or modem connection to command processor (using Line or Zmodem) or pass-through
- Inline Mode (data in I/O1, data out I/O2)
- Telnet to command processor or passthrough
- Telnet real-time sockets
- FTP push (automatic delivery to FTP server)
- FTP get (manual retrieval from FTP server)
- SFTP push/get

Alarms generated or detected within the S550 can be delivered through any of the following means:

- | | |
|-----------------|---|
| • Modem callout | • Asentria Alarms |
| • SNMP trap | • Script actions |
| • Email | • Relays (if configured with optional relay Expansion Card) |

Data Storage

Basic data storage in the S550 is accomplished in a database of four files – FILE1, FILE2, EVENTS, and AUDIT. FILE1 and FILE2 are typically associated with Serial Port I/O1 and Serial Port I/O2 respectively, although either serial port can store to either FILE1 and FILE2, or both. EVENTS and AUDIT are log files generated from the Event Log Settings and Audit Log Settings menus per the parameters set there. The number of records stored in each these four files can be displayed using the **DIR** command on any connection to the command processor, including FTP.

The S550 also features three “auxillary” files for storage of data to be used in scripting functions, named AUX1, AUX2, and AUX3. These three files are not displayed with the **DIR** command, although data collected via serial port or IPRC can be stored to any of these three auxillary files in addition to FILE1 and FILE2. Refer to the [Scripting](#) chapter for more information on processing data stored in AUX1, AUX2 and AUX3.

Remote Access

The S550 can provide an administrator transparent access to devices connected to the serial ports of the unit via passthrough connections or through the login menu in the web interface, Telnet and modem connections. This sort of access can be used to configure, maintain, or manipulate devices that would normally have no remote access.

Serial Monitoring (Data Events)

The S550 can be used to monitor incoming data for user-defined strings and then report the event via several avenues. The S550 allows for up to 1000 different data events. Each data event contains independent actions, counters, and other unique settings. Data events triggered within the S550 can be logged to an Event Log. This file can be viewed through the Event Log section of the setup menu, via the **TYPE EVENTS** command, or through FTP.

Event Notification

Actions generated or detected within the S550 can be delivered through any of the following means:

- Modem callout
- SNMP trap
- Email
- Asentria Alarms
- Script actions
- Relays (if configured with optional relay Expansion Card)

Audit Log

The S550 can be used to log many types of administrative events, from reset events to login attempts. These Audit Log entries are stored in a file and can be viewed through the Audit Log section of the setup menu, via the **TYPE AUDIT** command, or through FTP.

Parts Identification

Features and Accessories

Standard Equipment

The base S550 comes with the following standard on-board equipment:

- AC or DC Power Input
- 0MB logging database for CDR or other text records (actual size is 128K allocation for text record logging)
- 2 – RJ45 DTE serial I/O ports
- 2 – 10/100Mb Ethernet interfaces with support for six 802.1Q VLAN interfaces on each.
- 1 – MMC memory I/O slot
- 2 or 6 – Expansion Card slots
- Internal battery backup*

In addition to the above components, the standard unit is shipped the following accessories:

- This product manual and Asentria Alarm Manager software on the Documentation and Software CD
- RJ45 M-M unshielded serial cable and RJ45/DB9 straight thru adapter for each serial port ordered
- RJ45 Ethernet cables for each Ethernet port
- Power supply adapter (for AC units), or wiring harness and Molex plug (for DC units)

Options

Each of the following components is optional and may be installed on a S550:

- Additional RJ45 DTE serial I/O ports in sets of 4 to total 6, 10, 14, 18, 22, or 26 ports
- 4MB logging database for CDR or other text records
- Internal 56K baud, or wireless modem
- Run-time battery

The S550 may come with any of the following accessories as well, depending on the configuration or order:

- Modem cable for internal modem
- Antenna for wireless modem Expansion Card
- Serial cables and RJ45/DB9 adapters for 4-port Serial Expansion Cards

* Battery backup preserves clock operation when power is not present. Data records and settings are stored in non-volatile memory and therefore do not require backup.

LEDs, Ports, DIP Switches and Buttons



Fig 2: Front panel (S550-2)

LEDs – Front Panel

Note: When the S550 firmware is upgraded, the front panel LEDs flash in a specific pattern. This is described, along with FTP upgrade procedures in the [Upgrading the S550](#) section of the Features chapter.

Power

The Power LED is green and has two operational states. During the boot up cycle, it will blink once every second until the boot sequence is complete. During normal operation, it is steady on with a blink every 5 seconds.

MDM (Modem)

The MDM LED lights solid green whenever the modem is connected and blinks when the modem is dialing out.

ETH (Ethernet)

The Link LED lights solid green whenever an active Telnet or FTP connection is made to the unit.

ALM (Alarm)

This LED is reserved for future use.

25% - 75% - 100%

The S550 has three LEDs to indicate file full status. A blinking percentage full LED indicates the database has less than the amount indicated by that LED, but more than the previous. A solid lit LED indicates the database percentage is at or over the value for that LED.

Expansion Card *n*

Each optional Expansion Card has eight LEDs associated with it that may or may not be used.

LEDs – Back Panel

Each RJ45 port on the back panel has two LEDs associated with it – one on the Right of the port, one on the Left.

Ethernet Ports (ETH1 and ETH2)

- Right – Lights solid red when an Ethernet cable is connected to the port and an active Ethernet network. The LED is off when the cable is disconnected from the network, or the Ethernet Port.
- Left – Flashes yellow/green when network data (tcp packets) is being transmitted or received across the port. When no data is actually being transmitted/received, this LED is off.

I/O Port 1 & 2 (and any additional 4-I/O Port cards that may be installed)

- Right – Lights solid green when a correctly configured cable from another device is connected to it. Otherwise this LED remains off. As the I/O Port receives or transmits data, this LED will flash red.
- Left – Lights solid green when power is applied to the S550, regardless of whether a cable is connected to the I/O Port or not.




Fig 3: Back panel S550-2 (11" - wide model)




Fig 4: Back panel S550-6 (17" - wide model)

The above drawings shows the S550 configured (from right to left) with a bay for the optional run-time battery, (bottom) AC power jack, bank of 8 DIP switches, MMC memory I/O card slot, two RJ45 Ethernet ports, two RJ45 RS232 serial ports, Reset button, one RJ11 POTS modem port, and either two or six "slots" or expansion bays for optional Expansion Cards that expand the functionality of the unit with wireless modem, ADSL card, and a variety of sensor and relay I/O.

Ports

Memory I/O

The slot labeled Memory I/O is reserved for future use. Eventually S550's may be upgraded using a MultiMedia Card (MMC) in this slot.

Ethernet

The Ethernet 10/100Mb interfaces are standard RJ45. Either of these standard connectors will connect the S550 to an Ethernet hub or switch. Refer to the [Telnet/TCP Connections](#) section in the Features chapter for further information regarding a number of different types of telnet connection options. LEDs by each Ethernet connection on the back panel flicker when packets are being transmitted/received on that port.

The S550 features network connectivity via Secure Shell (SSH) and Secure FTP (SFTP). Refer to the [Secure Shell \(SSH\) and Secure FTP \(SFTP\)](#) section in the Features chapter for a detailed explanation of SSH and SFTP.

Serial Ports

Each of the two (or more) serial ports is configured as a DTE port using an RJ-45 connector. This is the standard recommended pinout for EIA/TIA-561 for 8 pin RJ45 connector:

PIN1	=RI =RING INDICATOR, INPUT to the S550
PIN2	=DCD =CARRIER DETECT, INPUT to the S550
PIN3	=DTR =DATA TERMINAL READY, OUTPUT from the S550
PIN4	=SIGNAL GROUND
PIN5	=RXD =RECEIVED DATA, INPUT to the S550
PIN6	=TXD =TRANSMITTED DATA, OUTPUT from the S550
PIN7	=CTS =CLEAR TO SEND, INPUT to the S550
PIN8	=RTS =REQUEST TO SEND, OUTPUT from the S550

The DB9 female cable end which mates with the serial port connectors of connected devices will often have a pair of screw-down cable screws. These cable screws should be used to assure a solid connection of the cable with the device.

Default settings for the serial ports are 19200-baud, 8-bit word length, no parity, and one stop bit (19200, 8N1). Use the internal setup menu to adjust these settings.

Internal Modem

If a dialup POTS modem is installed, an RJ-11 (typical U.S. phone) connector is used. A POTS (analog) dialup phone line is inserted into this connector.

The modem installed within this unit is FCC certified. For further information, consult the [Internal Modem Guidelines](#) appendix or the serial number label on the bottom of the S550.

*** Expansion Card Slots**

The S550 features two or six Expansion Card slots in which optional Expansion Cards can be installed to expand the capabilities of the S550. Contact Asentria Sales (sales@asentria.com) for more information on Expansion Cards.

DIP Switches

The bank of 8 DIP switches on the back panel of the S550 are used to control the baud and parity settings of I/O2, to set the operational mode for I/O2, and to put the unit into "boot load mode" where it can be forced to load a new application (firmware image). The following table shows how to set the various DIP switches to obtain certain settings:

I/O 2 Baud	SW1	SW2
2400	OFF	OFF
9600	ON	OFF
19200	OFF	ON
115200	ON	ON
I/O 2 Word, Parity	SW3	
8N1	OFF	
7E1	ON	
I/O 2 Mode	SW4	
Command Mode	OFF	
Data Mode	ON	
Boot Load Mode	SW8	SW1 thru SW7
No Forced App Reload (Default)	OFF	X (don't care)
Forced Application Reload	ON	ON

» **Note:** Boot Load Mode can only be set by flipping ALL DIP switches to the ON or UP position. This is not a setting that can be configured via internal menu settings, or Setting Keys.

» **Note:** For settings that can be set either via DIP switch, internal menu settings, or Setting Keys, the S550 always pays attention to the last setting, regardless of how it was done. So if the internal setting for I/O2 Mode is Command, and someone flips SW4 to the ON or UP position, the Mode is immediately set to Data.

Buttons

The only button on the S550 is the Reset button located on the back panel next to the left of serial port I/O 2.

Getting Connected

Power Up Sequence

On startup, the S550 goes through the following boot sequence in approximately 55 seconds:

- 1) The power LED flashes once each second for 30 seconds
- 2) The LEDs for Expansion Card 1 go through a 15 second flashing sequence
- 3) All LED's then go off for approximately 5 seconds
- 4) Power, Modem (if installed) and Ethernet LEDs light for 5 seconds, then Modem and Ethernet go off
- 5) Power LED will blink once every 5 seconds as a "heartbeat" while the S550 is powered on.

Default Passwords

The S550 uses a very flexible system for managing users, passwords, and access rights. By default, the only password preconfigured is "password" for the user named "admin". For security reasons it is highly recommended that you change this password, and record all configured passwords in a secure location.

Note that if a password is defined without a user name, the profile is defined just by the password. All of the default profiles are password-only.

The Status Screen

The S550 status screen is this unit's one-stop informational source. Most of the information that a user would need to know about the unit is available through this display. This section outlines this data and highlights why it is useful.

```
SiteBoss 550 2.03.040 STD      Serial #   : 5500000096
Site Name  : 550-5500000096
Date       : THU 03/13/08      1:  19200,8N1   I/O 1
Time       : 11:21:11          2:  19200,8N1   I/O 2
Modem      : Yes
Eth 1      : STATIC
IP Add     : 0.0.0.0
MAC Add    : 00:10:A3:60:01:56
Eth 2      : STATIC
IP Add     : 0.0.0.0
MAC Add    : 00:10:A3:60:01:57

COMPLETE
>
```

SiteBoss 550 indicates that this product is the S550, followed by **2.03.040**, the currently loaded firmware version.

Site Name is the identifier assigned to each S550 by the end user in the General Settings menu.

Date and **Time** display the current date and time.

Modem indicates whether the optional internal modem is installed.

Eth 1 and **Eth 2** displays STATIC, DHCP, or VLAN, depending on which mode each of the two Ethernet interfaces is configured for.

IP Add and **MAC Add** immediately following Eth 1 and Eth 2 are the network IP address assigned to each Ethernet card, and that cards MAC address. The MAC address of both Ethernet cards can also be found on the unit's serial number label.

Serial Number is the factory-assigned, unique serial number for this S550.

n: 19200,8N1 I/O n is a listing of all installed serial ports in order, displaying the current baud rate and parity setting (19200, 8N1) followed by the target name of the port (I/O n is default). This target name is used in event notifications and can be configured in the Serial Settings menu for each port. An asterisk following the baud rate and parity indicates that there is data stored in the file associated with that port.

Setup Menu

Overview

This section displays screen shots and descriptions taken from the command prompt menu system. However, the menu structure and options are the same as the web interface.

The Setup menu contains all of the configuration options available on the S550. It is organized in a logical tree structure with all settings classified under the following groups:

```
SiteBoss 550 - Main Setup Menu
A) Network Settings
B) Serial Settings
C) Modem Settings
D) User Profile Settings
E) Alarm/Event Definitions
F) Action Definitions
G) General Settings
H) Event Log Settings
I) Audit Log Settings
J) Scripting Settings

Enter your Selection:
```

Each section in this chapter will go over one of the above setup branches, outlining the options within.

Press either <ESC> or <ENTER> to go back one level in the menu tree, or <CTRL + C> to exit any setup menu and return to the command prompt.

Since this product allows for multiple simultaneous command processors, two administrators could conceivably change the same option at the same time, but due to the multitasking nature of the S550, the changes are processed in the order received.

The S550 processes setup changes in real time. In other words, the unit begins to implement changes to its configuration as soon as they are entered. There is no need to exit the setup menu or reboot the unit to apply changes. The exception to this rule is IP-specific network settings. Changes to these settings are implemented only after all open Telnet command processors are closed.

Option Types

String entry

There are several different types of inputs employed within the setup menu. The most common is the string type entry:

```
A) Site Name [Test Site]
```

When selected, this setting will provide a prompt requesting a new value. You may press <ENTER> or <ESC> to abort the option entry or press <SPACE> and <ENTER> to delete the current value and leave it blank. Some numerical or required settings will not allow an you to leave an option blank, so pay attention to the unit's response when attempting to delete a setting's value.

Toggle

The second most common option type is the toggle type option:

```
A) Enable Web Interface [OFF]
```

When selected, this option will not prompt for a new value. It will simply cycle to the next available option in its list. This switch type is typically used for options with two or three choices. Most often it is in an ON/OFF form, but could be a series of options such as "NONE", "1", and "2".

Alarm actions (action list)

Alarm actions have their own unique method of entry. Refer to the [Action List](#) section in the Features chapter for more information.

Option list

The option list type is similar to the toggle type in that it has a list of options to choose from:

```
SiteBoss 550 - Serial Port 2 Baud Rate
A) 300
B) 600
C) 1200
D) 2400
E) 4800
F) 9600
G) 19200
H) 38400
I) 57600
J) 115200
```

After selecting an option, you are immediately returned to the previous menu. The new value will be displayed to the right of the setting name, letter, or number.

Web Interface

The S550 has a built-in HTTP web server that can be used to configure the unit from anywhere the unit can be accessed on the network or Internet. Once you have enabled it through the network section of the setup menu, simply connect to <http://<IP address of S550>>

You will be greeted by a login screen. Log in with your Login ID (Username) and Password. These are the same credentials you would use to log into the command prompt. Once logged in, the General Status screen will be displayed, with a menu bar across the top of the page that displays the same menu options as the command prompt menu system. From here, you can alter any setting in the same way you could via the prompt.

Main Setup Menu

```
SiteBoss 550 - Main Setup Menu
A) Network Settings
B) Serial Settings
C) Modem Settings
D) User Profile Settings
E) Alarm/Event Definitions
F) Action Definitions
G) General Settings
H) Event Log Settings
I) Audit Log Settings
J) Scripting Settings
```

[Network Settings](#) contains settings for network communication, SNMP, FTP, PPP, Email, and more.

[Serial Settings](#) contains settings pertaining to the function of each serial port.

[Modem Settings](#) contains modem init settings and modem-specific security options.

[User Profile Settings](#) contains all of the user profiles and global security settings.

[Alarm/Event Definitions](#) contains all of the settings that define events within the S550.

[Action Definitions](#) contains configurations for all of the actions possible when events are detected.

[General Settings](#) contains the site name, answer string, confirmation prompt, date/time, and other general settings.

[Event Log Settings](#) allows for configuration and displaying of the Events Log.

[Audit Log Settings](#) allows for configuration and displaying of the Audit Log.

[Scripting Settings](#) allows for configuration of scripts.

Network Settings

The Network Settings menu contains all of the options pertaining to network communication.

```
SiteBoss 550 - Network Settings
A) Ethernet Settings
B) Default Router                []
C) Name Resolution Settings
D) Telnet Duplex                [FULL]
E) Inactivity Timeout           [0]
F) Web Interface Settings       [ON]
G) SNMP Settings
H) FTP Settings
I) PPP Settings
J) Email Settings
K) Real-Time Socket Settings
L) SNMP Trap Capture Settings
M) IP Address Restrictions
N) Static Route Settings
O) DSL Settings
P) VPN Settings
    Note: Changes to IP Address, Subnet Mask, or Router
          Address will not take effect until any open
          Telnet command processor sessions are ended.
```

[Ethernet Settings](#) displays the menu where you can configure each of the two Ethernet interfaces, and also any of the six VLAN interfaces that each supports.

Default Router displays the configured default router (gateway) for the unit. Refer to the [Default Router](#) section in the Features chapter for more information.

[Name Resolution Settings](#) allows you to configure the IP addresses of up to two Domain Name Servers (DNS).

Telnet Duplex controls the echo settings for Telnet. Full duplex causes the unit to echo all characters sent to the remote device. Half duplex turns off character echo. Default setting is Full.

Inactivity Timeout sets the number of minutes (0 - 255) before a network connection with no activity will be terminated. A setting of 0 means an inactive connection will not be terminated. Default setting is 0.

[Web Interface Settings](#) displays the Web Interface Settings menu where you can toggle the web interface ON or OFF, set the session timeout (0 - 65535 minutes), and set the tcp port number for the web connection.

[SNMP Settings](#) displays the SNMP Settings menu where you can configure version of SNMP, community names, and other SNMP trap settings.

[FTP Settings](#) displays the FTP Settings menu, where you can configure automatic FTP pushes of buffered data.

[PPP Settings](#) displays the PPP Settings menu, where you can configure settings for PPP Dialout, PPP Hosting, and IP Routing.

[Email Settings](#) displays the Email settings menu, where you can configure the SMTP server address, Email domain name, and authentication parameters.

[Real-Time Socket Settings](#) displays the Real-Time Socket Settings menus where you can configure real-time socket settings for each file of buffered data. Real-Time Sockets are used to collect data on TCP port 2201 from a serial port in real-time, while buffering data if the network connection goes down.

[SNMP Trap Capture Settings](#) displays the SNMP Trap Capture Settings menu where you can toggle this feature ON or OFF, and select which file to store the traps in.

[IP Address Restrictions](#) displays the IP Address Restrictions menu, where you can limit Ethernet and PPP communications to or from specific IP addresses.

[Static Route Settings](#) displays the Static Route Settings menu where you can configure static network routes.

[DSL Settings](#) displays the DSL Settings menu where settings are configured so the S550 can communicate using the optional [ADSL Modem](#).

[VPN Settings](#) displays the VPN Settings menu where settings are configured so the S550 can communicate with the optional Asentria SitePath secure, unified administration portal software.

Ethernet Settings

Ethernet Settings displays the following menu where each of the two installed Ethernet ports can be configured:

```
SiteBoss 550 - Ethernet Settings
A) Ethernet 1
B) Ethernet 2

Enter your Selection: a

SiteBoss 550 - Ethernet 1 Settings
A) Mode [STATIC]
B) IP Address [0.0.0.0]
C) Subnet Mask [255.255.255.0]
D) Router Address [0.0.0.0]
E) NAT [ON]
F) VLAN Settings
```

Mode toggles between STATIC, DHCP, or VLAN – whichever is appropriate for this Ethernet port. Default setting is STATIC.

IP Address is the network address assigned to this Ethernet card. Default setting is 0.0.0.0

Subnet Mask sets the network subnet mask provided by the network administrator. Default setting is 255.255.255.0

Router Address sets the router address provided by the network administrator. Default setting is 0.0.0.0

NAT is an ON/OFF toggle to enable Network Address Translation. Default setting is ON.

VLAN Settings displays the following sub-menu where any of six individual VLAN connections can be configured. Refer to the [VLANs](#) section in the Features chapter for a detailed explanation of VLANs.

```
SiteBoss 550 - VLAN Settings
A) VLAN 1
. . .
F) VLAN 6

Enter your Selection: a

SiteBoss 550 - VLAN 1 Settings
A) ID [0]
B) Priority [0]
C) IP Address [0.0.0.0]
D) Subnet Mask [255.255.255.0]
E) Router Address [0.0.0.0]
```

>> Note: The S550 does not heed changes to network configurations while you are connected to a command processor via Telnet, web interface, or SSH. Changes, including population of the candidate default router set, are pended until all network-based command processor sessions have ended. Open FTP and RTS connections will fail if these settings are changed during an open connection.

Name Resolution Settings

```
SiteBoss 550 - Name Resolution Settings
A) DNS Server 1 [0.0.0.0]
B) DNS Server 2 [0.0.0.0]
```

DNS Server 1 and **DNS Server 2** are the IP addresses of Domain Name Servers that you may want to configure so that you can use host names rather than IP addresses in functions where name resolution may be needed, such as; Email server, RTS push hosts, action IP settings, network time servers, scripting TCP connections, etc. Default setting for each DNS Server is 0.0.0.0.

Web Interface Settings

```
SiteBoss 550 Web Interface Settings
A) Enable Web Interface [ON]
B) Web Session Timeout [30]
C) Web Connection Port [80]
```

Enable Web Interface is an ON/OFF toggle to enable the S550's internal web server. Default setting is ON.

Web Session Timeout sets the number of minutes (0 - 65535 minutes) a connection may remain idle before expiring. A setting of 0 means the connection will never automatically expire. Default setting is 30.

Web Connection Port is the TCP port through which the web connection is made. Default setting is Port 80.

SNMP Settings

```
SiteBoss 550 - SNMP Settings
A) SNMP Agent Enable [ALL VERSIONS]
B) Read Community [public]
C) Write Community [public]
D) Trap Community [public]
E) Trap Settings
```

SNMP Agent Enable toggles between ALL VERSIONS, V3 ONLY, and OFF, and controls whether the unit responds to SNMP 'gets' and 'sets' in the selected version. Note that for V3 operation the user profile passwords are used for authentication (via MD5) and encryption (via DES). Passwords for user profiles intended for SNMPv3 use must be at least 8 characters. Default setting is ALL VERSIONS.

» **Note:** SNMP Agent Enable does NOT stop SNMP traps from being sent when it is set to OFF.

» **Note:** SNMP traps are *not* a guaranteed means of delivering notifications. Traps are a one-way IP network datagram and the device receiving traps does not acknowledge them. Therefore, if the trap does not reach its intended destination for whatever reason, the sending device has no way of recognizing this and resending the trap.

Read/Write/Trap Community sets the SNMP trap communities to use. Default setting for all is PUBLIC. (Max length for each is 23 chars)

Trap Settings displays a menu that allows you to configure what data should be included in the SNMP traps, as well as whether to send authentication failure traps. Authentication traps are notifications of invalid community name usage in SNMP operations. Default setting for all is ON, except for Authentication Failure Traps, which is OFF.

```
SiteBoss 550 - Trap Settings
A) Include Date and Time           [ON]
B) Include Site Name               [ON]
C) Include Sensor ID               [ON]
D) Include User Defined Name       [ON]
E) Include User Defined State      [ON]
F) Authentication Failure Traps    [OFF]
```

FTP Settings

```
SiteBoss 550 - FTP Settings
A) FTP Push Enable                 [OFF]
B) FTP Server Address              []
C) Username                       [Default FTP Username]
D) Password                       [*****]
E) Account                        []
F) Directory                      []
G) Minutes Between Push Attempts  [1440]
H) Select Files to Push
I) Remote File Names
```

FTP Push Enable toggles between OFF, REGULAR, and SECURE. Default setting is OFF.

FTP Server Address is the IP address or host name of the FTP server to push to. (Max length 64 chars)

Username/Password defines the login credentials that are able to access the remote FTP server. (Max length Username is 126 chars) (Max length Password is 31 chars)

Account is a third login option used only on some FTP servers. Consult your network administrator to see if this is necessary. (Max length 126 chars)

Directory is the path used to transfer the file(s). The file(s) is transferred to the root login directory if this option is left blank. (Max length 253 chars)

Minutes Between Push Attempts sets the number of minutes (1 to 9999) between FTP push attempts. Default setting is 1440 minutes.

Select Files to Push displays the FTP File Selection menu where you can select which files are pushed by toggling ON or OFF. Default setting for all is ON, except for Audit Log, which is OFF.

```
SiteBoss 550 - FTP File Selection
A) Data File 1           [ON]
B) Data File 2           [ON]
C) Events File           [ON]
D) Audit Log             [OFF]
```

Remote File Names displays the FTP File Names menu where you can give each file a name other than the default name, and/or prepend a date, time, and unique sequence # to the file name.

```
SiteBoss 550 - FTP File Names
A) Include Date in Filename [OFF]
B) Include Time in Filename [OFF]
C) Include Sequence #s in Filename [OFF]
D) Data File 1             [FILE1]
E) Data File 2             [FILE2]
F) Events File             [EVENTS]
```

Include Date/Time in Filename is an ON/OFF toggle to enable the addition of the file transfer date and/or time to the beginning of the name of each transferred file of data. Default setting is OFF.

Include Sequence #s in Filename is an ON/OFF toggle to enable the addition of a unique sequence number to the beginning of the name of each transferred file of data. This ensures that no two transfers will have the same file name. Default setting is OFF.

Data File *n* / Events File are text-entry fields where the name each data file will have on the remote server (not including any date, time, or sequence numbers) can be configured.

Once FTP Push has been configured, entering the **PUSHTEST** command will test the connectivity to the FTP server and write a “log in” and “log out” entry to the Status File in the directory you configured. No data is pushed with this command. Connection data displayed on the terminal screen is useful if the connection fails.

An immediate push of data can be done using the **PUSHNOW** command.

PPP Settings

```
SiteBoss 550 - PPP Settings
A) PPP Dialout Settings
B) PPP Hosting Settings
C) IP Routing
D) Route Test Settings
```

[**PPP Dialout Settings**](#) displays settings pertaining to making outbound PPP network connections.

[**PPP Hosting Settings**](#) displays settings for hosting a PPP connection.

[**IP Routing**](#) displays settings for routing of IP packets between PPP connections and the LAN a S550 is connected to.

[**Route Test Settings**](#) displays settings for network monitoring/PPP backup connection settings. This menu allows you to configure up to three IP addresses to ping on a regular basis. If any of the IPs are down, the unit will fall back to a PPP dialout in order to maintain reliable network connectivity for sending SNMP traps.

PPP Dialout Settings

```

SiteBoss 550 - PPP Dialout Settings
A) PPP Dialout Enabled           [OFF]
B) Telephone Number             []
C) User Name                    []
D) Password                     [*****]
E) Idle Connection Disconnect (sec) [60]
F) Maximum Retries              [3]
G) Carrier Detect Timeout (sec)  [60]
H) Login Sequence Timeout (sec)  [30]
I) Dialout Modem Init String     []
J) IP Address to Suggest        [0.0.0.0]

```

PPP Dialout Enabled is an ON/OFF toggle to enable PPP dialout. Default setting is OFF.

Telephone Number sets the phone number of the PPP host the S550 is to dial into. (Max length 48 chars)

User Name/Password sets the login credentials that are used to log into the PPP host. (Max length for each is 64 chars)

Idle Connection Disconnect (sec) sets the number of seconds to wait before disconnecting an idle connection. A setting of 0 means the unit does not disconnect due to an idle connection. Default setting is 60 seconds.

Maximum Retries defines the maximum number of times to retry a failed connection. Default setting is 3.

Carrier Detect/Login Sequence Timeout (sec) configure standard login timeouts, from 0 to 65535 seconds. Default setting is 60 seconds for Carrier Detect, and 30 seconds for Login Sequence.

Dialout Modem Init String sets the modem initialization string. (Max length 48 chars)

IP Address to Suggest sets an IP to try to acquire, if defined. Default setting is 0.0.0.0

PPP Hosting Settings

```

SiteBoss 550 - PPP Hosting Settings
A) PPP Hosting Enabled           [OFF]
B) Idle Connection Disconnect (sec) [60]
C) Local (Device) IP Address     [192.168.105.1]
D) Remote (Caller) IP Address    [192.168.105.2]

```

PPP Hosting Enabled is an ON/OFF toggle to enable inbound PPP connection hosting. Default setting is OFF.

Idle Connection Disconnect (sec) sets the number of seconds (0 – 65535) to wait before disconnecting an idle connection. A setting of 0 means the unit does not disconnect due to an idle connection. Default setting is 60 seconds.

Local (Device) IP Address sets the IP address of the S550 for the PPP session. Default is 192.168.105.1

Remote (Caller) IP Address sets the IP address of the calling device for the PPP session. Default is 192.168.105.2.

IP Routing

```

SiteBoss 550 - IP Routing
A) Route PPP to Ethernet         [OFF]
B) Route Ethernet to PPP         [OFF]
C) Ethernet to PPP NAT Enable    [ON]
D) Ethernet Interface            [ETH1]

```

Each of the above options toggles settings for routing TCP/IP packets of specific types and origins to and from a device connected via PPP.

Route PPP to Ethernet toggles ON/OFF to enable the S550 to forward IP frames originating on PPP that are not IP-addressed to the unit, as well as forward IP frames received on Ethernet that are associated with forwarded frames that originated on PPP. Default setting is OFF.

Route Ethernet to PPP toggles ON/OFF to enable the S550 to forward IP frames originating on Ethernet that are not IP-addressed to the unit, as well as forwards IP frames received on PPP that are associated with forwarded frames that originated on Ethernet. Default setting is OFF.

Ethernet to PPP NAT Enable toggles ON/OFF to enable the S550 to do network address translation on these forwarded frames. Default setting is ON.

Ethernet Interface toggles between ETH1, ETH2, or any of the six VLANs that can be configured on either ETH1 or ETH2, to indicate which interface to use for the PPP connection. Default setting is ETH1.

Refer to the [IP Routing](#) section in the Features chapter for a detailed explanation of IP Routing.

Route Test Settings

SiteBoss 550 - Route Test Settings

A) Route Test Enable	[OFF]
B) Minutes Between Tests	[10]
C) IP Address 1	[]
D) IP Address 2	[]
E) IP Address 3	[]

Route Test Enable is an ON/OFF toggle to enable route testing. Default setting is OFF.

Minutes Between Tests sets the number of minutes (0 – 65535) to wait between each round of testing. Default setting is 10 minutes.

IP Address *n* sets the hostnames or IP addresses to ping for the test.

Email Settings

SiteBoss 550 - Email Settings

A) SMTP Server Hostname/IP Address	[]
B) Email Domain Name	[ASENTRIA.COM]
C) Authentication (LOGIN)	[OFF]

SMTP Server Hostname/IP Address sets the hostname or IP address of the outbound mail server. (Max length 64 chars)

Email Domain Name sets the *@domain_name.com* to use when the S550 sends an Email. Default setting is "ASENTRIA.COM". (Max length 48 chars)

Authentication (LOGIN) displays a menu to configure the credentials that may be required by your server for SMTP authentication. Some SMTP servers require an authentication to relay Emails. Default setting is OFF.

SiteBoss 550 - Email Authentication Settings

A) Authentication Enabled	[OFF]
B) Username	[]
C) Password	[*****]

Authentication Enabled is an ON/OFF toggle to enable Email authentication. Default setting is OFF.

Username/Password defines the login credentials. (Max length for each is 48 chars)

A typical Email notification for a No Data alarm might look like the following:

```
From: Asentria SiteBoss 550 [mailto:Asentria_SiteBoss 550 @Asentria.com]
Sent: Thursday, February 14, 2008 3:59 PM
To: support@Asentria.com
Subject: Event
```

```
02/14 15:59 :: 550000096 :: No-Data 1 Alarm :: No Data Alarm Message
```

Real-Time Socket Settings

```
SiteBoss 550 - Real-Time Socket Setup
A) FILE1
B) FILE2
C) EVENTS

Enter your Selection: a

SiteBoss 550 - FILE1 Real-Time Data Socket Setup
A) Real-Time Socket Mode           [LISTEN]
B) Show Answer String on Connection [ON]
C) Require Xon to Start Data Flow   [OFF]
D) Idle Connection Close Timer     [0]
E) Close Socket When File Empty     [OFF]
F) Real-Time Socket Push Hostname/IP []
G) Real-Time Socket Push Port Number [3000]
H) Real-Time Socket Push Retry Timer [5]
```

Real-Time Socket Mode toggles between LISTEN, PUSH, and OFF. When set to LISTEN this functions like traditional real-time sockets on TCP port 2201. When set to PUSH the unit tries to make a TCP connection on the TCP port specified in G) Real-Time Socket Push Port Number. As long as a connection exists, the unit sends all data in the specified file on the connection as data become available. Default setting is LISTEN.

Show Answer String on Connection is an ON/OFF toggle to enable the prompt indicating successful connection to the Real-Time Socket (RTS) port. Default setting is ON.

Require Xon to Start Data Flow is an ON/OFF toggle to enable the Xon/Xoff data flow control requirement. Default setting is OFF.

Idle Connection Close Timer sets the number of seconds (0 – 255) to wait before disconnecting an idle connection. A setting of 0 means the connection will never automatically close. Default setting is 0.

Close Socket When File Empty is an ON/OFF toggle to set whether or not the S550 will automatically terminate the RTS connection when the file for this port has been emptied. Default setting is OFF.

Real-Time Socket Push Hostname/IP sets the hostname or IP address of the server where the unit will push the data if the RTS Mode is set to Push. (Max length is 64 chars)

Real-Time Socket Push Port Number sets the TCP-port number the RTS push should use. Default setting is port 3000.

Real-Time Socket Push Retry Timer sets the number of minutes (1 – 255) to wait before retrying an RTS push that has previously failed. Default setting is 5 minutes.

SNMP Trap Capture Settings

```
SiteBoss 550 - SNMP Trap Capture Settings
A) SNMP Trap Capture Enable      [OFF]
B) Store Collected Traps In     [FILE1]
```

SNMP Trap Capture Enable is an ON/OFF toggle to enable the capturing of SNMPv1 traps and SNMPv2c inform-requests (informs). Default setting is OFF.

Store Collected Traps In sets the data file in which the collected traps/informs are stored. Default setting is FILE1.

Refer to the [SNMP Trap Capture](#) section in the Features chapter for a detailed explanation of SNMP Trap Capture.

IP Address Restrictions

```
SiteBoss 550 - IP Address Restrictions
No IP Restrictions Established
A) Add Item to Table
```

This menu is used to manipulate the IP restriction table. Refer to the [IP Address Restrictions](#) section in the Features chapter for a detailed explanation of IP Address Restrictions. By default, no address restrictions are configured.

Static Route Settings

```
SiteBoss 550 - Static Route Settings
A) Route 1
B) Route 2
. . .
G) Route 7
H) Route 8

Enter your Selection: a

SiteBoss 550 - Static Route 1 Settings
A) Enable      [OFF]
B) Destination Network [0.0.0.0/0]
C) Gateway     [0.0.0.0]
D) Interface   [NONE]

Enter your Selection:
```

Static routes are network routes that specify in a more or less permanent way (*static*) that traffic to a certain destination (destination host or destination network) gets *routed* out a certain interface or via a certain gateway. Static routes gives you the ability to fine-tune how outbound network traffic leaves the unit for up to eight different routes.

Enable is an ON/OFF toggle to enable a static route. Default setting is OFF

Destination Network is the network notation, i.e., w.x.y.z/s, where s is the significant bits. Default is 0.0.0.0/0.

Gateway is the IP address of the gateway. Default setting is 0.0.0.0

Interface toggles through all of the interfaces' available on this S550 – ETH1, ETH2, E1V1, E1V2, E1V3, E1V4, E1V5, E1V6, E2V1, E2V2, E2V3, E2V4, E2V5, E2V6, PPPP, WPPP, and None. Default setting is NONE.

Refer to the [Static Routes](#) section in the Features chapter for a detailed explanation of Static Routes.

DSL Settings

```

SiteBoss 550 - DSL Settings
A) Start Mode                [MANUAL]
B) Type                      [PPPOA]
C) VPI                      [0]
D) VCI                      [0]
E) Encapsulation            [VCM]
F) Mode                    [BRIDGED]
G) Username                 []
H) Password                 [*****]
I) IP Address               [0.0.0.0]
J) Mask                     [0.0.0.0]
K) Router                   [0.0.0.0]

```

Following describes the menu options for configuring the optional ADSL Modem. For more information regarding the operation of the ADSL modem, Setting Keys, DSL Routing example, and DSL Glossary, please refer to the [ADSL Modem](#) chapter later in this manual.

Start Mode toggles between MANUAL and AUTO to set how the DSL interface is to be raised. Set this to MANUAL to require user intervention to raise the DSL interface, or to let a VPN (if it is configured to use DSL) raise the DSL interface when the VPN needs to use DSL. Set this to AUTO to tell the unit to automatically raise the DSL interface upon boot. Default setting is MANUAL.

Type toggles between PPPoA, PPPoE, Static, or DHCP. This should be set as directed by your ADSL provider. This is the most important DSL setting since its value determines what other DSL settings are applicable to the DSL configuration. Default setting is PPPoA.

VPI sets the [VPI](#) (Virtual Path Identifier) used on the DSL interface. This should be set as directed by your ADSL provider and is required for DSL operation. Values are: 0 to 4095 Default setting is 0.

VCI sets the [VCI](#) (Virtual Channel Identifier) for the DSL interface. This should be set as directed by your ADSL provider and is required for DSL operation. Values are: 0 to 65535. Default setting is 0.

Encapsulation toggles between VCM and LLC to control whether the encapsulation is [LLC](#) (Logical Link Control) or [VCM](#) (Virtual Channel Multiplexed). This should be set as directed by your ADSL provider and is required for DSL operation. Default setting is VCM.

Mode toggles between BRIDGED and ROUTED to control whether the DSL is set up for Bridged mode or Routed mode when the DSL type is STATIC. Default setting is BRIDGED.

Username and **Password** specify the PPP Username and PPP Password for the DSL interface when the DSL type is set to PPPoA or PPPoE. These should be set as directed by your ADSL provider and are required for DSL operation. Values are text strings, max length 64 characters.

IP Address sets the public IP address of the unit in the case where the DSL link is active. If the DSL type is STATIC, the user needs to set this. If the DSL Type if DHCP, it is set automatically. This should be set as directed by your ADSL provider. Value is a dotted quad IP address. Default setting is 0.0.0.0

Mask sets the subnet mask used on the DSL interface. If the DSL type is STATIC, the user needs to set this. If the DSL Type if DHCP, it is set automatically. This should be set as directed by your ADSL provider. Value is a dotted quad subnet mask. Default setting is 0.0.0.0

Router sets the router for the DSL interface. If the DSL type is STATIC, the user needs to set this. If the DSL Type if DHCP, it is set automatically. This should be set as directed by your ADSL provider. Value is a dotted quad IP address. Default setting is 0.0.0.0

VPN Settings

```
SiteBoss 550 - VPN Settings
```

- A) VPN 1
- B) VPN 2
- C) CPE Settings
- D) Commissioning Settings

Following describes the menu options for configuring VPN Settings. These settings are only for use with the Asentria SitePath secure, unified administration portal software. Contact Asentria Technical Support for further information.

VPN 1 and **VPN 2** display a sub-menu where each of two VPN connections can be configured.

CPE Settings displays a series of sub-menus where the IP address (both Real and Alias), name, description, and keep-alive period for up to 64 CPE (Customer Premises Equipment) can be set.

Commission Settings displays a sub-menu where all the parameters for commissioning the S550 with the SitePath application are configured.

Serial Settings

```
SiteBoss 550 - Serial Settings
```

- A) 1-I/O 1 Settings
- B) 2-I/O 2 Settings

» Note: All serial I/O ports are set to function in Data and ESBUS mode, except for I/O 2, which can be set to Data and Command mode. Therefore the I/O 2 Settings menu has all the options of I/O 1, plus a few others I/O 1 does not have. Options that are exclusive to I/O 2 will be indicated as such below – all others are applicable to all ports.

Serial Port Menu

```
SiteBoss 550 - Serial 2
```

- | | |
|-------------------------------------|-----------|
| A) Target Name | [I/O 2] |
| B) Baud Rate | [19200] |
| C) Data Format | [8N1] |
| D) Handshaking | [NONE] |
| E) Wrap Around | [OFF] |
| F) Record Stamping | |
| G) Character Masking | [ON] |
| H) Data Alarm Enable | [OFF] |
| I) Store Data To | [2] |
| J) Store Alarms During Pass-Through | [OFF] |
| K) Duplex | [FULL] |
| L) Inactivity Timeout | [0] |
| M) Port Mode | [COMMAND] |
| N) Strip Sent Pass-Through LFs | [OFF] |
| O) Strip Received Pass-Through LFs | [OFF] |
| P) Multiline Record Settings | [OFF] |
| Q) Data Type | [ASCII] |
| R) Change ETX to CR/LF | [OFF] |

Target Name is the name given to the device connected to the other end of each port. The target name is used in event notifications. Default setting is I/O n. (Max length is 24 chars)

Baud Rate displays a selection menu for baud rates available for the port. These values range from 300 baud to 115200 baud. Default setting is 19200.

Data Format toggles settings for word length, parity, and stop bit settings. The available options are: 8N1, 7E1, 7O1, 7N1, and 8O2. Default setting is 8N1.

Handshaking toggles settings for how the port will handshake with the connected device. The available options are: NONE, XON/XOFF, BOTH, and DTR. Default setting is NONE.

Wrap Around is an ON/OFF toggle to set whether the incoming data will wrap (overwrite) the oldest data in the file should it become full. Default setting is OFF.

Record Stamping displays a menu that allows you to select whether the Date/Time and/or the Site Name are pre-pended to each incoming data string. Default setting for Date/Time Stamping and Site Name Stamping is OFF.

Character Masking is an ON/OFF toggle to enable the character mask. The character mask allows you to block most non-printing ASCII characters. Specifically, the following ASCII character values are blocked: 0, 1, 4-9, 11, 12, 14-31, and 128-255. Default setting is ON.

Data Alarm Enable is an ON/OFF toggle to enable data alarm monitoring for this port. Default setting is OFF.

Store Data To displays a menu that allows you to toggle ON/OFF the files to which incoming data on this port should be stored, if any.

Store Alarms During Pass-Through is an ON/OFF toggle to determine whether data strings that meet data alarm criteria are stored in the Events File when a pass-through session is active on this port. Default setting is OFF.

Duplex (Port 2 only) toggles between FULL and HALF. Full duplex causes the unit to echo all characters sent to the connected terminal when in Command mode. Half duplex turns off character echo. Default setting is FULL.

Inactivity Timeout (Port 2 only) is the time (1 - 255 minutes) before a serial connection with no activity will be terminated. A setting of 0 means an inactive connection will not be terminated. Default setting is 0.

Port Mode sets the port function.

- **IO/1** toggles between DATA and ESBUS. DATA configures the port as an inbound RS232 data port. ESBUS configures the port to communicate with external RS485 Asentria EventSensors. (This requires the use of an RS232-RS485 adapter)
- **IO/2** toggles between COMMAND and DATA. COMMAND allows for serial command processor access. DATA configures the port as an inbound data port just like I/O 1.

Strip Sent Pass-Through LFs is an ON/OFF toggle to enable the stripping of linefeeds on passthrough data *sent out* of the S550. Default setting is OFF.

Strip Received Pass-Through LFs is an ON/OFF toggle to enable the stripping of linefeeds on passthrough data *received* by the S550. Default setting is OFF.

[Multiline Record Settings](#) displays the Multiline Record Settings menu.

Data Type toggles between ASCII and BINARY to indicate the type of data being collected on this port. Default setting is ASCII.

Change ETX to CR/LF is an ON/OFF toggle to set whether ETX characters in the incoming data should be converted to CR/LF characters. Default setting is OFF.

Multiline Record Settings

```
SiteBoss 550 - Serial Port 1 Multiline Record Settings
A) Multiline Record Enable           [OFF]
B) Blank Line Count                  [0]
C) Complex Multiline Detection       [OFF]
```

The S550 has the ability to monitor incoming serial data for multi-line records (individual records that are broken into multiple lines with carriage returns). If the records are separated by a specific number of blank lines, this basic configuration menu will suffice. If a more complex delineation scheme is used, enable Complex Multiline Detection.

Multiline Record Enable is an ON/OFF toggle to enable multiline record detection. Default setting is OFF.

Blank Line Count sets the number of blank lines that must come between records. Default setting is 0.

Complex Multiline Detection displays settings for detecting more complex multiline records. Default setting is OFF.

```
SiteBoss 550 - Serial Port 1 Complex Multiline Record Settings
A) Complex Multiline Record Enable      [OFF]
B) Start Field 1 Character Position      [0]
C) Start Field 1 Text                    []
D) Start Field 2 Character Position      [0]
E) Start Field 2 Text                    []
F) Collect Lines Before Start Record     [0]
G) End Detection                         [FORMULA]
H) Line Count                           [0]
I) End Field 1 Character Position         [0]
J) End Field 1 Text                      []
K) End Field 2 Character Position         [0]
L) End Field 2 Text                      []
```

Complex Multiline Record Enable is an ON/OFF toggle to enable advanced multiline detection. Default setting is OFF.

Start Field *n* Character Position sets the character position used to define the beginning of the multiline field. This option is used with "Count" method record end detection.

Start Field *n* Text sets the text used to determine the beginning of the multiline field. This option is used with "Formula" method record end detection.

Collect Lines Before Start Record sets the number of blank lines that are between each record.

End Detection toggles between FORMULA, COUNT, and BLANKS to set the method of detecting the end of each record. Default setting is FORMULA.

Line Count is the number of lines to meter each record at. This option is used with "BLANKS" record end detection.

End Field *n* Text/Character Position is the counterpart to start the text or character position option. This option sets the end delimiter for multiline records.

Modem Settings

```
SiteBoss 550 - Modem Settings
A) Dialup Modem
B) Wireless Modem
```

The Modem Settings menu displays two sub-menus for configuring either the internal 56K modem, or an optional wireless modem expansion card.

Dialup Modem

```
SiteBoss 550 - Dialup Modem Settings
A) Data Format          [8N1]
B) Duplex               [FULL]
C) Init String          [ATM1]
D) Inactivity Timeout   [0]
E) Upon Modem Connect Go Directly To [LOGIN]
F) Caller ID Security   [OFF]
```


Note: If the optional 56K dialup modem is not installed in the S550, this menu is displayed, but changing any of the settings will not do anything.

Data Format toggles settings for word length, parity, and stop bit settings. The available options are: 8N1, 7E1, 7O1, and 7N1. Default setting is 8N1.

Duplex controls the echo settings for the modem command processor. Full duplex causes the S550 to echo all characters sent to the remote device. Half duplex turns off character echo. Default setting is FULL.

Init String sets the user-defined modem initialization string. This string is sent to the modem before important factory modem initialization settings, so certain settings in this init string may be overridden. Default setting is ATM1. (Max length 126 chars) **Note:** Make sure to enter 'AT' at the beginning of this initialization string.

Inactivity Timeout sets the number of minutes (0 – 255) to wait before disconnecting an idle modem connection. A setting of 0 means the connection will never automatically expire. Default setting is 0.

Upon Modem Connect Go Directly To toggles through a list of actions to control what a user sees directly after connecting via modem. LOGIN requires the user to login with username and password, and will then take them to a command prompt. A serial port (I/O1, I/O2, etc.) redirects a modem user directly to that serial port upon connecting. In this passthrough mode, the command processor of the S550 is transparent. Default setting is LOGIN.

Caller ID Security displays a menu that allows you to configure from one to twenty inbound phone numbers to restrict modem access.

Caller ID Security

```
SiteBoss 550 - Caller ID Security
A) Enable                               [OFF]
B) Caller ID 1                           []
   ...
U) Caller ID 20                           []
V) Add Number From Log List
```

Note: Caller ID must be available on the phone line connected to the S550 for this feature to work.

Enable is an ON/OFF toggle to enable caller ID restrictions. When enabled, the S550 will only answer the modem if caller ID indicates one of the allowed phone numbers is connecting. Default setting is OFF.

Caller ID *n* allows you to add or change a specific phone number. You are allowed to use simple wildcards in phone numbers: An asterisk (*) wildcard allows for any number of digits to appear to the right of that position. A question mark (?) matches any single digit. If no numbers are defined in this menu, all incoming calls are accepted. (Max length 47 chars)

Add Number From Log List displays a list of phone numbers that have recently dialed into the S550 for addition to this list.

Wireless Modem

```
SiteBoss 550 - Wireless Modem Settings
A) Mode                               [OFF]
B) APN                                []
C) PIN                                []
D) Idle Timeout (minutes)             [5]
E) Band (GPRS only)                   [DUAL-850/1900]
F) PPP/Wireless User Name              []
G) PPP/Wireless Password               [*****]
H) Default Route Enable                [OFF]
```

>> Note: If the optional wireless modem expansion card is not installed in the S550, this menu is displayed, but changing any of the settings will not do anything, except for the PPP/Wireless User Name and Password settings (see below).

>> Note: For a complete description of the setup and operation of the wireless modem, please refer to the [Wireless Modem](#) chapter later in this manual.

Mode toggles between OFF (disable modem), PERMANENT-EDGE (maintain “always-on” connection with EDGE modem), and PERMANENT-GPRS (maintain “always-on” connection with GPRS modem). Default setting is OFF.

APN sets the Access Point Name (APN) as defined by your wireless provider. Default setting is “”. (Max length is 31 chars)

PIN sets the PIN associated with the SIM card (if any). Default setting is “”. (Max length is 15 chars)

Idle Timeout sets the number of minutes (3 – 255) to wait before disconnecting an inactive modem connection. The purpose of this setting is to allow the modem to get reset after a period of inactivity to ensure the modem connection is working properly. Default setting is 5 minutes.

Band (GPRS only) toggles between DUAL - 850/1900, DUAL – 900/1800, DUAL – 900/1900, MONO – 850, MONO – 900, MONO-1800, and MONO – 1900. This sets the GSM bands on which the modem will operate. Default setting is DUAL - 850/1900.

>> Note: This setting is only used with the GPRS modem. For this setting to take effect, the wireless modem must be reset; this can be accomplished by restarting the host unit, or by setting the wireless modem mode to OFF for at least 10 seconds, then back to a GPRS setting.

PPP Wireless User Name/Password sets the login credentials for the PPP connection. These settings are identical to the same settings in the [PPP Dialout Settings](#) menu– so a change in one menu will change the settings in the other. (Max length for each is 64 chars)

Default Route Enable is an ON/OFF toggle to enable the wireless interface to be the default route when connected. Default setting is OFF.

User Profile Settings

```
SiteBoss 550 - User Profile Settings Menu
A) User 1: admin/*****/COMMAND/FILE1
B) User 2:
. . .
K) User 11:
L) User 12:
M) Global Password/Security Settings
```

[User n](#) displays the configuration menu for each user profile.

[Global Password/Security Settings](#) displays a menu of global security options.

>> Note: Passwords are case sensitive and are masked in all menus and while typing them from the command line, for security reasons. If a user without permissions accesses the User Profile Settings menus, they will see all fields in this menu either masked or with no data in them. If they select an option, a message will be displayed that says: “You do not have permission to change this setting.”

>> Note: If an invalid or duplicate username is entered, the S550 responds as follows:

```
Invalid Entry.
Press any key to continue...
```

Note: When configuring a new password, the S550 will ask you to re-enter the password. If the second entry of the password does not match the first, the S550 responds as follows:

```
Invalid Entry - Confirm Password does not match.
Press any key to continue...
```

User Setup Menu

```
SiteBoss 550 - User Setup Menu
A) Enable This User Access          [ON]
B) User Name                        [admin]
C) Password                        [*****]
D) User Profile Expiration Date/Time []
E) Allow User Connection via        [LMTFRSs]
F) Upon Login then Go To            [COMMAND]
G) Set Pass-through Pointer To      [FILE1]
H) Pass-through Permissions
I) After PT, ESC Takes User To      [MENU]
J) PPP Connection                   [ROUTING]
K) Setup/Status Rights              [MASTER]
L) File Release Permissions
M) File Delete Permissions
N) Additional Authentication Options
```

Enable This User Access is an ON/OFF toggle to enable access for this user profile. Default setting is OFF for all except User 1.

User Name/Password sets the username and/or password for this profile. Default is blank for all except User 1 which is User Name: **admin** and Password: **password** (Max length for each is 31 chars)

User Profile Expiration Date/Time sets a date and/or time that this profile may be automatically disabled. This also provides an option to adjust the current date/time that is on the S550. Selecting that option will transfer you to the System Date/Time menu. If left blank, this user profile will not expire. Default setting is blank.

Allow User Connection via displays a menu allowing you to toggle ON or OFF access via Local (I/O 2), Modem, Telnet, FTP, Real-Time Socket, and Secure Shell (SSH). These are abbreviated: LMTFRSs and default setting for all is ON.

Upon Login then Go To toggles the action this user will be directed to upon logging in, with the following options: Menu, Command, and Passthrough as shown here:

Menu

```
SiteBoss
Password: *****

SiteBoss 550 Version 2.03.040
at 550-550000096

1. Pass-Through to I/O 1
2. Pass-Through to I/O 2
P. 550 Command Prompt
M. 550 Setup Menu
S. 550 Status Menu
X. Exit (end connection)
```

Command

```
SiteBoss
Password: *****

READY
>
```

Passthrough

```
SiteBoss
Password: *****

Connected to I/O 1
```

Set Pass-through Pointer To is in effect if the “Upon Login then Go To” action is set to Passthrough. This option toggles the serial port the user will be routed to. Default setting is File1.

Pass-through Permissions is in effect if the “Upon Login then Go To” action is set to Menu. This option displays a menu showing all serial ports, and allows you to toggle ALLOW or DENY for each port as needed. If a port is set as ALLOW, then that serial port is displayed in the Menu after the user logs in. If a port is set as DENY, then that serial port is not displayed in the Menu. Default setting for all ports is ALLOW.

After PT, ESC Takes User To sets the action this user can perform when they exit out of a passthrough connection.

PPP Connection toggles between LOCAL, ROUTING and NONE. LOCAL allows PPP access, but denies all routing to whatever LAN the S550 is connected to. ROUTING enables Route Ethernet to PPP and Route PPP to Ethernet for the user, but only if those settings are enabled globally. NONE disables PPP access for the user. Default setting is ROUTING.

Setup/Status Rights toggles through the actions available to the user if they are given access to the command prompt. Options are MASTER, NONE, VIEW, ADMIN1, ADMIN2, and ADMIN3. See the [User Rights Table](#) for more information on each access level. Default setting is MASTER.

File Release/Delete Permissions displays a menu showing all data files, Events Log and Audit Log, and allows you to toggle ALLOW or DENY for each as needed. Default setting for all is ALLOW.

Additional Authentication Options displays extra-high security options.

```
SiteBoss 550 - Additional Authentication Options
A) Secure Authentication via Telnet          [OFF]
B) For Telnet, Send Password To             []
C) Secure Authentication via Modem          [OFF]
D) For Modem, Send Password To             []
E) Secure Authentication via Local Command Port [OFF]
F) Password Expires After                   [30]
G) Secure Callback 1                       []
H) Secure Callback 2                       []
I) Secure Callback 3                       []
```

Secure Authentication via Telnet/Modem toggles between OFF (regular), CHALLENGE, and SEND PASSWORD and CALLBACK (modem only) authentication modes. Default setting for each is OFF.

OFF (regular) authentication requires only the normal username/password authentication.

CHALLENGE requires the user send their username/password and then they are prompted with a short challenge code. That code must be plugged into a program called Response Code Generator (RCG). This software can be found on the Documentation and Utilities CD. Contact Asentria for more information on how to use or obtain this application. RCG requires a shared secret as well as the challenge code generated by the S550. The user must then respond with the proper hash generated by RCG in order to gain access.

SEND PASSWORD will generate a single-use password and send it to the Email address(es) specified by the next option. That password will only allow a login for the user whom it was generated for.

CALLBACK initiates a modem callout to the numbers configured in **Secure Callback *n*** options below.

For Telnet/Modem, Send Password To sets the Email address(es) where the single-use password is to be sent.

Secure Authentication via Local Command Port toggles between OFF (regular), and CHALLENGE. Because the user is connected via the local Console port, Send Password is not an option. Default setting is OFF.

Password Expires After sets the number of minutes (0 – 180) before the single-use password expires. A setting of 0 means the password will never automatically expire. Default setting is 30.

Secure Callback *n* sets the modem callback numbers. If configured, the S550 will disconnect any modem connections from this user and then attempt to dial out to each of these numbers. If one of the numbers answers, the other end must respond with the login credentials of the user used to initiate the callback. (Max length 48 chars)

Global Password/Security Settings

```
SiteBoss 550 - Global Password/Security Settings Menu
A) Show Username/Password Prompt      [OFF]
B) Local Command Requires Password    [OFF]
C) Modem Callin Requires Password     [OFF]
D) Globally Allow Access via          [MTRFSs]
E) TCP/IP Port 23 Requires Password   [ON]
F) TCP/IP Port 210x Requires Password [OFF]
G) TCP/IP Port 220x Requires Password [OFF]
H) Username and/or Password Required  [PASSWORD ONLY]
I) Shared Secret for Challenge/Response []
```

Global Password/Security Settings set parameters for passwords and security that are required for **every** user who attempts to log into the S550.

Show Username/Password Prompt is an ON/OFF toggle to set whether a prompt for logging in is displayed. Default setting is OFF.

Local Command Requires Password is an ON/OFF toggle to set whether a password for I/O 2 users is required. Default setting is OFF.

Modem Callin Requires Password is an ON/OFF toggle to set whether a password for modem users is required. Default setting is OFF.

Globally Allow Access via displays a menu allowing you to toggle ON or OFF access via Modem, Telnet (ports 23, 200x, 210x), FTP, Real-Time Socket, and Secure Shell (SSH). These are abbreviated: MTRFSs and default setting for all is ON.

TCP/IP Port 23 Requires Password is an ON/OFF toggle to set whether a password for Telnet (port 23) users is required. Default setting is ON.

TCP/IP Port 210x Requires Password is an ON/OFF toggle to set whether a password for passthrough (port 210x) users is required. Default setting is OFF.

TCP/IP Port 220x Requires Password is an ON/OFF toggle to set whether a password for real-time socket (port 220x) users is required. Default setting is OFF.

» **Note:** If any of the above options are set to OFF, users connecting via that method are automatically granted all access.

Username and/or Password Required toggles between: PASSWORD ONLY, USERNAME/PASSWORD (PW), or PASSWORD(PW)/USERNAME. Default setting is PASSWORD ONLY.

Shared Secret for Challenge/Response sets the shared secret used to generate Challenge/Response codes. (Max length 48 chars)

Alarm/Event Definitions

» **Note:** Refer to the [Data Events](#) section in the Features chapter for an example-driven approach to defining alarm definitions.

```
SiteBoss 550 - Alarm/Event Definitions Menu
A) Class Table
B) Data Alarm/Filter Settings
C) EventSensor Device Settings
D) No-Data 1 Alarm Settings           [OFF]
E) No-Data 2 Alarm Settings           [OFF]
F) Scheduled Event 1 Settings          [OFF]
G) Scheduled Event 2 Settings          [OFF]
H) Serial Handshaking Alarm Settings
I) Data Filter Action                 [REJECT]
J) Asentria Alarm Version              [1.1]
K) Require Asentria Alarm ACKs         [OFF]
```

[Class Table](#) displays the menu for configuring event classification settings.

[Data Alarm/Filter Settings](#) displays the menus for configuring serial data event monitors.

[EventSensor Device Settings](#) displays the menus for configuring internal and external sensors and modules that may be installed.

[No-Data *n* Alarm Settings](#) displays the menus for configuring alarms based on period of time when no-data is received on a specific serial port.

[Scheduled Event *n* Settings](#) displays the menus for configuring alarm notifications for specific times and days of the week.

[Serial Handshaking Alarm Settings](#) displays the menu for enabling serial handshaking alarms for specific ports.

Data Filter Action toggles between REJECT and ACCEPT to indicate whether data filters are configured to reject or accept specific incoming data string(s). Default setting is REJECT.

Asentria Alarm Version toggles between 1.0 and 1.1 to indicate which type of Asentria Alarm notification will be displayed. Refer to the [Asentria Alarms](#) section in the Features chapter for a detailed explanation of Asentria Alarms.

Require AsentriaAlarm ACKs is an ON/OFF toggle to enable or disable forcing the unit to require an acknowledgment when first connecting, and after each Asentria Alarm. If disabled, the S550 will allow non-CRC mode where Asentria Alarms are delivered without waiting for any indication that the messages were properly delivered. If enabled, CRC mode is required by the S550. Refer to the [Asentria Alarms](#) section for more information about CRC and non-CRC modes. Default setting is OFF.

Class Table

```

SiteBoss 550 - Class Table
A) Class 1                      [Info]
B) Class 2                      [Minor]
C) Class 3                      [Major]
D) Class 4                      [Critical]
E) Class 5                      []
...
L) Class 12                     []

```

Class *n* defines the event classification assignable to events detected by the S550. (Max length 47 chars)

Info, Minor, Major, and Critical are the default class names assigned to the first four classes. These can be changed and others added as desired to meet your specific needs.

The class number and name are reported in Asentria Alarms, and SNMP traps. It is a mechanism for you to provide varying severities for different alarms so that you can act on them upon receipt.

Data Alarm/Filter Settings

```

SiteBoss 550 - Data Alarm/Filter Settings
A) Data Alarm Field Settings
B) Data Alarm Macro Settings
C) Data Alarm Settings
D) Display Alarm Status
E) Exit Upon True Data Alarm    [OFF]

```

[Data Alarm Field Settings](#) displays the menu for configuring up to 16 data alarm fields.

[Data Alarm Macro Settings](#) displays the menu for configuring up to 100 macros to be used for data alarming.

[Data Alarm/Filter Settings](#) displays the menu for configuring up to 1000 data alarms or filters.

Display Alarm Status displays real time information on data event monitors you've configured.

Exit Upon True Data Alarm is an ON/OFF toggle to set whether the S550 will stop processing more data event evaluations on a single record after it has found one match. This should be disabled if it is possible to have more than one event in a record. This is a global setting – it applies to ALL configured data alarms. Default setting is OFF.

Data Alarm Field Settings

```

SiteBoss 550 - Data Alarm Field Definition Table
      Start   Length   Line   Type      Name
A) Definition A      0      0      0   [Alpha]
B) Definition B      0      0      0   [Alpha]
...
P) Definition P      0      0      0   [Alpha]

Enter your Selection: a


SiteBoss 550 - Data Alarm Field Definition
Data Field: A
A) Start Position          [0]
B) Field Length            [0]
C) Field Name              []
D) Field Line Number       [0]
E) Field Type              [Alpha]

```

Start Position sets the number of the characters to begin a particular alarm field starting from position 1. Field definition is disabled if set to 0.

Field Length sets the length of this particular alarm field. Default setting is 0.

Field Name sets the name given for the alarm field. This name must be unique, is limited to 12 characters, and it must not contain any spaces. It can contain alphanumeric characters and the underscore, but it must start with a letter. These field names are case sensitive. If left blank, you can refer to the field by it's field letter (A,B, etc...).

 **Note:** The S550 does not perform error checking to ensure that no two fields have the same name. Please make sure your fields all have unique names to avoid conflicts.

Field Line Number sets the optional line number the field should be limited to in multiline records.

Field Type toggles between Alpha and Numeric. Alpha is used for most alphanumeric data alarming, and Numeric is used if you need to alarm on a range of numbers. Default setting is Alpha.

Data Alarm Macro Settings

```
SiteBoss 550 - Data Alarm Macro Settings
A) Macro 1                      []
B) Macro 2                      []
...
P) Macro 16                    []
Q) Next Macro Page

Enter your Selection: a

SITEBOSS - Settings for Data Alarm Macro 1
A) Name                        []
B) Equation                    []
```

Data alarm macros provide a way to define up to 100 equations that can be used in one or more data alarm equations. Each macro consists of an equation and an associated name that can be used to reference the macro in a data alarm equation. Refer to the [Data Alarm Macros](#) section in the Features chapter for more information.

Data Alarm/Filter Settings

```
SiteBoss 550 - Data Alarm/Filter Settings
A) Alarm/Filter Page 1 (Alarms 1-16)
B) Alarm/Filter Page 2 (Alarms 17-32)
...
P) Alarm/Filter Page 16 (Alarms 241-256)
Q) Next Page Selection Screen
```

Data alarms are configured by selecting an option from the main Data Alarm/Filter Settings menu, then selecting one of the options which will give you a group of 16 data alarm/filters (1-16, 17-32, etc) or selecting the Next or Previous Page Selection Screen. This will display a menu where you can select from those 16 data alarm options as follows:

```
SiteBoss 550 - Data Alarm/Filter Settings
A) Alarm/Filter 1                []          [OFF]  [ALARM]
...
P) Alarm/Filter 16               []          [OFF]  [ALARM]
Q) Next Alarm/Filter Page
R) Setup Alarm/Filter Fields
S) Display Alarm Status
T) Exit Upon True Data Alarm     [OFF]
```

Enter your Selection:

[Alarm/Filter *n*](#) displays the menu where an individual data alarm or filter can be configured.

Next or Previous Alarm/Filter Page displays either the next or previous set of 16 Data Alarm/Filters.

Setup Alarm/Filter Fields displays the identical [Data Alarm Field Setting](#) menu as described above. This is simply an easy way to access that menu without having to exit back through the previous menus.

Display Alarm Status displays real time information on data event monitors you've configured.

Exit Upon True Data Alarm is an ON/OFF toggle to set whether the S550 will stop processing more data event evaluations on a single record after it has found one match. This should be disabled if it is possible to have more than one event in a record. This is a global setting – it applies to ALL configured data alarms. Default setting is OFF.

Data Alarm/Filter *n* Settings

```
SiteBoss 550 - Settings For Data Alarm/Filter 1
A) Alarm/Filter Enable           [OFF]
B) Alarm/Filter Mode             [ALARM]
C) Alarm/Filter Name             []
D) Alarm/Filter Equation         []
E) Threshold                     [1]
F) Auto-Clear when Threshold Reached [ON]
G) Alarm Counter Clear Interval  [12 HOURS]
H) Alarm Counter Reset Time      [00:00]
I) Actions                       []
J) Class                         [Info]
K) Data Alarm Trap Number        [503]
L) Clear This Alarm Counter Now
```

Alarm/Filter Enable toggles each individual data event monitor ON or OFF. Default setting is OFF.

Alarm/Filter Mode toggles between ALARM and FILTER to indicate whether the S550 will recognize this data event as an Alarm and take some action, or as a Filter and either accept or reject the data string. Default setting is ALARM.

Alarm/Filter Name sets the name for the event monitor. This name is reported with the specified actions. (Max length 16 chars)

Alarm/Filter Equation defines the event equation using the event fields defined in the previous menu. (Max length 160 chars) Refer to the [Configuring Data Alarm Equations](#) section in the Features chapter for more information.

Threshold sets the number of times the event equation must be matched before an event is triggered. If the event counter is allowed to grow beyond the threshold, the unit will not trigger an event again until after the counter is reset. Default setting is 1.

Auto-Clear when Threshold Reached is an ON/OFF toggle to control whether the unit will clear the event counter each time the threshold is met. Default setting is ON.

Alarm Counter Clear Interval sets an interval at which the unit should clear the match counter for an individual data event. Available options are: 2 hours, 4 hours, 6 hours, 8 hours, 12 hours, Daily, and Never. The first clear occurs at midnight. Default setting is 12 Hours.

Alarm Counter Reset Time sets the time at which the daily clear should take place if it is enabled in the Alarm Counter Clear Interval. This value is in 24-hour format. Default setting is 00:00.

Actions displays the [Actions List](#), a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Data Alarm Trap Number sets the number to be sent with any SNMP traps for this event. Default is 503, but trap number can also be set in the range of 1000 – 1199 as needed.

Clear This Alarm Counter Now allows you to manually clear the counter for the selected data alarm. This happens as soon as this option is selected, so make sure you really want to clear the counter before selecting it.

Actions List

```
Enter one or more actions using this format:
(For more details see the users manual)
-----
Cancel : cancel(idname)
Dispatcher : dispatch(phone# or index)
Email : email(email or index)
Group : group(groupname)
ID : id(id name)
Inform : inform(ipaddress or index)
Malert : malert(phone# or index)
Modem : modem(phone# or index)
Postpone : postpone(idname, seconds)
Pause : pause(seconds)
Relay : relay(action, eventsensor, point)
Script : script(action, name or number)
Talert : talert(ipaddress or index)
Trap : trap(ipaddress or index)
(separate multiple actions using semicolon)

Current Actions:
Enter Data Alarm Actions:
```

The Actions List provides you with a flexible mechanism to tell the unit how to react to events. An action list is a text string that specifies what the unit should do upon an event. It's comprised of a list of keywords and parameters separated by semicolon. Each keyword specifies a certain action and has its own parameter set, which is enclosed in parentheses. Refer to [Action List](#) in the Features chapter for more information.

EventSensor Device Settings

The S550 supports a wide variety of internal and external sensor devices and relays, including contact closures, temperature and humidity sensors, analog voltage and current sensors, and relays. For the purposes of clarity, all of these will be generally referred to as “EventSensors” (ES) unless a specific type of sensor or relay is being described.

Internal sensors are those on Expansion Cards that can be installed in the expansion bays on the back of the S550. External sensors separate devices available from Asentria that are connected to serial I/O1 (set to ESBUS mode) via an RS232-RS485 adapter. Additionally, the two serial I/O ports on the S550 can also be wired as contact closures.

The Sensor Events Menu is used to configure and control EventSensors. If you don't have any internal sensors or relays, or remote ES modules connected, this menu will be unpopulated except for the two internal I/O ports shown as “2-CC”. Because of the numerous ES configurations possible, menus shown in this section will probably not look exactly like the ones for your S550. (The menu below shows an S550 Sensor Events Menu with the two internal I/O ports and one external ES-3 module with temperature sensor and 8 contact closures.)

```
SiteBoss 550 - Sensor Events Menu
  Name                ID          Alive    Number    Configuration
A) INTERNAL           -         -        200       2-CC
B) ES-3 Test          06021892  Y         1         1-TS 8-CC
C) <none>
...
Q) <none>
R) Sensor Unresponsive Settings
```

[EventSensor Slots](#) (A thru Q) displays the settings menu for each ES.

[Sensor Unresponsive Settings](#) displays the Sensor Unresponsive Menu where you can configure the actions the S550 takes if an ES becomes unresponsive.

EventSensor Slots

```
SiteBoss 550 - Internal Events Menu
A) Device Name [INTERNAL]
B) Contact Closure 1 [unnamed]
C) Contact Closure 2 [unnamed]
Enter your Selection:
```

The display for each EventSensor will vary depending on configuration. EventSensors can be configured with varying combinations of the following I/O types. Refer to the [Event Sensor Configuration Setup](#) section in the Features chapter for more information.

- [Contact Closure](#)
- [Temperature sensor](#)
- [Humidity sensor](#)
- [Analog voltage sensor](#)
- [Relay output](#)

Sensor Unresponsive Settings

```
SiteBoss 550 - Sensor Unresponsive Menu
A) Sensor Unresponsive Timeout [30]
B) Sensor Unresponsive Actions []
C) Sensor Unresponsive Trap Number [50]
D) Sensor Unresponsive Class [Info]
```

Sensor Unresponsive Timeout sets the time (10 - 65535 seconds) to wait before declaring a non-communicative EventSensor unresponsive. Default setting is 30.

Sensor Unresponsive Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Sensor Unresponsive Trap Number sets the number to be sent with any SNMP traps for this event. Default is 50, but trap number can also be set in the range of 1000 – 1199 as needed.

Sensor Unresponsive Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

No-Data *n* Alarm Settings

No Data Alarms can be configured on the S550 to monitor data coming in via the serial ports, and take an alarm action if a certain period of time passes with no data.

```
SiteBoss 550 - No-Data Alarm 1 Settings
A) Alarm Enable           [OFF]
B) Alarm Actions          []
C) Alarm Message          [No-Data Timeout 1]
D) Alarm Class            [Info]
E) Trap Number            [505]
F) Schedule 1 Begin Time  [00:00]
G) Schedule 1 End Time    [00:00]
H) Schedule 1 Duration (minutes) [0]
I) Schedule 2 Begin Time  [00:00]
J) Schedule 2 End Time    [00:00]
K) Schedule 2 Duration (minutes) [0]
L) Apply Alarm on Days    [MTuWThF]
M) Enable Ports
N) Add Exclusion
O) Delete Exclusion
   []
   []
```

No-Data *n* Alarm Settings allows you to configure two separate No-Data Alarms, each of which can be configured for two different ranges of times with different time durations. The periods of time should be configured to match the calling patterns of your business or organization. For example, if your normal business hours are M-F 8:00 to 5:00, you will want to set lower time durations during those hours than you would “after hours” when call volumes are lighter and the periods of time where there is “no data” might be longer.

Alarm Enable is an ON/OFF toggle to enable the no-data monitor. Default setting is OFF.

Alarm Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Alarm Message sets the text string to be delivered with this event's alarms. Default setting is "No-Data Timeout *n*". (Max length 126 chars)

Alarm Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this no-data alarm.

Trap Number sets the number to be sent with any SNMP traps for this event. Default is 505, but trap number can also be set in the range of 1000 – 1199 as needed.

Schedule *n* Begin Time/End Time sets the beginning and ending times (24 hour clock) for each of two ranges of time.

Schedule *n* Duration is the number of minutes (0-65535) the unit will wait without receiving data before alarming.

Apply Alarm on Days displays a menu where the seven days of the week are listed, and each can be toggled ON or OFF to designate whether this particular No-Data alarm is active on that day. Default setting is ON for Monday thru Friday, and OFF for Saturday and Sunday.

Enable Ports displays a menu where the installed serial ports are listed and each can be toggled ON or OFF to designate whether this particular No-Data alarm is active on that port. Default setting is OFF for all ports.

Add Exclusion/Delete Exclusion allow you to add or delete specific dates when this No-Data Alarm should “take the day off”. For example, Christmas is a day you might want to add here. Select Add Exclusion and type in **12/25**. To delete a date, you select Delete Exclusion and type in the date you want to remove. After an exclusion date is added it appears in the brackets at the bottom of the menu. 15 dates can be entered to be excluded.

Scheduled Event Settings

Scheduled Events allow you to schedule specific a specific date/time for an alarm action to occur. For example, you might want the S550 to send you an Email every morning at 8:00 just so you know it is live on the network.

```
SiteBoss 550 - Scheduled Event 1 Setup
A) Enable Event                [ON]
B) Event Actions                []
C) Event Message               [Scheduled Event 1]
D) Event Class                 [Info]
E) Trap Number                 [506]
F) Event Time Sunday           [OFF]
G) Event Time Monday           [OFF]
H) Event Time Tuesday          [OFF]
I) Event Time Wednesday        [OFF]
J) Event Time Thursday         [OFF]
K) Event Time Friday           [OFF]
L) Event Time Saturday         [OFF]
M) Add Exclusion
N) Delete Exclusion
    []
    []
```

Scheduled Event *n* Setup allows you to configure two separate Scheduled Events, each of which can be configured for any one time on any day of the week. Each day’s time can be scheduled independently from the others.

Enable Event is an ON/OFF toggle to enable the Scheduled Event. Default setting is OFF.

Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information..

Event Message sets the text string to be delivered with this event’s action. Default setting is "Scheduled Event *n*". (Max length 126 chars)

Event Class sets the class for the event. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this event.

Trap Number sets the number to be sent with any SNMP traps for this event. Default is 506, but trap number can also be set in the range of 1000 – 1199 as needed.

Event Time *day* sets the time (24 hour clock) each day at which the scheduled event action will occur. If no time is configured for any day, this menu displays OFF. Default setting is OFF for each day.

Add Exclusion/Delete Exclusion allow you to add or delete specific dates when this Scheduled Event should “take the day off”. For example Christmas is a day you might want to add here. Select Add Exclusion and type in **12/25**. To delete a date, you select Delete Exclusion and type in the date you want to remove. After an exclusion date is added it appears in the brackets at the bottom of the menu. 15 dates can be entered to be excluded.

Serial Handshaking Alarm Settings

Serial Handshaking Alarms allows the S550 to monitor each of its serial ports and alert you if the DTR signal from the connected devices drops low. This would be an indicator that the connected device has failed, the cable between the S550 and the device has been disconnected, or a number of other reasons depending on the device. It can also alert you when the DTR signal goes high again.

```
SiteBoss 550 - Serial Handshaking Alarm Settings
A) I/O 1 Serial Handshaking Alarms      [OFF]
B) I/O 2 Serial Handshaking Alarms      [OFF]
```

[I/O n Serial Handshaking Alarms](#) displays a menu for configuring alarming on serial DTR handshaking conditions.

I/O n Serial Handshaking Alarms

```
SiteBoss 550 - I/O 1 Serial Handshaking Alarms
A) Serial Handshaking Low Alarm Enable  [OFF]
B) Serial Handshaking Low Alarm Actions []
C) Serial Handshaking Low Alarm Message [Handshake Low]
D) Serial Handshaking Low Alarm Class   [Info]
E) Serial Handshaking Low Trap Number   [510]
F) Serial Handshaking High Alarm Enable [OFF]
G) Serial Handshaking High Alarm Actions[]
H) Serial Handshaking High Alarm Message[Handshake High]
I) Serial Handshaking High Alarm Class  [Info]
J) Serial Handshaking High Trap Number  [510]
```

Serial Handshaking Low/High Alarm Enable is an ON/OFF toggle to enable alarming on high or low handshaking levels. Default setting is OFF.

Serial Handshaking Low/High Alarm Actions displays the Actions List, a menu where the action string for the alarm is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Serial Handshaking Low/High Alarm Message is the message sent with any text-based action for this event. Default setting is "Handshake Low/High". (Max length for each is 126 chars)

Serial Handshaking Low/High Alarm Class sets the class for the event. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this event.

Serial Handshaking Low/High Trap Number sets the number to be sent with any SNMP traps for this event. Default is 510, but trap number can also be set in the range of 1000 – 1199 as needed.

Action Definitions

This menu is where you configure all of the actions possible when events are detected.

```
SiteBoss 550 - Actions Definition Menu
A) Hostname/IP Address 1          []
B) Hostname/IP Address 2          []
C) Hostname/IP Address 3          []
D) More Hostnames/IP Addresses    []
E) Email Address 1                []
F) Email Address 2                []
G) Email Address 3                []
H) More Email Addresses           []
I) Phone Number 1                 []
J) Phone Number 2                 []
K) Phone Number 3                 []
L) Phone Number 4                 []
M) Callout Attempts               [5]
N) Callout Delay (seconds)        [60]
O) Action Schedule                [OFF]
P) Reminder Interval (minutes)    [120]
```

Hostname/IP Address *n* sets the hostname or IP address of the device(s) receiving SNMP Traps. The number (1,2,3) corresponds to the “index” number for Traps as discussed in the [Action List](#) section of the Features chapter.

More Hostnames/IP Addresses displays the IP Address Definition Menu where three more hostnames or IP Addresses (index 4,5,6) can be configured.

Email Address *n* sets the Email address of the person(s) receiving Email alerts. The number (1,2,3) corresponds to the “index” number for Email alerts as discussed in the [Action List](#).

More Email Addresses displays the Email Address Definition Menu where three more Email Addresses (index 4,5,6) can be configured.

Phone Number *n* sets the phone number (index 1,2,3,4) to call for each dispatch, malert or modem callout as discussed in the [Action List](#).

Callout Attempts sets the total number of times to attempt dispatch, malert or modem callouts if previous attempts fail. Default setting is 5.

Callout Delay sets the time in seconds (0 - 400) to wait between callout attempts. Default setting is 60 seconds.

Action Schedule displays the Action Schedule Settings Menu where actions can be limited to defined days and times.

Reminder Interval sets the time in minutes (0 – 65535) at which an action is repeated if the sensor (contact closure, temperature, humidity, or voltage) that triggered the alarm is still in the “active” state. When the sensor has been returned to the inactive state, the reminder interval is no longer in effect. Default setting is 120 minutes.

Action Schedule

```
SiteBoss 550 - Action Schedule Settings
A) Action Schedule Enable        [OFF]
B) Begin Time                    [08:00]
C) End Time                      [17:00]
D) Weekdays Only                [ON]
```

Actions Schedule Enable is an ON/OFF toggle to enable the action schedule. Default setting is OFF.

Begin Time/End Time sets the beginning and ending times (24 hour clock) during which alarm actions can be taken. Default settings are 08:00 (Begin Time) and 17:00 (End Time).

Weekdays Only toggles whether actions are only performed Monday thru Friday. Default setting is ON.

General Settings

```
SiteBoss 550 - General Settings
A) Site Name                      [550-555000096]
B) Answer String                  [SiteBoss]
C) Escape Key                     [27]
D) Confirmation Prompt            [ON]
E) Time Stamp Format               [HH:MM]
F) Date Stamp Format               [MM/DD]
G) Space After Date/Time Stamp    [ON]
H) Prompt                         [>]
I) Date/Time Setup
```

Site Name sets the name assigned to this S550. This name is included with alarm messages (Traps, Emails, etc.) and is displayed at the top of the Status screen. The name should be unique for clarity. (Max length 40 chars) Default setting is "550 - <serial number>"

Answer String sets the string that is presented when a user connects to the S550 via Telnet or modem. (Max length 31 chars) Default setting is SiteBoss.

Escape Key is the decimal ASCII character code of the key you must press three times to escape from passthrough or other transparent modes. Default is 27, the <ESC> key.

Confirmation Prompt is an ON/OFF toggle to set whether a confirmation prompt (*Are you sure (y/n)?*) is displayed when the commands **DEFAULT** or **COLDSTART** are issued. If there is no response within 30 seconds, the S550 will cancel the command. Default is ON.

Time Stamp Format toggles through three options for how time stamps are formatted: HH:MM, HH:MM:SS, or BLANK. Default setting is HH:MM.

Date Stamp Format toggles through four options for how date stamps are formatted: MM/DD, MM/DD/YY, MM/DD/YYYY, or BLANK. Default setting is MM/DD.

Space After Date/Time Stamp is an ON/OFF toggle to set whether a space is appended to the end of the Date/Time stamp. Default setting is ON.

Prompt sets the character(s) or settings values displayed as the command line prompt. Refer to the [Customizable Command Prompts](#) section in the Features chapter for more information. Default setting is ">". (Max length 63 chars)


[Date/Time Setup](#) displays the System Date/Time menu where you can manage the clock, daylight savings control, and configure a networked time server.

Date/Time Settings

```
SiteBoss 550 - System Date/Time
A) Current Date                   [12/18/2007]
B) Current Time                   [09:53:39]
C) Adjust for Daylight Savings    [ON]
D) GMT Difference (hours)         [8]
E) GMT Difference Direction       [BEHIND]
F) Enable Time Protocol           [OFF]
G) Time Servers
```


Current Date sets the date. The unit automatically calculates the day of the week to display on the Status screen.

Current Time sets the time (24 hour clock).

 **Note:** The date and time settings are maintained by means of an internal battery backup when power is removed from the S550.

Adjust for Daylight Savings is an ON/OFF toggle that allows automatic daylight savings time updating.

A brief explanation of daylight savings time (effective 2007): On the second Sunday in March, clocks are set ahead one hour at 2:00 a.m. local standard time, which becomes 3:00 a.m. local daylight time. On the first Sunday in November, clocks are set back one hour at 2:00 a.m. local daylight time, which becomes 1:00 a.m. local standard time.

GMT Difference (hours) sets the number of hours the current time zone is offset from GMT. Valid input ranges from 0 to 12. Default setting is 8 hours.

GMT Difference Direction sets whether you are east (AHEAD) or west (BEHIND) of GMT. For example, Pacific time (GMT-8) is behind and Tokyo time (GMT +9) is ahead. Default setting is BEHIND.

Enable Time Protocol toggles between OFF, SIMPLE, and NTP. Default setting is OFF.

SIMPLE - When network time is set to SIMPLE the unit attempts to contact the configured time servers (see Time Servers setting below) periodically, attempting to query each using Simple Network Time Protocol (SNTP), Time, and Daytime protocols, in that order. Once a response is received for any protocol, the unit sets the system clock to the new time, updates the real time hardware clock (RTC), then the network time process dies. The interval for checking network time is hard-coded to 12 hours plus or minus a random several hours.

NTP - When network time is set to Network Time Protocol (NTP), the NTP daemon is kept running at all times. Unlike the SIMPLE setting, with NTP the clock is not immediately set as soon as a time server is contacted. Rather, the NTP daemon utilizes various algorithms to set the time in an accurate and robust manner. Since the NTP daemon updates the system time asynchronously, the current time is stored in the RTC every 30 minutes while it is running. Note that if you change the clock manually, it may be a period of an hour or more before NTP resets it.

Time Servers displays a menu where the hostname or IP address of six time-servers can be configured. (Max length 64 chars) The S550 uses the following servers by default:

- time.nist.gov - 192.43.244.18 - Boulder, CO
- time-b.nist.gov - 129.6.15.29 - Gaithersburg, MD

Event Log Settings

The Event Log is a record of all data events that occur within the S550.

SiteBoss 550 - Event Log Settings

A) List Events File	
B) Clear Events File	
C) Enable Events Log File	[ON]
D) Maximum File Size	[32]
E) Store Data Alarm Records	[OFF]
F) Store Sensor Events	[OFF]
G) Date/Time Stamp Data Alarm Records	[OFF]
H) Prepend Data Alarm Name	[OFF]

List Events File displays the contents of the Events File, if any records exist.

Clear Events File purges the records within the Events File. Records in the Events File are deleted immediately when this option is selected, so make sure you want to do this before selecting.

Enable Events Log File is an ON/OFF toggle to enable Event logging. Default setting is ON.

Maximum File Size sets the maximum number of KB the Event Log can reach before overwriting the oldest records. Available options are 0, 32, 64, 128, 256, 512 and 1024. Default setting is 32.

Store Data Alarm Records is an ON/OFF toggle to enable storing data alarm records. Default setting is OFF.

Store Sensor Events is an ON/OFF toggle to enable storing records generated by environmental sensors. Default setting is OFF.

Date/Time Stamp Data Alarm Records is an ON/OFF toggle to prepend a Date/Time stamp to the beginning of data alarm records. Default setting is ON.

Prepend Data Alarm Name is an ON/OFF toggle to prepend the name of the Data Alarm to the beginning of the data alarm record. This aids in identifying which Data Alarm an alarm record is associated with. Default setting is ON.

Audit Log Settings

The Audit Log is a record of a variety of actions that occur within the S550. Data in this log can be very useful to Asentria Tech Support when troubleshooting problems, or for your own use.

SiteBoss 550 - Audit Log Settings		
A) List Audit Log File		
B) Clear Audit Log File		
C) Enable Audit Log File		[ON]
D) Maximum File Size		[32]
E) Store Reset Events		[ON]
F) Store Command Entry		[ON]
G) Store Relay Activity		[ON]
H) Store Alarm Actions Taken		[ON]
I) Store Password Failures		[ON]
J) Store Logins/Disconnects		[ON]
K) Store Serial Handshaking Alarms		[ON]
L) Store Pass-through Activity		[ON]
M) Store Inactivity Timeouts		[ON]
N) Store Polling Activity		[ON]

List Audit Log File displays the contents of the Audit Log file, if any records exist.

Clear Audit Log File purges the records within the Audit Log file. Records in the Audit Log File are deleted immediately when this option is selected, so make sure you want to do this before selecting.

Enable Audit Log File is an ON/OFF toggle to enable Audit logging. Default setting is ON.

Maximum File Size is the maximum number of KB the event log can reach before overwriting the oldest records. Available options are 0, 32, 64, 128, 256, 512, and 1024. Default setting is 32.

The remaining options are ON/OFF toggles to enable logging of the action described. Default settings for all is ON.

Scripting Settings

Scripting is a S550 feature that is complex enough that it has been given it's own chapter in this User Manual. The initial Scripting Settings menu is displayed below, but a full description of the options along with other information necessary to use the scripting functions can be found in the [Scripting](#) chapter.

```
SiteBoss 550 - Scripting Settings
A) Enable Scripting                [OFF]
B) Clear Pending Records           [0]
C) DTR Override Ports
D) List Allocated Devices
E) List Scripts
F) Manage Script Files
```

Features and How To Use Them

Upgrading the S550

Save the update file (550-2.03.010-std-a71.udf) to a directory on your PC or an FTP server. FTP upgrades can be done in either of two ways: by using the S550's FTP client to get the update file, or sending the update file from another host to the S550's FTP server. Following are the instructions for both methods.

Note: Before upgrading it is always a good idea to make a copy of the Setting Keys file in your S550, in case settings are lost during the upgrade. This usually does not happen, but it's better to be safe than sorry.

S550 as FTP client method:

From the command line type: **xf f get <update filename> <host> <username>**

(note: you can type 'xf' at the command prompt to get usage for this command.)

Here is an actual session:

```
> xf f get 550-2.03.010-std-a71.udf 10.10.5.32 anonymous
Receiving 550-2.03.010-std-a71.udf via FTP
Anonymous's password:
.....
COMPLETE

<and the update starts here>
```

S550 as FTP server method:

- 1) Make an FTP connection to the S550 using a username and password that has MASTER rights.
- 2) Type **hash** at the ftp prompt. (This is optional - it just creates hash marks (###) while the file is transferring so you can see something happening.)
- 3) At the next ftp prompt type: **put drive:\directory\<update filename>**
For example: put C:\upgrades\550-2.03.010-std-a71.udf
- 4) Hash marks will now appear to show you that the file is transferring. When the transfer is complete you will be returned to an ftp prompt.
- 5) Type: **bye** at the ftp prompt. The unit still has to process this file, which takes about 5 minutes, at which time the unit will reboot. When the unit detects the update file and begins processing it. Wait until the unit reboots before proceeding.
- 6) After the S550 reboots, connect to it and either check the top line of the Status screen, or type **ver** at the command line. You should see that the unit is now upgraded to the new version.
- 7) Check your settings to be sure none have been lost. If they have, reload the Setting Keys file.

Setting Keys

Setting Keys (SK) provide a flat file, human readable, means of setting and retrieving settings within the unit. Setting Keys are commonly used to clone settings across multiple units or in automated processes.

Setting Keys is abbreviated when used on the command line as **SK**. Following are commands when working with the Setting Keys File from the command line of the unit.

SK [KEY[=value]] allows for reading or setting a single Setting Key. If the value portion of the command is omitted, the S550 will report back the value stored in that key. If the value is given, it will be stored in the key.

SK GET [X|A [CUSTOM] [filter]] initiates a download of unit settings. This listing can be retrieved either by Xmodem or plain ASCII using the X and A attributes, respectively. If the transfer mode attribute is omitted, the unit will prompt for the download method. The CUSTOM tag may be used to retrieve only the settings that are not set to factory defaults. A filter may be applied to limit the keys output to just the branch specified. For example, to retrieve an ASCII listing of all EventSensor settings, use the command: **SK GET A event.sensor**

SK SET [X|A] puts the unit in bulk Settings Keys upload mode. Any of the settings retrieved by SK GET can be manipulated and uploaded with new values. The unit will process settings in any order or number; not all settings need to be uploaded each session. As with SK GET, both ASCII and Xmodem transfer methods may be used to upload settings to the unit. These transfer methods are indicated by using the X and A attributes, respectively. The S550 monitors for invalid Setting Keys and will notify you after the upload if any invalid data was received.

When using SK SET in ASCII mode, the data uploaded must end with a line consisting of the word "END" followed by a return.

SK HERE allows you to set or get individual keys interactively. Typing just the key name will cause the value to be displayed. Typing the key name plus a new value will set that key. The unit will keep prompting for a new key or key/value pair until you press <Esc> or <Enter>.

SK LOG displays a list of any errors generated during an SK Set.

Setting Keys can also be retrieved and loaded via FTP.

FTP> GET SKALL FILENAME.TXT retrieves all of the Setting Keys for the unit, similar to the **SK GET A** command described above.

FTP> GET SKCUSTOM FILENAME.TXT retrieves any settings that are not set to factory default, similar to the **SK GET A CUSTOM** command described above.

FTP> PUT FILENAME.TXT SKALL and **PUT FILENAME.TXT SKCUSTOM** load the settings in FILENAME.TXT onto the S550.

Upon successful completion of loading the settings FTP will respond with "226 - Transfer complete". If there is a problem in the Setting Keys file then FTP will respond with "226 - Transfer complete; errors in setting key file! Type Get SKLOG to view"

FTP> GET SKLOG retrieves the Setting Keys log as described above.

Telnet/TCP Connections

The S550 provides support for Telnet/TCP connections via two internal Ethernet interfaces. Refer to the [Ethernet Settings](#) menu for information on how to configure these.

All Telnet connections are TCP connections but not all TCP connections are Telnet connections. A Telnet connection is made to the S550 by using the Telnet protocol and by specifying a TCP port address. 'Telnet' refers to a TCP connection made on port address 23, which specifies that characters are supposed to be handled a certain way. The S550 supports Telnet connections and also supports some custom assigned port numbers to facilitate certain connection features.

The following information assumes that you know how to run your computer to establish and use Telnet/TCP connections and only require the specific information relating to the S550 features. Port numbers below include "x" where "x" is the corresponding S550 file or port number. (ie; 2101 refers to the telnet passthrough connection made on serial port 1.)

- **Port Address 200x**: A connection to port 200x is just like a regular Telnet connection to port 23, except it sets the default file for retrieving data or the default port when the [Bypass](#) command is given.
- **Port Address 210x** : A connection to port 210x routes you directly to the device connected to the corresponding serial (I/O) port. A banner message will be displayed indicating you are connected to that I/O port. To disconnect from this access mode press the <ESC> key twice. Refer to the Passthrough section in this chapter for more information.
- **Port Address 220x**: A connection to port 220x is referred to as a Real-Time Socket. These are sockets that are dedicated to exporting data from file "x" in the S550. If there is any data already stored in a particular file, it will first be transferred out of the S550 to the user or machine initiating the connection. After all the data currently in the file is transferred out, any data that is coming into the S550 will be immediately transmitted out and across this connection. Refer to the [Real-Time Socket Settings](#) menu for information on how to configure these.

VLANS

A VLAN (802.1Q Virtual Local Area Network) is used to separate broadcast domains via software instead of via hardware (physical layout of network devices and cabling). Software on network nodes (like the S550) abstracts this into virtual network interfaces, so each interface can have its own virtual interface configuration (static address, subnet mask, router). The unit operates with virtual interfaces the same as it would with real interfaces.

Configuration

Each Ethernet interface can have up to 6 VLANs bound to it. Access configuration items via any of the following:

Menu

Setup -> Network Settings -> Ethernet Settings -> Ethernet x -> VLAN Settings

Web

Networking -> Ethernet Settings -> Ethernet x Settings -> scroll down to VLANx Settings

Keys

```
net.eth[].vlan[].id
net.eth[].vlan[].priority
net.eth[].vlan[].ip
net.eth[].vlan[].mask
net.eth[].vlan[].router
net.eth[].mode
```

VLAN ID

0 to 4094; this is what identifies the VLAN.

VLAN priority

0 to 7; this is the priority assigned to egress frames.

IP, mask, router

Configured like any other interface. This router setting is included in the set of candidate default routers which the unit can use. The unit does not yet support configuration of individual host and network routes. Select the default router with the `net.default.router` setting, if the unit has not already selected an appropriate one for you. Note that the unit does not heed changes to network configuration while you are connected to a command processor via Telnet or SSH. Changes, including population of the candidate default router set, are pending until all network-based command processor sessions have ended.

Network mode

Set this to VLAN to engage the interface in VLAN mode. While the interface operates in VLAN mode, its normally configured settings (IP, mask, router) are still configured but the interface does not use them. The interface heeds those settings only when it's in STATIC mode.

Example

Put the unit on three VLANs bound to the cable attached to the first Ethernet adapter, 10.20.20.0/24, 10.30.30.0/24, and 10.40.40.0/24, with VLAN ids 20, 30, and 40, respectively. The unit will route off its local nets via the 10.30.30.1 router.

Configure:

```
net.eth[1].vlan[1].id=20
net.eth[1].vlan[1].ip=10.20.20.2
net.eth[1].vlan[1].mask=255.255.255.0
net.eth[1].vlan[2].id=30
net.eth[1].vlan[2].ip=10.30.30.2
net.eth[1].vlan[2].mask=255.255.255.0
net.eth[1].vlan[2].router=10.30.30.1
net.eth[1].vlan[3].id=40
net.eth[1].vlan[3].ip=10.40.40.2
net.eth[1].vlan[3].mask=255.255.255.0
net.eth[1].mode=vlan
```

If no other interfaces are active then the unit will select 10.30.30.1 as the default router (gateway); if other routers are configured for other interfaces then you can override this by configuring `net.default.router`.

Secure Shell (SSH) and Secure FTP (SFTP)

This section consists of six topics regarding SSH and SFTP:

- I. [Quick Start: SSH into the unit](#)
- II. [SFTP CDR out of the unit](#)
- III. [Reestablishing authenticity of the SFTP host](#)
- IV. [Configuring authentication](#)
- V. [Configuring a login banner for SSH.](#)
- VI. [Menu changes](#)

Quick Start: SSH into the unit

The S550 supports Secure Shell (SSH) version 2, including Secure FTP (SFTP). SSH version 1 is not supported. Some configuration steps are necessary before the initial SSH connection to the unit. Connect to the unit via a conventional method (serial port, telnet, modem) to make these configuration changes. The changes are:

1. Make a user profile with a username and password (required)
2. Configure network settings (required)
3. Generate the host key (optional)

These are the steps in detail:

1. Make a user profile with a username and password (required). This is done via the Setup->User Profile Settings menu.
2. Configure network settings (required) - By default the unit ships with static IP address 0.0.0.0. Change this to an appropriate static IP address on your network, as well as the default router and subnet mask if necessary.
3. Generate the host key (optional) - By default the S550 requires password authentication and does not require public key authentication. If you are not certain that you fully understand what public key authentication is, call Asentria Technical Support and ask them to explain it to you. The S550 ships with a host key already generated. You may decide to generate the host key yourself so you can be sure you are the only possessor of the host key. To generate the host key yourself, enter **SSHC -HT RSA** to create the 1024-bit rsa host key.

At this point the unit is ready to receive SSH connections. You can do the same tasks you can do on a conventional connection, like unit administration and passthrough, only now it is secured by SSH.

SFTP CDR out of the unit

The S550 uses SFTP to transfer CDR securely. SFTP runs on top of SSH version 2 and so has the same security as SSH. The unit supports password and public key authentication methods for SFTP.

If the SFTP host requires a password then the password entered in the Setup->Network Settings->FTP Settings menu is used. If the SFTP host requires public key authentication then do the following configuration steps:

1. Create a client key on the unit
2. Configure the SFTP server to make it aware that the unit is authorized to connect.
3. Configure SFTP push
4. Establish the authenticity of the SFTP host to the unit

These are the steps in detail:

1. Create a client key on the unit. - Enter **SSHC -T RSA** to create an RSA public/private key pair. The unit will generate the key and then output the key's fingerprint and public part as human-readable mostly base-64 text. The key text will begin with "ssh-" and end with "Asentria_clientkey_<serial number of unit>". You can see the unit's public client key at any time by entering **SSHC**.
2. Configure the SFTP server to make it aware that the unit is authorized to connect. - The SFTP server must know the unit's public client key in order to do public key authentication. This means taking the public client key output by

the unit and configuring it in the SFTP server. For UNIX SSH servers (which typically support SFTP), this is done by appending the unit's public client key to the "authorized_keys" file in the ".ssh" directory of the user account the unit uses to SFTP-push CDR. Check with your System Administrator to determine exactly how to do this with your SFTP server.

3. Configure SFTP push - Go to the Setup->Network Settings->FTP Settings menu. Select option A until it reads "SECURE" and then configure the server address, username, password, etc.

4. Establish the authenticity of the SFTP host to the unit. - At this point the unit does not know whether to trust the configured SFTP host. (It may be a malicious host that is pretending to be your host.) Essentially you must tell the unit that you vouch for the host that is running the SFTP server; assuming you are 100% sure that the host to which the unit connects is really your host. Do this by entering **PUSHTEST**. This command is used to see that the connection between the unit and the SFTP (or FTP) host is working. For SFTP, it is also used to let you vouch for the host. The first time you make the unit connect to the SFTP host with the **PUSHTEST** command, you will see a message like the following:

```
The authenticity of host <your SFTP host> can't be established.
RSA key fingerprint is d4:1a:16:46:8a:36:59:24:22:e5:ec:6f:01:fc:74:78.
Are you sure you want to continue connecting (yes/no)?
```

You may enter **YES** (you vouch for the host) or **NO** (you do not vouch for the host) at this point. To help you vouch, the unit reports the host key fingerprint. If this fingerprint is equal to the fingerprint of the host key that you know really belongs to your host, then you can safely vouch for it.

If you enter **NO** then the unit will not be able to push CDR to the SFTP host because it is un-trusted. If you enter **YES** then the unit can trust the server and the server's host key is stored on the unit. As long as the SFTP host key does not change, future connection attempts from the unit to the SFTP host will be trusted.

If the host key does change and you do not vouch for the SFTP host again to the unit (since the host has a new host key) then the unit will revert to not trusting the host (and not push CDR). If this happens and you enter **PUSHTEST**, the unit will say you have to reestablish the authenticity of the SFTP host (see next section).

Reestablishing authenticity of the SFTP host

If the host key changes, you will see something like the following when you enter **PUSHTEST**:

```
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
@@@@@@@@@@@@@@@@
@  WARNING: REMOTE HOST IDENTIFICATION HAS CHANGED!  @
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
@@@@@@@@@@@@@@@@
IT IS POSSIBLE THAT SOMEONE IS DOING SOMETHING NASTY!
Someone could be eavesdropping on you right now (man-in-the-middle attack)!
It is also possible that the RSA host key has just been changed.
The fingerprint for the RSA key sent by the remote host is
d7:3a:05:e0:70:4d:2c:15:ae:d2:f1:c2:75:d2:af:53.
Please contact your system administrator.
```

The unit will not push to a host that it sees has a different host key than the one you had vouched for. This is because the unit does not know if the host key changed due to the key of the real host actually changing or due to an imposter server coming on line to pretend to be your host (and thus having a different host key).

If you know your host key has not changed then you know the unit is being eavesdropped on. Otherwise, the host key simply changed and you must reestablish the authenticity of the host to the unit. Do this with the following steps:

1. Delete the old host key from the unit by entering **SSHC -DKM <old hostname>**
2. Enter **PUSHTEST** to vouch for the host again

Configuring authentication

By default the unit requires password authentication and does not require public key authentication in SSH. For added security you may decide to require public key authentication when connecting to the unit. Do this with the following steps:

1. Enable public key authentication by entering **SK SEC.SSH.AUTH.PUBKEY=ON**
2. Obtain the public key of the SSH client you intend to use.
3. Make the unit aware that your client is authorized to connect.
 - a. On the unit, enter **SSHC -AO**
 - b. Input the public key of the client. It should be a long line of ASCII text starting with "ssh-".
 - c. Ensure there is a new line after the key (enter LF or CRLF if you're not sure)
 - d. Enter **END** on a line by itself followed by LF or CRLF.

At this point the unit should be able to authenticate your client with public keys. You may decide that public key authentication alone is sufficient, and password authentication is not required. If so, you may disable password authentication by entering:

SK SEC.SSH.AUTH.PASSWORD=OFF

Configuring a login banner for SSH.

The unit can display a standard message when users log in via SSH. Configure this with the following steps:

1. Enter **SSHC -AN**
2. Input your authentication banner as printable ASCII text; multiple lines are allowed.
3. Input **END** on a line by itself followed by LF or CRLF.

Menu changes.

The FTP Settings Menu, FTP Push Enable option has three possible settings:

OFF, REGULAR and SECURE (for SFTP)

Default Router

The Default Router setting allows you to select the default router (gateway) for the S550. This tells the S550 which router to use if a packet is not on any of the LANs defined on the network port. The default router is selected from the routers defined for the Ethernet ports or VLANs.

More information for advanced users:

This setting allows you to select the default router (gateway) for the unit. The unit uses a routing table to determine how to send any outbound IP frame. Each entry in the routing table tells the unit how to send a frame whose destination address matches a rule in the routing table. Routing table entries are examined from most-restrictive to least-restrictive, so the default routing table entry is the last entry in the table since it is the least restrictive. It is the catch-all route: it tells the unit how to send a frame when it doesn't know how else to send it. The only routes on the unit at this time are network interface routes and the default route. Network interface routes tell the unit how to send a frame bound for a machine on one of the unit's local networks (subnets). These routes are automatically configured when you configure the address of a network interface. If an outbound frame is destined for a machine off all local networks then it is sent according to what the default route specifies. The default route specifies the default router to use for these frames.

Each network interface has a router setting which you can configure; this is the machine on that interface to which frames will be sent if they do not route to the local network of that interface. However the unit uses only one of those configured routers at this time. As you configure router settings the unit will choose a default router for you. This is available for you to see (and override) via this `net.default.router` setting. The values you may choose for this setting (i.e., router addresses) must be in the set of routers which you have specified, or the special value, "DSL", which means that the DSL interface peer is the default router.

If you have configured only one router for all of your network interfaces then you don't have to worry about this setting: the unit configures it for you and there is nothing you can override it with. However, like other certain network settings, note that the default router is not engaged until there are no command processor via telnet sessions running. The default router setting is special in that its set of allowed values (the routers for the various network interfaces) are determined at runtime. This combined with the limitation of not engaging the default router during a command processor session via telnet may prevent the unit from automatically configuring the default router for you if you are configuring network settings via telnet. In such cases where you expect the unit to automatically configure the default router for you and you are logged in via telnet command processor, you may have to either manually select the default router or log out of all telnet command processors to correctly configure the default router.

Values

Values are dotted-quads and must be in the set of routers configured with `net.eth.router` and `net.eth.vlan.router`.

Setting Key syntax

`net.default.router`

Static Routes

Static routes are network routes that specify in a more or less permanent way (*static*) that traffic to a certain destination (destination host or destination network) gets *routed* out a certain interface or via a certain gateway. These give you the ability to fine-tune how outbound network traffic leaves the unit for up to eight different routes.

Configuration

The S530 has a set of 8 static route slots. Each slot has an option to enable it, set the destination net, set the gateway, and set the interface.

- **Enable** is ON/OFF, default OFF.
- **Destination Network** is network notation, i.e., w.x.y.z/s, where s is the significant bits. Default is 0.0.0.0/0.
- **Gateway** is the IP address of the gateway. Default setting is 0.0.0.0
- **Interface** is one of the allowed values: ETH1, ETH2, E1V1, E1V2, E1V3, E1V4, E1V5, E1V6, E2V1, E2V2, E2V3, E2V4, E2V5, E2V6, PPPP, WPPP, and NONE. Default is NONE. PPPP is short for PSTN PPP. WPPP is short for Wireless PPP. Currently PPPP and WPPP are the same native interface but in the future they may be different.

To configure a static **host** route you

1. Enable it
2. Specify a destination net with sigbits == 32
3. Specify gateway or interface

To configure a static **network** route you

1. Enable it
2. Specify a destination net with sigbits < 32
3. Specify gateway or interface

You can specify a gateway or interface. If you specify a gateway only then the frame will be IP-addressed to the destination subnet and transmitted to the gateway, and the gateway needs to be either a local Ethernet subnet or the peer of a PPP connection (be it wireless or PSTN). If you specify an interface, regardless of specifying a gateway, then the frame will be transmitted out that interface. If it is an Ethernet interface then the destination address (which matches the destination net of the route) will be arped. If it is a PPP interface then the frame which matches its route will be transmitted to the PPP peer.

>> Note: Specifying that certain traffic goes out a PPP interface does not cause PPP to be raised when that traffic needs to leave the unit. If a PPP interface is down then any static routes that specify a PPP interface are effectively disabled.

>> Note: Currently there is no support for PSTN PPP and Wireless PPP to be functional at the same time. Eventually this will not be the case, but in the meantime the effect is that if you specify a static route with WPPP interface when the PSTN PPP is up instead of the Wireless, then that traffic will go out the PSTN PPP interface.

Setting Keys

- Net.staticroute.enable
- Net.staticroute.destnet
- Net.staticroute.gateway
- Net.staticroute.if

Example

Configure to route traffic to the the host 10.90.90.2 to go out via a special gateway 10.90.80.67.

```
net.staticroute[1].enable=on
net.staticroute[1].destnet=10.90.90.2/32
net.staticroute[1].gateway=10.90.80.67
```

Configure to route traffic to 192.168.1.0/24 (which means a subnet of 255.255.255.0) to go out the wireless interface, whenever wireless is up.

```
net.staticroute[1].enable=on
net.staticroute[1].destnet=192.168.1.0/24
net.staticroute[1].if=WPPP
```

IP Address Restrictions

IP Address Restrictions is the primary defense against unauthorized access via a network or PPP connection. An administrator can restrict access by configuring one or more IP addresses that will be the only ones allowed to access the unit. Restrictions can also be configured to allow or deny access to larger groups of IP addresses using .0 and .255 wildcards. IP Address Restrictions do not replace or override any restrictions set by User Profiles, but they do provide an extra level of protection by causing the unit to ignore all network traffic except from the addresses allowed.

IP Address Restrictions are configured from the Setup/Network Settings/IP Address Restrictions menu in all network-enabled Asentria products. When selected, you will see a submenu similar to the following. Selecting option A) Add Item to Table, presents a list of the different kinds of restrictions you can configure.

```
SiteBoss 550 - IP Address Restrictions
No IP Restrictions Established
A) Add Item to Table

Enter your Selection: a
Enter IP addresses that are allowed access:
0.0.0.0 allows all IP addresses
255.255.255.255 restricts all IP addresses
XXX.XXX.XXX.0 allows all IP addresses in a subnet
XXX.XXX.XXX.255 restricts all IP addresses in subnet

New IP Restriction:
```

From the “New IP Restriction” prompt you can enter up to eight IP addresses that will be allowed access to the unit. The list is exclusive by default, so if you define a single IP address, that one is allowed access while all others are denied.

Wildcards are also available to allow or deny access to larger groups of IP addresses. 0 and 255 serve as wildcards for access and no-access, respectively. For example, an IP restriction of 0.0.0.0 would allow all access to the unit where 255.255.255.255 would allow none. More practically, 192.168.55.0 would only allow traffic from IP addresses beginning with 192.168.55.

Keep in mind that certain outbound network functions in the unit, such as FTP push, Email alerts, and pings, require a response from the receiving device. These devices should not be restricted so the function can be completed successfully.

The Asentria unit evaluates the list of IP restrictions from top to bottom. When it finds an entry that specifically allows or disallows access, it uses that entry and stops looking. For example, examine the following list:

```
SiteBoss 550 - IP Address Restrictions
1. 192.168.100.20
2. 192.168.100.1
3. 0.0.0.0
4. 192.168.99.255
A) Add Item to Table
B) Delete an Item from Table
C) Delete All Items from Table
```

A computer with a 192.168.99 IP would be granted access to the unit despite #4 because #3 is processed first. #3 allows everyone access. If you wanted to allow everyone access except computers on subnet 192.168.99 you should switch number 3 and 4.

Note: IP restrictions do not replace or override password protection; they simply provide an extra means of security by causing the unit to ignore all traffic from disallowed IP addresses.

If no IP restrictions are defined in this menu, all incoming connections are allowed.

IP Routing

Description

When you connect to the S550 via PPP you can make the unit act as a router between you and devices on one of the unit's local networks. This allows you to communicate IP traffic between you and devices you wish to remotely access. IP routing can also route traffic that originates on the remote site's network to you. By *traffic* we mean ICMP, TCP, UDP.

Benefit

IP Routing allows you remote network access (as opposed to remote RS-232 access) to devices at the unit's site.

Configuration

IP Routing is configured with the following settings.

All Products:

- `net.ppprouting.enable`
This setting controls whether the unit routes IP traffic from PPP to any Ethernet interface.
- `net.ethrouting.enable`
This setting controls whether the unit routes IP traffic from the specified routing interface to PPP.
- `net.ethrouting.nat.enable`
This setting controls whether the unit does NAT on routed frames egressing the unit on the PPP interface.
- `sec.user.ppptype`
This is a per-user setting which controls whether the user under which the PPP session was authenticated can actually route frames to one of the unit's local networks. It is for added security.

Multihomed units only (S550):

- `net.eth.nat`
This setting controls whether the unit does NAT on routed frames egressing the unit on this interface.
- `net.routing.if`
This setting controls to which network interface the unit routes PPP traffic.

Example

You want to remotely access the SSH CLI of some piece of equipment at a remote site. SSH rides on TCP so it can be routed and NATted. Install a S550 at the remote site with the following configuration and connect the first Ethernet adapter to the network that has your equipment.

```
// set up ppp user
sec.user[1].name= pppuser
sec.user[1].password= ppppassword
sec.user[1].ppptype= routing

// set up ppp hosting
net.ppphost.enable= on

// set up routing
net.ppprouting.enable= on

// set up nat
net.eth[1].nat= on

// set up routing interface
net.routing.if= ETH1
```

Now connect to the unit via PPP and then connect to your equipment via your SSH client.

SNMP Trap Capture

The S550 can receive and buffer SNMPv1 traps and [SNMPv2c inform-requests \(informs\)](#), collectively referred to here as “notifications”. Each notification can be subjected to data event evaluation, stored in the Event Log, and delivered via normal Event Log delivery.

When SNMP Trap Capture is enabled, the S550 listens on port 162 for notifications; those over 1024 bytes are ignored. The unit responds successfully to informs as soon as they arrive regardless of the content of the inform.

The first task the S550 does upon receiving a notification that is an inform, is to send a response. It then converts the notification to a multiline record (MLR). A multiline record is an ASCII data packet comprised of 1 or more lines. In this application each line is terminated by CRLF. A trap that is converted to an MLR is called a trap MLR; an inform that is converted to an MLR is called an inform MLR. They are generally called notification MLRs when the difference is irrelevant. There are specific format rules imposed to enable easy use of data events.

1. The first line of the trap MLR specifies the most important common attributes of a trap in this format:

```
TRAP AA:BBBBB CCCCCCCC DDDDDDDD FROM EEE.EEE.EEE.EEE ENTERPRISE FFF...
```

where the fields occupied by A - F are:

A. generic trap number (position 6, length 2, padded with 0s) The generic trap number indicates the generic trap type, of which there are 7:

- 0: coldStart
- 1: warmStart
- 2: linkDown
- 3: linkUp
- 4: authenticationFailure
- 5: egpNeighborLoss
- 6: enterpriseSpecific

B. specific trap number (position 8, length 5, padded with 0s)

C. date the trap was received (in MM/DD/YY format, position 15, length 8)

D. time the trap was received (in HH:MM:SS (24-hr) format, position 24, length 8)

E. source IP address (position 38, length 15, each octet is padded with 0s)

F. enterprise OID (position 65, variable length)

2. The first line of the inform MLR specifies the following:

```
INFORMREQUEST CCCCCCCC DDDDDDDD FROM EEE.EEE.EEE.EEE
```

where the fields occupied by C, D, & E are:

C. date the inform was received (in MM/DD/YY format, position 15, length 8)

D. time the inform was received (in HH:MM:SS (24-hr) format, position 24, length 8)

E. source IP address (position 38, length 15, each octet is padded with 0s)

3. Each additional line in the MLR (for both inform MLRs and trap MLRs) is devoted to 1 varBind in the notification.

The format of this varBind line is

```
AAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA = BBB...
```

where the fields occupied by A & B are:

A. varBind OID (position 1, length 40, left-justified, truncated or padded with spaces as necessary)

B. varBind value (position 44, variable length, limited to 115 bytes)

Note: Quote marks are never inserted by the unit in varBind values, even if the value type is OCTET STRING.

4. Every trap MLR and inform MLR has its last line be "END".
5. The entire MLR must conform to the following rules:

- The maximum size of a line is 160 bytes.
- The maximum number of lines allowed in an MLR is 12.
- The maximum total size for an MLR is 1200 bytes.

The unit ignores any varBinds which would cause it to break any of the above rules.

The unit stores notifications in the Event log depending on the Event Log storage settings (Setup -> Event Log Settings -> Event Log menu). If Store Data Alarm Records is enabled (default is disabled), then all notification MLRs are stored in the Event Log. Since notification MLRs are stored in the Event Log, the user can poll them by any means of polling the Event Log (**TYPE EVENTS** command, FTP, or setup menu).

Setting Key

net.trapcap.enable

SNMP Informs

SNMP Inform requires a SMIPv2 MIB. When loaded into an SNMP manager, the Asentria SMIPv2 MIBs require an associated MIB called Asentria-Root. Both are available from the Asentria website (www.asentria.com) or Asentria Technical Support (support@asentria.com)

SNMP Inform support (that is, sending SNMP Informs) was added in S550 version 2.00.150.

Unlike SNMP Traps, which do not require acknowledgement from the receiving node, SNMP Informs do require an acknowledgement, thus ensuring guaranteed delivery.

Configuration

SNMP Informs are configured using the following Setting Keys:

net.snmp.ntfn.attempts

This is the number of attempts of sending a notification (trap/inform) per cycle (that is, the initial attempt + retries). If this is 0 then there is 1 infinite cycle.

net.snmp.ntfn.timeout

This is the number of seconds between 2 attempts to send an SNMP notification in the same cycle.

net.snmp.ntfn.cycles

A cycle is a set of notification attempts delimited by a successful action delivery or snooze period. This setting is the maximum number of cycles to try per notification action, where one notification action corresponds to one "inform" keyword in an action list for an event.

net.snmp.ntfn.snooze

The snooze period measures the time in minutes between two SNMP notification cycles for any one notification action. That is, if you have two events generate informs, each inform will have its own timeouts for retries and cycles, and its own snooze period.

Then set up an event which does an inform action to an SNMP manager or inform receiver. E.g., event.sched[1].actions=inform(10.10.5.10). An Asentria S550 with notification capture enabled can serve as an inform receiver. Remember you can't just send an inform to anything: you must send it to a machine capable of replying to the unit with an inform response. Only when the unit gets the inform response will it consider the inform action a success.

Passthrough

Passthrough (also known as “Bypass”) is a bi-directional communication link for either a modem or Telnet connection through the S550 to a device attached to a serial port. Passthrough is useful for configuring or maintaining devices connected to the S550 without having to be in the same physical location.

Passthrough to a serial port is available on TCP ports 210 n where ‘ n ’ is the number of the serial port.

Passthrough to a serial port is available via modem using the **BYPASS n** command where ‘ n ’ is the number of the serial port.

To terminate a passthrough session, press the Escape Key three times.

Following is a table showing what passthrough sub-features/behaviors are applicable to the S550 and a detailed description of each sub-feature below the table.

Sub-feature	S550
Bypass command	Yes
Adjustable end sequence pause	Yes
End sequence for network passthrough	3 escapes (via login menu) or 1 escape (via bypass command)
End sequence for modem passthrough	1 escape (via bypass command)
Joinable sessions	Yes
Buffered passthrough	No

Bypass command

The command **BYPASS n** , where ‘ n ’ is the number of the serial port, is used on a modem passthrough connection.

Adjustable end sequence pause

This feature means you can control the minimum amount of time between entering escape characters that the unit will register as an authentic escape sequence. That is, you can set this to 1/4 second, meaning that in order to escape passthrough, you must enter the escape sequence with at least 1/4 second between each escape. The point is to make the unit disregard escape sequences that happen from the passthrough data itself, which is assumed to travel across the link without pauses between the escape characters. The sys.pt.endpause setting controls this.

Joinable sessions

Up to 3 passthrough sessions can be joined in that they all connect to the same serial port. Data arriving on the serial port gets passed through to all parties, and data arriving from any one party gets passed through to the connected serial port as well as the other parties.

Buffered passthrough

Buffered passthrough is where upon connecting to a passthrough session, the first thing the unit does is dump all data that has been buffered in that port's database file, instead of connecting to the port right away. Once all data from that file is output then unit connects you to the port. If no data has been buffered (or this feature is turned off) then the unit initially connects you to the port. This option is not available on the S550.

By default the unit provides passthrough access to anyone and can be further defined in the [User Profile Settings](#) menus. Various settings control its behavior, as discussed above with each sub-feature.

Data Events

This section offers a brief tutorial on how to set up a functional data event that will send an SNMP trap when the word "test" is received over a data port. Full details on how to configure data alarm equations are available in the next section, [Configuring Data Alarm Equations](#).

Set Up a Data Event

1. From the command prompt, access the Setup menu. Select "Alarm/Event Definitions", "Data Alarm/Filter Settings", and then "Data Alarm Field Settings". The following menu allows a user to define up to 16 data event fields to be used when scanning for event data. Below is an abbreviated example of this menu:

```
SiteBoss 550 - Data Alarm Field Definition Table
      Start   Length   Line   Type      Name
A) Definition A      0      0      0   [Alpha]
B) Definition B      0      0      0   [Alpha]
...
O) Definition O      0      0      0   [Alpha]
P) Definition P      0      0      0   [Alpha]
```

2. Select field A. The menu in the following example will be displayed.

```
SiteBoss 550 - Data Alarm Field Definition
Data Field: A
A) Start Position           [0]
B) Field Length             [0]
C) Field Name               []
D) Field Line Number        [0]
E) Field Type               [Alpha]
```

3. Select Start Position. When prompted to enter a new value, enter "1" and press <ENTER>.
4. Select Field Length. When prompted to enter a new value, enter "4" and press <ENTER>.
5. Select Field Name and enter "test_field", then press <ENTER>.
6. Press <ENTER> to return to the Field definition Table. If configured properly, the data event field should appear in this menu.
7. Press <ENTER> to return to the Data Alarm/Filter Settings menu. From here, select the Data Alarm Settings menu, Alarm/Filter Page 1, then Alarm/Filter 1. The following menu will be displayed:

```
SiteBoss 550 - Settings For Data Alarm/Filter 1
A) Alarm/Filter Enable      [OFF]
B) Alarm/Filter Mode        [ALARM]
C) Alarm/Filter Name        []
D) Alarm/Filter Equation    []
E) Threshold                [1]
F) Auto-Clear when Threshold Reached [ON]
G) Alarm Counter Clear Interval [12 HOURS]
H) Alarm Counter Reset Time [00:00]
I) Actions                  []
J) Class                    [Info]
K) Data Alarm Trap Number   [503]
L) Clear This Alarm Counter Now
```

8. Press "A" to toggle Alarm/Filter Enable to ON.
9. Alarm/Filter Mode should be set to ALARM. If it is set to FILTER, press "B".
10. Select Alarm/Filter Name and enter "Test Event 1".
11. Select Alarm/Filter Equation and enter `test_field="test"`. This will cause an event to occur any time the word "test" is received.


12. Select Actions and enter "T1" to cause this data event to send a trap to SNMP Manager #1, as configured below in the Hostname/IP Address menu.

Other Setup

1. Return to the Main Setup Menu, select "Action Definitions", select "Hostname/IP Address 1" and enter either the hostname or IP address of the SNMP Manager where the trap will be sent.
2. Press <CTRL> + C to return to the command line.

Testing

Connect to the unit serially on I/O 1 and type the word **test** followed by <ENTER>. This should trigger the above data event, and an SNMP trap should be sent to SNMP Manager #1. If this is not the case, double check the network and data event settings and then call Asentria Technical Support.

 **Note:** There will be a 30 second delay in alarming if the terminal emulator being used does not send a LF with the CR. This may be circumvented by pressing <CTRL + J> to generate a LF.


Configuring Data Alarm Equations

The equation is the heart of any data event. The following are a few examples event equations:

- `alarm_code = "L31"`
- `ext >= "A 600" AND exit_code = "DN"`
- `(alarm_code > "1051" OR exit_code = "10w74x") AND switch = " 001.1.9*.**"`
- `@ = "CRITICAL"`

Here are a few tips to help you create your own data event equations:

- Multiple field references are acceptable, as long as both fields are the same length. For example, `d=c` is a valid equation if the fields that both 'd' and 'c' represent are two characters long
- Variable names are case sensitive
- Equation literals (the data contained within quotation marks) are case sensitive
- If any rule is violated in a equation, an alarm will not be generated, nor will an error be presented

 **Note:** There may be times when two or more fields are necessary to analyze one piece of data. For example, if a time is represented in hh:mm format, some calculations may require two different fields. Other times, wildcards will do the job of masking out non-important characters just fine.

The data alarm equations used in the S550 are standard Boolean-type operators. The following table outlines each of the supported operators and their function.

Operator	Function
>	Greater Than
<	Less Than
>=	Greater Than or Equal to
<=	Less Than or Equal to
! or <>	Not Equal to
=	Equal to
*	Single character wildcard (matches any character or space)
()	Parenthesis used to combine operations
OR	Logical OR
AND	Logical AND
@	Positional wildcard (used in place of a field name to match anywhere within an incoming record)

Data Alarm Macros

Data alarm macros provide a way to define up to 100 equations that can be used in one or more data alarm equations. Each macro consists of an equation and an associated name that can be used to reference the macro in a data alarm equation. They simplify the creating of data alarm events, particularly where more than one event uses the same expression in its equation. Also, since the macro expression is evaluated only once per record, it improves the efficiency of alarm processing.

Data alarm macros can be configured using the setup menu or setting keys:

Menu

Setup -> Alarm/Event Definitions -> Data Alarm/Filter Settings -> Data Alarm Macro

Settings Keys

event.macro[].name
event.macro[].equation

The macro equation is entered the same way as a data alarm equation. A macro equation cannot refer to another macro; in such a case, the expression involved will always evaluate to FALSE. The macro equation can be up to 160 characters in length.

The macro name is the name by which the macro is referenced in any data alarm equation, and can be up to 16 characters in length. Macro names are subject to these restrictions:

- Macro names and data field names are not case sensitive; therefore DLT35 and Dlt35 are equivalent.
- A macro cannot be given the same name as a data field or another macro.
- The following names are reserved and should not be used as macro names or data field names:

°IOx (where x is a number)	°FALSE
°IPRC	°AND
°TRAP	°OR
°FTP	°IS
°TRUE	°ISNOT

Using a macro name or data field name that starts with AND or OR will cause that part of the expression to always evaluate to FALSE.

Macro names and data field names cannot start with \$.

When used in a data alarm equation, macros are always compared to TRUE or FALSE. Any other comparison yields a result of FALSE.

Example

Settings

- event.data[1].enable= ON
- event.data[2].enable= ON
- event.data[1].equation= m1=true
- event.data[2].equation= m1 = true and f2 = "0"
- event.field[1].start= 7
- event.field[2].start= 6
- event.field[1].length= 1
- event.field[2].length= 1
- event.field[1].name= f1
- event.field[2].name= f2
- event.macro[1].name= m1
- event.macro[1].equation= f1="1"

Incoming records

0000001	N	019	00	DN1042	T001034	02/25	09:21	00:00:50	A	5558481677
0000002	N	020	00	DN5280	T001033	02/25	09:22	00:00:08	A	5551377443
0000003	N	021	00	T002014	DN6502	02/25	09:22	00:00:10		
0000004	N	022	00	T007002	DN5700	02/25	09:19	00:02:36		
0000005	E	023	00	T002024	DN1006	02/25	09:22	00:00:58		
0000006	N	024	00	T002042	DN6000	02/25	09:21	00:00:46		
0000007	N	025	00	DN5154	T001035	02/25	09:04	00:17:50	A	5558451000
0000008	N	026	00	DN1192	T001031	02/25	09:22	00:01:10	A	5558406776
0000009	N	027	00	DN1048	T001034	02/25	09:23	00:00:26	A	5556426898
0000010	N	028	00	DN1197	T001020	02/25	09:19	00:04:30	A	5552550948
0000011	N	029	00	DN6063	T001033	02/25	09:23	00:00:16	A	5557458535
0000012	N	030	00	T002019	DN6447	02/25	09:23	00:00:10		

Alarm records

0000001	N	019	00	DN1042	T001034	02/25	09:21	00:00:50	A	5558481677	(DA 1)
0000001	N	019	00	DN1042	T001034	02/25	09:21	00:00:50	A	5558481677	(DA 2)
0000011	N	029	00	DN6063	T001033	02/25	09:23	00:00:16	A	5557458535	(DA 1)

- The first record matches data alarm 1, because macro 'm1' is true. Macro 'm1' is true any time the character in the 7th position is '1'.
- The first record also matches data alarm 2, because macro 'm1' is true and field 'f2' contains a '0' character.
- The eleventh record matches data alarm 1, again because macro 'm1' is true. It does not match data alarm 2 because field 'f2' does not contain a '0' character.

Action List

An action list is a text string that specifies what the unit should do upon an event. It's comprised of a list of keywords and parameters separated by semicolon. Each keyword specifies a certain action and has its own parameter set, which is enclosed in parentheses.

For example, the keyword *trap* has a parameter <address or index>, and has syntax *trap(address or index)* in an action list. This keyword means send a trap to the specified parameter. If the parameter is an address then it uses that address as the trap destination. If the parameter is an index then it uses the address specified in the IP action setting list, indexed by the specified index. (This IP action setting list is *action.ip*, so *trap(1)* means send a trap to the address in setting *action.ip[1]*.)

- *cancel(idname)*
Cancel any running action list identified by *idname*.
- *dispatch(phone# or index)*
Send a Dispatcher alarm via modem; *index* is the phone number configured with *action.call.number*. E.g., *action.call.number[index]*.
- *email(email or index)*
Send an email to the address specified by *email*; *index* is the email address configured with *action.email*
- *group(groupname)*
Identify this action list as part of a group identified by *groupname*; not currently used. In a future version this will be used to cancel or postpone groups of action lists.
- *id(idname)*
Identify this action list by *idname*.
- *malert(phone# or index)*
Send an malert (Asentria Alarm via modem); the parameters are the same as for the dispatch keyword.
- *modem(phone# or index)*
Make the unit dial a phone number and start a login session (to the unit's command processor) with the answering machine. The parameters are the same as for the dispatch keyword.
- *postpone(idname, seconds)*
Postpone an already-running action list identified by *idname* for a duration specified by *seconds*.
- *pause(seconds)*
Pause operation for a duration specified by *seconds*.
- *relay(action, EventSensor, point)*
Put a relay in a certain state specified by *action*.
 - *action*: one of the following words, by case-insensitive exact match or partial unambiguous match: *open*, *close*, *active*, or *inactive*
 - *EventSensor*: the number of the EventSensor that has the specified relay, where it is the same as that referred to by the index in an EventSensor key (e.g., 200 in *event.sensor[200].** for the internal EventSensor) as well as that referred to by the SNMP *esIndex* object.
 - *point*: the number of the relay (1-based) on the specified EventSensor. E.g., this is the same number *x* in *"event.sensor[200].relay[x]."*
- *script(action, name or number)*
Start or stop a script
 - *action* is the case-insensitive exact match of *exec* or *kill*.
 - *name* is the registered name of the script
 - *number* is the number of the registered script
- *talert(ipaddress or index)*
Send a talert (Asentria Alarm via TCP).
 - *ipaddress* is the destination machine;
 - *index* is the IP address configured with *action.ip*. E.g., *action.ip[index]*.
- *trap(ipaddress or index)*
Send an SNMP trap. The parameters are the same as for the talert keyword. In order to send a trap there must be a route for it. Since a trap is an unacknowledgable action, the way the unit knows if a trap is successful is if it was able to leave the unit. In order for a trap to leave the unit there must be an IP route to its host. A trap action without a route to its host is considered a failure. "Without a route" means, for example, that:
 - if the host is meant to be on a local net but cannot be ARPed
 - if the host is meant to be off all local nets but the router cannot be ARPed
 - if the above two conditions exist and PPP cannot be raised as a backup route.

Each action can take a varying amount of time depending on what's going on in the unit. E.g., a trap may take less than a second to send if there is a route for it on a network interface that is already up (like Ethernet). Otherwise, if the unit is configured to bring up PPP in case the trap cannot be sent on an already-up interface, then the trap may take a minute to send while the unit brings up PPP.

The unit starts all actions up to the first pause keyword at the same time. E.g., if you have an action list like *trap(1);email(1);modem(1);pause(60);trap(2)* then the unit will start the first 3 actions, pause for a minute, then start the last action.

Wherever you can configure an event you can configure its actions. Generally this is with the *.actions Setting Key that applies to the event you want to monitor. You can also configure Email actions (in the action list syntax) for a user profile's login challenge destination (e.g., [[sec.user.challenge.telnetsto]). Not all actions are applicable to all events: relay actions can be caused only by sensor events and data events.

Asentria Alarms

Asentria Alarms are a receipt-verified alert system delivered via modem, or TCP on port 4000.

When an Asentria Alarm is initiated, the box dials into the callout number specified by the action. Once connected, it sends a header and waits for a specific response. If the S550 receives a specific response to the header, it delivers alarms in CRC mode; otherwise, alarms are delivered in non-CRC mode. In CRC mode, each Asentria Alarm is transmitted with some extra control characters and a CRC, and the remote host is required to acknowledge each alarm in a certain format.

After all Asentria Alarms have been delivered, the box waits for 20 seconds for any type of keystroke. If a keystroke is detected, the box will present a login menu.

Asentria Alarm Protocol

Initial header

Note: Please see the Control Characters appendix for more information about special characters used within this section.

Upon dialing into the receiver, the S550 will send a message similar to the following:

```
SiteBoss 550
Server Room B
Asentria Alarm Notice ver. 1.00
(CR/LF) (ENQ)
```

The first line of the output is the S550's answer string.

The second line is the S550's unit ID.

The third line indicates the version of Asentria Alarm.

The final line is the (ENQ) control code.

Non-CRC Mode

After sending the initial header, the S550 pauses for 10 seconds to wait for an ACK from the receiver. Non-CRC mode requires the Require Asentria Alarm ACKs setting to be turned off. If the S550 sees no response or the receiver replies with:

```
(ACK) 00 (ACK)
```

then non-CRC mode is assumed and the sender will transmit the alarms. The control characters (SOH), (SOT), and (ETX) are not transmitted in non-CRC mode.

CRC Mode

CRC mode exists to ensure that event notifications are delivered intact. Asentria Alarms delivered in CRC mode have extra control characters and a 16-bit CRC included in each alarm to allow for error detection by the receiver.

Additionally, CRC mode causes the S550 to store and later retry each alarm until a proper acknowledgement is received from the receiver.

If Require Asentria Alarm ACKs is enabled, the S550 will require a positive CRC mode response or it will disconnect and retry the call. To enable CRC, the receiver must respond with the following after the header is received:

```
(ACK) 01 (ACK)
```

Once CRC mode is enabled, each alarm must be acknowledged by a message in the following format:

```
(ACK) XX (ACK)
```

XX represents the alarm ID to acknowledge. The ID can be found in the first line of each record sent by the S550.

Alarm Transmission

After successfully initiating a session, alarms are delivered in the following format:

```
(SOH) ID=XX (SOT)
Date=03/03/08
Time=10:30:02
TargetPort=
TargetName=
AlarmType=Data Alarm
AlarmName=Test Alarm
Threshold=0
Severity=Critical
Text1=text record line
Text2=text record line
(ETX) XX
(CR/LF)
(CR/LF)
```

The alarm ID indicates the index number of each alarm delivered during a call. This number restarts at 1 for each new call.

The severity line represents the Class value defined for this alarm.

Up to twelve lines of Text n may be sent.

XX represents the 16-bit CRC if CRC mode is enabled. If not, this line will contain two spaces.

If additional alarms are queued to send in the same transmission, the above output is repeated, and the ID incremented with each alarm. When non-CRC alarm transmission is selected, alarms are sent with a 5 second delay between each. When all alarms have been transmitted, then S550 sends the following:

```
(EOT)
(CR/LF)
(CR/LF)
```

At this point, the S550 waits 20 seconds for the receiver to send any input, and then hangs up. If any commands are received, a command prompt is established and the connection will remain active.

Action Definition

Asentria Alarm actions are designated by "M" in action definitions. The numbers correspond to callout numbers.

Example: M1 -or- M123

EventSensor™ Configuration Setup

The S550 can be ordered with any of the following different internal I/O devices or can be connected to a number of external EventSensor devices as described in this section. The setup menus are the same regardless of whether the device is internal or external to the S550.

Input

[Contact closure](#)
[Temperature](#)
[Humidity](#)
[Voltage](#)

Output

[Relays](#)

```
EventSensor ID: 03020000
Name: unnamed
Contact Closure States:
 01 unnamed          Open
 02 unnamed          Open
 03 unnamed          Open
 04 unnamed          Open
 05 unnamed          Open
 06 unnamed          Open
 07 unnamed          Open
 08 unnamed          Open
```

Above is a representative Internal Events Menu showing an ES-1 EventSensor that features 8 contact closures. Descriptions of temperature, humidity, voltage and relays will follow.

[Contact Closure *n*](#) displays the menu for configuring each of the contact closure points.

Contact Closure Setup

```
SiteBoss 550 - Internal Contact Closure Event 1
A) Sensor Name                [unnamed]
B) Contact Closure Enabled    [OFF]
C) Event State                 [OPEN]
D) Threshold                   [2]
E) Event State Actions        []
F) Return to Normal Actions    []
G) Event State Class           [Info]
H) Return to Normal Class      [Info]
I) Event Trap Number           [110]
J) Return to Normal Trap Number [110]
K) Active Alarm Alias          []
L) Inactive Alarm Alias        []
```

Contact closures (CC) sense the state of a circuit. A weak voltage is applied to the source pin and if pulled to ground by a connection on the circuit, the sensor reports a "closed" state. If it remains high, the sensor reports an "open" state. All of the CCs share a common ground. The contact closures may be configured to alarm in either the open or closed state, depending on the needs of the attached devices.

Sensor Name is an alphanumeric field that allows you to name this contact closure. (Max length 16 chars)

Contact Closure Enabled toggles ON/OFF to enable this contact closure. Default setting is OFF.

Event State is an OPEN/CLOSED toggle that determines whether an event will be triggered when the contact closure circuit is opened or closed. The default state is OPEN.

Threshold is the number of seconds (0-255) the sensor must remain in the event state before an actual event occurs. Default threshold is 2.

Event State/Return to Normal Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Event State/Return to Normal Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Event/Return to Normal Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for Contact Closure Events is 110, but any number in the alternate range of 1000 – 1199 can be used.

Active Alarm Alias is a special sensor name used when reporting active events for this sensor.

Inactive Alarm Alias is the same as Active Alarm Alias, but used with Return to Normal events.

Temperature Sensor Setup

```
SiteBoss 550 - Internal Temperature Event
A) Temperature Sensor Enabled          [OFF]
B) Sensor Values Represented in        [FAHRENHEIT]
C) Temperature Deadband                 [3]
D) Very High Event Settings             [100] []          [120] [Info]
E) High Event Settings                  [80]  []          [120] [Info]
F) Return to Normal Settings            [-]   []          [120] [Info]
G) Low Event Settings                   [50]  []          [120] [Info]
H) Very Low Event Settings              [30]  []          [120] [Info]
```

Temperature Sensor Enabled toggles ON/OFF to enable the temperature sensor. Default setting is OFF.

Sensor Values Represented In toggles either FAHRENHEIT or CELSIUS for the desired temperature scale.

Temperature Deadband is the range, in degrees, on either side of a temperature setting that prevents the alarm from repeatedly going in and out of the "alarm state" as the actual temperature fluctuates above and below the temperature setting.

[Very High/High/Low/Very Low Event Settings](#) display a menu where the temperature at each level can be configured to alarm along with the action(s) to occur, trap number, and class. In the case of Very High or High levels, the alarm will occur as the temperature rises above the setting. In the case of Low or Very Low, the alarm will occur as the temperature drops below the setting.

[Return to Normal Settings](#) displays a menu where the actions to occur when the temperature returns to normal (drops below the High/Very High settings, or rises above the Low/Very Low settings) can be configured.

Very High/High/Low/Very Low Event Settings Setup

```
SiteBoss 550 - Internal Temperature Event Settings
A) Very High Event Temperature          [100]
B) Very High Event Actions               []
C) Very High Event Trap Number          [120]
D) Very High Event Class                 [Info]
```

The menu for setting Very High Temperature settings is shown. Menus for High/Low/Very Low are identical.

Very High Event Temperature sets the temperature at which the Very High Event Actions will be triggered.

Very High Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Very High Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for Temperature Events is 120, but any number in the alternate range of 1000 – 1199 can be used.

Very High Event Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Return to Normal Settings Setup

```
SiteBoss 550 - Internal Temperature Event Settings
A) Return to Normal Event Actions          [ ]
B) Return to Normal Event Trap Number      [120]
C) Return to Normal Class                  [Info]
```

Return to Normal Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Return to Normal Event Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for Temperature Events is 120, but any number in the alternate range of 1000 – 1199 can be used.

Return to Normal Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Humidity Sensor Setup

```
SiteBoss 550 - Internal Humidity Event
A) Humidity Sensor Enabled                [OFF]
B) Humidity Deadband                      [3]
C) Very High Event Settings                [90] [ ] [130] [Info]
D) High Event Settings                    [80] [ ] [130] [Info]
E) Return to Normal Settings               [-] [ ] [130] [Info]
F) Low Event Settings                     [20] [ ] [130] [Info]
G) Very Low Event Settings                 [10] [ ] [130] [Info]
```

Humidity Sensor Enabled toggles ON/OFF to enable the humidity sensor. Default setting is OFF.

Humidity Deadband is the range on either side of a humidity setting that prevents the alarm from repeatedly going in and out off the "alarm state" as the actual humidity fluctuates above and below the humidity setting.

[Very High/High/Low/Very Low Event Settings](#) display a menu where the humidity at each level can be configured to alarm along with the action(s) to occur, trap number, and class. In the case of Very High or High levels, the alarm will occur as the humidity rises above the setting. In the case of Low or Very Low, the alarm will occur as the humidity drops below the setting.

[Return to Normal Settings](#) displays a menu where the actions to occur when the humidity returns to normal (drops below the High/Very High settings, or rises above the Low/Very Low settings) can be configured.

Very High/High/Low/Very Low Event Settings Setup

```
SiteBoss 550 - Internal Humidity Event Settings
A) High Event Humidity [80]
B) High Event Actions []
C) High Event Trap Number [130]
D) High Event Class [Info]
```

The menu for setting High Humidity settings is shown. Menus for Very High/Low/Very Low are identical.

High Event Humidity sets the humidity at which the High Event Actions will be triggered.

High Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

High Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for Humidity Events is 130, but any number in the alternate range of 1000 – 1199 can be used.

High Event Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Return to Normal Settings Setup

```
SiteBoss 550 - Internal Humidity Event Settings
A) Return to Normal Event Actions []
B) Return to Normal Event Trap Number [130]
C) Return to Normal Event Class [Info]
```

Return to Normal Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Return to Normal Event Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for Humidity Events is 130, but any number in the alternate range of 1000 – 1199 can be used.

Return to Normal Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Analog Voltage Sensor Setup

```
SiteBoss 550 Internal Events Menu
A) Device Name []
B) Analog Input 1
C) Analog Input 2
D) Analog Input 3
E) Analog Input 4
F) Analog Input 5
G) Analog Input 6
H) Analog Input 7
I) Analog Input 8
J) Clear Settings for This EventSensor
```

The analog voltage sensors provide individual voltage sensing. These sensors can be used in various applications, from monitoring a power supply to verifying RS232 voltage levels.

Device Name is the option name given to the sensor.

[Analog Input *n*](#) displays a menu where each analog voltage sensor can be configured.

Clear Settings for This EventSensor when selected will immediately clear all of the configured settings for this sensor and remove it from the Sensor Events menu (except for Internal Sensors). Return to the Sensor Events menu to assign it a new slot, if desired, and reconfigure it.

Analog Input *n*

```
SiteBoss 550 Internal Analog Input Event 1
A) Analog Input Enabled           [OFF]
B) Input Polarity                 [POSITIVE]
C) Deadband                      [30]
D) Very High Event Settings       [600]      []      [140]  [Info]
E) High Event Settings           [600]      []      [140]  [Info]
F) Return to Normal Settings     [-]       []      [140]  [Info]
G) Low Event Settings            [0]       []      [140]  [Info]
H) Very Low Event Settings       [0]       []      [140]  [Info]
I) Unit Conversion Settings      [Volts]
```

Analog Input Enabled toggles ON/OFF to enable this analog sensor. Default setting is OFF.

Input Polarity indicates to the unit whether the input polarity will be positive or negative.

Deadband is the range on either side of a voltage setting that prevents the alarm from repeatedly going in and out off the "alarm state" as the actual voltage fluctuates above and below the voltage setting.

[Very High/High/Low/Very Low Event Settings](#) displays a menu where the voltage at each level can be configured to alarm along with the action(s) to occur, trap number, and class. In the case of Very High or High levels, the alarm will occur as the humidity rises above the setting. In the case of Low or Very Low, the alarm will occur as the humidity drops below the setting.

[Return to Normal Settings](#) displays a menu where the optional action definition for alarms as they return to a normal state can be configured.

[Unit Conversion Settings](#) displays a menu where "real world" values can be configured

Very High/High/Low/Very Low Analog Input Event Settings

```
SiteBoss 550 Internal Analog Input Event Settings
A) Very High Event Value          [600]
B) Very High Event Actions        []
C) Very High Event Trap Number    [140]
D) Very High Event Class          [Info]
```

The menu for setting Very High Event Value settings is shown. Menus for High/Low/Very Low are identical.

Very High Event Value sets the voltage (in tenths) at which the Very High Event Actions will be triggered.

Very High Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information.

Very High Event Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for Analog Events is 140, but any number in the alternate range of 1000 – 1199 can be used.

Very High Event Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Return to Normal Settings

```
SiteBoss 550 Internal Analog Input Event Settings
A) Return to Normal Event Actions          []
B) Return to Normal Event Trap Number      [140]
C) Return to Normal Event Class            [Info]
```

Return to Normal Event Actions displays the Actions List, a menu where the action string for the event is configured. This field will be empty [] if no actions have been configured, and will show [*SET*] if one or more actions have been configured. Refer to [Action List](#) in the Features chapter for more information..

Return to Normal Event Trap Number sets the trap number which can be useful when using SNMP trap managers that employ a trap numbering system to help identify incoming traps. The default trap number for analog events is 140, but any number in the alternate range of 1000 – 1199 can be used.

Return to Normal Event Class sets the class for the alarm. When this option is selected, a list of the classes previously defined in the [Class Table](#) is displayed, from which you can select one to be assigned to this data alarm.

Unit Conversion Settings

```
SiteBoss 550 Analog Input Event Unit Conversion
A) Unit Name                               [Volts]
B) Low Voltage Amount (tenths)             [0]
C) Low Unit Amount (tenths)               [0]
D) Low Unit Sign                           [POSITIVE]
E) High Voltage Amount (tenths)           [600]
F) High Unit Amount (tenths)              [600]
G) High Unit Sign                          [POSITIVE]
```

Relay Output Setup

```
SiteBoss 550 - Internal Relay Event Settings
A) Device Name                             []
B) Relay 1                                 []
C) Relay 2                                 []
D) Relay 3                                 []
E) Relay 4                                 []
F) Relay 5                                 []
G) Relay 6                                 []
H) Relay 7                                 []
I) Relay 8                                 []
J) Clear Settings for This EventSensor
```

Internal relay outputs provide electrical output that can open or close an external circuit. Typically this is used with devices that would not otherwise be able to interface with a host product, like audio alarms, LEDs, custom circuitry, and an almost limitless number of other applications.

Device Name is the option name given to the relay module.

[Relay *n*](#) displays a menu where each relay output can be configured.

Clear Settings for This EventSensor when selected will immediately clear all of the configured settings for this relay and remove it from the Sensor Events menu (except for Internal Sensors). Return to the Sensor Events menu to assign it a new slot, if desired, and reconfigure it.

Relay *n*

```

SiteBoss 550 - Internal Relay Event 1
A) Relay Name                               []
B) Relay Active State                       [CLOSED]

```

Relay Name is a text-entry field that allows you to name this relay.

Relay Active State toggles CLOSED/OPEN to set whether the relay will close or open when activated. Default setting is CLOSED.

Relays as Alarm Action

Relays can be used to open or close part of a circuit of your design or part of another product. You can use the S550 internal relays to control these devices. Relays can be toggled based on sensor readings, data events, or even remotely by SNMP.

⚠ Caution: Do not exceed maximum ratings for relays. S550 relays are only designed to switch relatively low voltages and amps, and are not intended to switch AC powered devices. Only a certified electrician should work with and connect AC Voltage to the S550. Improper use outside the guidelines of this manual could cause injury or death.

Max switched voltage: 60V

Max switched current: 1A

Max switched power: 30W

Remember Ohm's law: $W = V \times A$ (watts = volts x amps)

$30W = 1A \times 30V$

$30W = .5A \times 60V$

⚠ Note: Be aware of the inrush (startup) current of the device you are connecting to the relays. A device drawing 1A while powered up can draw many times that upon power up. This is especially true with capacitive or inductive circuits.

Action Definition

Relay action definitions are somewhat more complicated than other alarm actions in that they must declare the action to perform, which sensor the relay is on, and which relay on that sensor to switch.

Relay actions are declared with the following syntax: `Raxxyy`

a: The action to perform. Options are C (close), O (open), A (active), I (inactive). Active and Inactive states are determined by the relay's configuration.

xx: The EventSensor slot the relay is on. This value is a two-digit number starting with 01, corresponding to the slot (Number) the EventSensors are declared in the setup menu.

yy: Two-digit indicator of which relay to toggle.

Example: RC0107 -or- RA0103RI0104

⚠ Note: Unlike other action definitions, each relay definition must start with an R. Where other sensors may be defined as T23 (for SNMP trap managers 2 and 3), multiple relay actions must be defined in the following manner: RC0401RO0402.

Customizable Command Prompts

This feature allows the prompt in the command processor to be customized, and includes the ability to embed one or more settings values in the prompt. A customized command prompt can help simplify administration of units, particularly where multiple units are involved.

The command prompt setting is available in the General Settings menu section, and via the Setting Key 'sys.prompt'. The setting can contain up to 64 characters, but the prompt itself is limited to 30 characters; any additional characters are truncated.

In addition to specifying plain text to be included in the command prompt, setting values can be embedded using a special syntax: `$(setting_key_name)`. If this construct is used, the value of the specified setting key replaces the construct. If the setting key is not accessible for any reason (invalid key, insufficient user access level, etc), "ERROR" is displayed instead.

Note: S550 only supports the 'sys.sitename' setting key; all others return "ERROR".
To make the system prompt blank, set 'sys.prompt' to a null value (i.e. "sk sys.prompt = ").

Examples:

Set prompt to be ">"

Via Setup menu: Enter new prompt: >
Via Setting Key: sk sys.prompt = >

Set prompt to be "Site Name"

Via Setup menu: Enter new prompt: SiteBoss (or whatever the site name is)
Via Setting Key: sk sys.prompt = "\$(sys.sitename) "

Set prompt to be "System Date and Time>"

Via Setup menu: The date and time entered via the Prompt option do not
 change as the actual date and time progress. What you enter
 here will always be displayed as the prompt, until you change
 it. If you want the date/time prompt to change with the
 system clock, then change it via the Setting Key entry
 describe below.
Via Setting Key: sk sys.prompt = \$(sys.clock.date) \$(sys.clock.time)>

Scripting

Scripting provides the ability to easily customize the operation of an Asentria device. Scripts are written in the Lua scripting language, with access to Asentria-specific functionality via a rich set of library functions. Scripts can read or change any setting on the unit, and can also create custom settings that can be accessed via Setting Keys. Scripting capabilities open up all sorts of possibilities that would previously require custom factory programming.

This chapter covers the configuration and management of scripts in the Asentria S550, and assumes a level of scripting knowledge that may not be applicable to all S550 users who wish to use scripting. For a basic primer in scripting in the S550, titled "Scripting 101", please contact Asentria Tech Support to have this document emailed to you.

Configuration

General - the steps for using a script are:

- Write the script code in a text editor.
- Transfer the script to the unit.
- Configure the script (can be done any time before running the script).
- Invoke the script (if not scheduled to start automatically).
- The details of these steps are given in later sections.

Requirements and Limitations

Scripts can be created in any text editor as long as they are saved in pure text format. Both DOS and Unix end-of lines are supported. A maximum of 20 scripts can be used on the unit. This includes both scripts that are loaded and scripts that are running.

Running Scripts

Before a script can be run, it must be transferred to the unit and then configured. Simply putting the script file on the unit will not allow it to be run.

Getting the Script Onto the Unit

The **SCRIPT GET** command can be used to transfer a script to the unit via XMODEM, YMODEM, ZMODEM, or TFTP. There is also a setup menu item for this. A simple script could be created directly on the unit using the **SCRIPT EDIT** command or the equivalent setup menu item.

Script Configuration

A script must be configured to tell the unit when the script should run, and provide any parameters required by the script. Scripts are configured via the settings described in a following section.

Script Management

In addition to scripting settings, scripts are managed via a group of commands that are available in any command processor. Here is a list of the commands with a brief description:

SCRIPT [HELP]	Display list of script commands.
SCRIPT LIST	Display a list of configured scripts.
SCRIPT START	<script> [<args>...] Start a script.
SCRIPT STATUS	<script> Display detailed status of a script.
SCRIPT STOP	<script> Stop a running script.
SCRIPT RECORDS [CLEAR]	Show/clear pending script records.
SCRIPT DEVICES	Show script device allocations.
SCRIPT GET/PUT	<file> [<args>...] Transfer script file to/from the unit.
SCRIPT DELETE	<file> Delete a script file.
SCRIPT EDIT	<file> Edit a script file (using VI editor).
SCRIPT DIR	List script file directory.
SCRIPT SHOW	<file> Display script file.
SCRIPT TEST	<script> Enter interactive script interpreter.

The following sections describe the above commands in detail.

HELP - Display Help Information

Displays the command information shown above. The command list is also displayed if an invalid command is entered.

Usage

SCRIPT or SCRIPT HELP

LIST - Display List of Configured Scripts

Scripts that are present on the box but not configured are not shown in this list.

Usage

SCRIPT LIST

Displays a list of configured scripts and their current status like this:

```
Scripts Status - All Scripts
Name      State      Schedule      Arguments
=====
Script 1   Not loaded  Always       argument 1
Script 2   Not loaded  On startup, at 14:30  argument 2
```

START - Start a Script Manually

Starts a script using the specified arguments. If no arguments are specified, then the arguments associated with the script via the configuration settings are used. Attempting to start a script that is already running produces an error message, with no ill effects.

Usage

SCRIPT START <scriptname> [<arguments>...]

STATUS - Display Detailed Status of a Script

Displays detailed status of a script, including its current state, schedule, configured arguments, and information about the last time the script ran. The display looks like this:

```
SITEBOSS - Script 1 Status

Current state: Stopped
Name: Hello World
File Name: hello.lua
Schedule: Manual
Arguments: Argument 1
Open devices:
Last run time: 10/24/07 09:38:01
Last stop time: 10/24/07 09:38:32
Last exit code: 0
```

Usage

SCRIPT STATUS <scriptname>

STOP - Stop a Running Script

Causes a running script to stop. The script may not stop right away, depending on how often it checks its messages, and how long it takes to perform any shutdown tasks. If a script is in some loop where it doesn't handle the shutdown request or is otherwise crashed, it will not stop for about 20 seconds until the system shuts it down.

Usage

SCRIPT STOP <scriptname>

RECORDS - Display/Clear Pending Script Records

Displays the number of records in the special DB files dedicated to scripts, AUX1, AUX2, and AUX3. This number is the aggregate of the records in all three files. The CLEAR option deletes the records in all three files at once.

Usage

SCRIPT RECORDS [CLEAR]

DEVICES - Display Device Allocations

Displays a list of IO devices that are currently allocated to scripts. For example, if a script reserves IO1 for i/o activity, it will appear in this list.

Usage

SCRIPT DEVICES

GET/PUT - Transfer Script File

Transfers a script file to or from the unit. Type the command without any arguments for usage information.

Usage

SCRIPT action method <script file name> [host]

Available actions: GET, PUT

Available methods: X[MODEM], Y[MODEM], Z[MODEM], T[FTP]

Script file name is required (including .lua extension)

Host is required for tftp

Script file name is case-sensitive, other items are not.

DELETE - Delete a Script File

Deletes a script file, which must be specified with the .lua extension.

Usage

SCRIPT DELETE <script file name>

EDIT - Edit a Script File

Opens a script file for editing in the VI text editor. If the script file does not exist, a new one is created. The script file name specified must have the .lua extension.

Usage

SCRIPT EDIT <script file name>

DIR - Display Script File Directory

Displays a list of the script files on the unit.

Usage

SCRIPT DIR

SHOW - Display Script File

Displays the contents of a script file. The script file name must be specified with the .lua extension.

Usage

SCRIPT SHOW <script file name>

TEST - Test a Script in Interactive Mode

Opens the script in the interactive OmniLua interpreter.

Usage

SCRIPT TEST <script name>

Script Settings

There is a group of standard settings that control various aspects of scripting. These settings are available in the setup menu as shown here (using S550 as example):

```
SiteBoss 550 - Main Setup Menu
A) Network Settings
...
J) Scripting Settings

Enter your Selection: j

SiteBoss 550 - Scripting Settings
A) Enable Scripting [OFF]
B) Clear Pending Records [0]
C) DTR Override Ports
D) List Allocated Devices
E) List Scripts
F) Manage Script Files
```

The individual settings are detailed in the following sections.

Enable Scripting is an ON/OFF toggle that controls whether scripts are allowed to run on the unit at all. If scripting is disabled, then scripts cannot be started either automatically or manually, and other scripting functionality such as record collection and DTR override will not happen regardless of the related settings. If scripting is disabled while scripts are running, they will be issued the STOP command which could take up to 20 seconds to complete. If re-enabled, scripting will not function until after the previous scripting session is completely shut down (i.e. all scripts are stopped).

Clear Pending Records displays the number of script records pending, and when selected will clear them, setting the counter back to 0.

DTR Override Ports displays a menu that toggles ON/OFF to specify IO ports where DTR handling will be under script control. Normally the state of the DTR output pin on the IO ports is kept high. On these ports, after a power-cycle or reset, DTR will stay low until a script changes it to the high state.

List Allocated Devices displays a list of I/O devices that are currently allocated to a running script.

[List Scripts](#) displays the menu that lists all of the 20 script entries, including the name, current state, and configured arguments. Selecting a script opens up a submenu with detailed settings and status for that script.

[Manage Script Files](#) displays the menu that allows the user to manage script files.

Script List

```
SiteBoss 550 - Script 1 Settings
A) Enable [OFF]
B) Name []
C) File Name []
D) Run Always [OFF]
E) Run At Startup [OFF]
F) Run At Scheduled Time [OFF]
G) Repeat Interval (minutes) [0]
H) Arguments []
I) Start Script Now
J) Stop Script Now
K) Detailed Status [Disabled]
```

Enable is an ON/OFF toggle that enables/disables the script. If disabled, the script will not run on schedule, and cannot be run manually. Default setting is OFF.

Name sets the name of script. This is the name that is used when referring to the script, and should not be confused with the name of the script file associated with the script.

File Name sets the name of the script file associated with this script. The same script file can be used with any number of scripts.

Run Always is an ON/OFF toggle where if enabled, the script starts after the unit starts up, and is restarted automatically if it stops for any reason. Default setting is OFF.

Run At Startup is an ON/OFF toggle where if enabled, the script starts after the unit starts up. If it stops for any reason, it is not restarted unless the unit itself is restarted. Default setting is OFF.

Run At Scheduled Time is an ON/OFF toggle where if enabled, the script is run at the specified time each day. Default setting is OFF.

Repeat Interval sets the time in minutes of how often the script is repeated. If a non-zero value is entered, the script is run at the specified interval, measured from the last time the script was started on a schedule. Default setting is 0.

Arguments sets the specified arguments that are passed to the script when it is invoked on a schedule, manually from the setup menu, or via the **SCRIPT START** command with no arguments specified. Note: Arguments do not work when running scripts interactively.

Start Script Now when selected immediately starts the script using the configured arguments. This item has no effect if the script is already running.

Stop Script Now when selected immediately stops the script if it is running. This may take up to 30 seconds before it actually stops the script. If Run Always is set then the script will restart immediately after ending.

Detailed Status displays detailed information about the script (example shown below).

```
SiteBoss 550 - Script 1 Status

Current state: Disabled
Name: Goodbye World
File Name: goodbye.lua
Schedule: Manual
Arguments: argument 2
Open devices:
Last start time: <never>

Press a key to continue...
```

Manage Script Files

```
SiteBoss 550 - Manage Script Files
A) List Script Files
B) View Script File
C) Edit Script File
D) Delete Script File
E) Download Script File to Unit
F) Upload Script File From Unit
```

List Script Files displays a list of all script files contained on the unit. Equivalent to the **SCRIPT DIR** command.

View Script File displays the contents of the selected script file. Equivalent to the **SCRIPT SHOW** command.

Edit Script File bring up the selected script file, or a new blank one, in the VI text editor. Equivalent to the **SCRIPT EDIT** command.

Delete Script File deletes the selected script file. Equivalent to the [SCRIPT DELETE](#) command.

Download Script File to Unit transfers a script file to the unit. Equivalent to the [SCRIPT GET](#) command.

Upload Script File From Unit transfers a script file from the unit. Equivalent to the [SCRIPT PUT](#) command.

Script Programming Guide

Scripts are written using the Lua programming language. In addition to built-in Lua constructs and the standard Lua libraries, the 'omni' library provides an interface to Asentria-specific functionality.

A complete list of Asentria-specific functions can be found in [OmniLua Function List](#). Additional OmniLua scripting information can be found in the [Scripting FAQ](#).

Scripting FAQ

1. [How do I post records to a database file using a script?](#)
2. [How do I retrieve or change a setting?](#)
3. [How do I create a custom setting?](#)
4. [Which functions should a well-behaved script contain?](#)
5. [How do I save frequently-changing data so it survives a power cycle?](#)
6. [How can I generate an event?](#)

How do I post records to a database file using a script?

In order to post a record to the database, the script creates a table that defines the records, then passes it to the [a_lib.DBPostRecord\(\)](#) function.

How do I retrieve or change a setting?

Settings are accessed from a script using their corresponding Setting Key, via the [a_lib.AccessSetting\(\)](#) function. This function returns the value of the setting in text format. Simply pass the name of the Setting Key by itself to read the value. To modify the value, append "= <value>" to the Setting Key, where <value> is the desired value for the setting.

How do I create a custom setting?

Custom settings are not supported at this time. However, if you require a custom setting for a script, you can use an existing setting of the same type, and use it for your script instead. This works as long as the normal use of the setting will not affect the operation of the unit in an undesirable manner.

For example, let's say you need a couple of settings to store a username and password for your script to log onto some external server. You could use the username and password settings from an unused user profile (sec.user[x].name, sec.user[x].password); if you leave the profile disabled, then using those settings for your script will have no effect on the operation of the unit. Those are a convenient example, but you could use any setting that is used to hold a text value that's long enough.

Which functions should a well-behaved script contain?

Any script that might run for more than a few seconds should watch for a shutdown message from the system. This is done using the [a_lib.CheckMessages\(\)](#) function. The purpose of this function is to allow communication between scripts, and to allow a script to watch for system messages.

When the script receives the Terminate message (Message ID 13808) it should stop whatever it is doing and shut down gracefully, using the [a_lib.Exit\(\)](#) function. If a script does not check for and respond to the Terminate message, it will be shut down by the system about 20 seconds after the message is initially sent.

If a script uses a device, such as an IO port, for more than a couple of seconds, it should likewise listen for the Yield Device message (Message ID 13819). This way, if a passthrough session is attempted to that port, the script could potentially close the device so the passthrough session can use it.

How do I save frequently changing data so it survives a power cycle?

Using settings or even a temporary file to save frequently-changing non-volatile data is not a good idea, as it could result in premature failure of the flash memory.

You can use the [a_lib.DBDeleteAndPost\(\)](#) function to save up to 500 characters of text (or any other data that can be stored in a Lua string). This stores the data in a special area of the database, which has provisions for being maintained regardless of power loss. The data can be retrieved using the normal methods (i.e. [a_lib.DBGetRecord\(\)](#), where the file is specified as AUX1 or whatever). Note: DIR ALL displays a directory of all records in the unit in all files.

How can I generate an event?

A script can generate an event using the function [a_lib.PostEvent\(\)](#). This function allows the script to specify event message text, actions, class, and trap number (in case one of the specified actions is a trap). The actions are not specified directly; rather, they are specified by passing the Setting Key of any action setting that specifies the desired group of actions. It doesn't matter which action setting is used, as long as its setting reflects the desired action

OmniLua Function List**IO Functions**

[a_lib.CloseDevice](#)
[a_lib.Flush](#)
[a_lib.GetCharacter](#)
[a_lib.GetLine](#)
[a_lib.OpenDevice](#)
[a_lib.SendString](#)
[a_lib.SetDTR](#)
[a_lib.TCPClose](#)
[a_lib.TCPConnect](#)
[a_lib.WaitForString](#)

Database Functions

[a_lib.DBDeleteAndPost](#)
[a_lib.DBDeleteRecords](#)
[a_lib.DBGetRecord](#)
[a_lib.DBGetRecordCount](#)
[a_lib.DBLockFile](#)
[a_lib.DBUnlockFile](#)
[a_lib.DBPostRecord](#)

Miscellaneous Functions

[a_lib.AccessSetting](#)
[a_lib.CheckMessages](#)
[a_lib.Decrypt](#)
[a_lib.Encrypt](#)
[a_lib.Exit](#)
[a_lib.HashFinalize](#)
[a_lib.HashInit](#)
[a_lib.HashUpdate](#)
[a_lib.InitEncryption](#)
[a_lib.PostAudit](#)
[a_lib.PostEvent](#)
[a_lib.SendMessage](#)
[a_lib.SetLED](#)
[a_lib.Sleep](#)
[a_lib.Relay](#)

IO Functions

a_lib.CloseDevice

Description

Closes an IO device (IO port or modem) that has been previously opened, freeing it for use by other scripts or processes.

Syntax

```
a_lib.CloseDevice(handle)
a_lib.CloseDevice(name)

handle:          The handle obtained when the device was opened
name:            The name of the device (i.e. "com1", "mdm1", etc)
```

Returns

None.

Example

```
a_lib.CloseDevice(name)

name:            The name of the device (i.e. "com1", "mdm1", etc)
```

a_lib.Flush

Description

Removes any characters waiting to be read.

Syntax

```
a_lib.Flush(handle)

handle:          The handle obtained when the device or socket was opened
```

Returns

None.

Example

```
-- flush waiting characters
a_lib.Flush(handle)
-- send a command
a_lib.SendString(handle, "yazzo\n")
-- look for some response
response = a_lib.GetLine(handle, 2000)
```

a_lib.GetCharacter

Description

Reads a single character from the device or socket. Returns immediately whether a character is available or not.

Syntax

```
a_lib.GetCharacter(handle)
```

handle: The handle obtained when the device or socket was opened

Returns

Character that was read, or 'nil' if no character available.

Example

```
-- prompt user
a_lib.SendString(handle, "Are you sure (y/n)? ")
-- wait for a character
repeat
    char = a_lib.GetCharacter(handle)
until char ~= nil
-- if response is Yes
if char == 'y' or char == 'Y'
    -- do stuff.....
end
```

a_lib.GetLine

Description

Reads a line of text from the device or socket. Returns when a line is received that is terminated by CR, or when the timeout, if specified, is exceeded. The maximum size of the received line must be less than 128 characters.

Syntax

```
a_lib.GetLine(handle)
a_lib.GetLine(handle, timeout)
```

handle: The handle obtained when the device or socket was opened
timeout: How many milliseconds to wait for the incoming line;
 will wait forever if timeout is not specified

Returns

Returns a string containing line that was read, not including the terminating CR. Returns 'nil' if a complete line was not received before the timeout, or if more than 128 characters were received without a terminating CR.

Example

```
-- get line of input, timeout in 2 seconds
string = a_lib.GetLine(handle, 2000)
-- if we got something
if string ~= nil then
    -- do stuff with it...
end
```

a_lib.OpenDevice**Description**

Opens an IO device (IO port or modem), and prevents it from being used by other scripts or processes.

Syntax

```
a_lib.OpenDevice(name)

name:                The name of the device (i.e. "com1", "mdm1", etc)
```

Returns

Returns a handle if successful, 'nil' if not.

Example

```
-- open the device
handle = a_lib.OpenDevice("com1")
if handle ~= nil then
    -- do some stuff....
    -- then close the device
    a_lib.CloseDevice(handle)
end
```

a_lib.SendString**Description**

Sends a string via the specified device or socket.

Syntax

```
a_lib.SendString(handle, string)

handle:                The handle obtained when the device or socket was opened
string:                The text string to be sent
```

Returns

Returns the number of bytes sent if successful, 'nil' if not.

Example

```
-- send status message to remote terminal
a_lib.SendString(handle, "Connected successfully.\n")
```

a_lib.SetDTR

Description

Sets the state of the DTR pin on the specified IO port. The port must be configured via the 'scripting.dtrcontrol.portenable' setting for DTR to be under scripting control.

Syntax

```
a_lib.SetDTR(port, state)

name:           The name of the port (i.e. "com1", etc)
state:          Value representing the desired state (0 = low, anything
else = high)
```

Returns

Returns 1 if successful, 'nil' if not.

Example

```
-- set DTR high on io3
a_lib.SetDTR("com3", true)
```

a_lib.TCPClose

Description

Closes a TCP connection that was opened previously using `a_lib.TCPConnect()`.

Syntax

```
a_lib.TCPClose(handle)

handle:          The handle obtained when the connection was established
```

Returns

None.

Example

```
-- connect to remote host using telnet port
handle = a_lib.TCPConnect("192.168.168.3", 23, 10, "telnet")
-- if connection successful
if handle ~= nil then
  -- wait for a prompt
  if a_lib.WaitForString(handle, "READY", 5000) ~= nil then
    -- do some stuff...
  end
  -- close the connection
  a_lib.TCPClose(handle)
end
```

a_lib.TCPConnect**Description**

Establish a TCP connection with a remote host.

Syntax

```
a_lib.TCPConnect(ip_address, port)
a_lib.TCPConnect(ip_address, port, timeout)
a_lib.TCPConnect(ip_address, port, options ...)
a_lib.TCPConnect(ip_address, port, timeout, options ...)
```

ip_address:	The IP address of the remote host
port:	The TCP port to connect to
timeout:	Connection timeout, in seconds (optional - default is 30)
options:	Strings representing socket options: "telnet" - use telnet option negotiation

Returns

Returns a handle if successful, 'nil' if not.

Example

```
-- connect to remote host using telnet port
handle = a_lib.TCPConnect("192.168.168.3", 23, 10, "telnet")
-- if connection successful
if handle ~= nil then
  -- wait for a prompt
  if a_lib.WaitForString(handle, "READY", 5000) ~= nil then
    -- do some stuff...
  end
  -- close the connection
  a_lib.TCPClose(handle)
end
```

a_lib.WaitForString**Description**

Waits for the specified string to be received on the specified handle.

Syntax

```
a_lib.WaitForString(handle, string)
a_lib.WaitForString(handle, string, timeout)
```

handle:	The handle obtained when the device or socket was opened
string:	The text string to be sent
timeout:	How many milliseconds to wait for the string to arrive;
	waits forever if timeout not specified

Returns

Returns 1 if successful, 'nil' if not.

Example

```
-- wait 5 seconds for prompt
if a_lib.WaitForString(handle, "READY", 5000) then
  -- send a command
  a_lib.SendString(handle, "ver\n")
end
```

Database Functions

a_lib.DBDeleteAndPost

Description

Posts data to an auxiliary database file, deleting the existing file first. The purpose of this function is to provide a way for a script to store information that needs to be preserved across resets and power-cycles of the unit. Since the file is deleted first, the data is never written to flash (which would slow things down and possibly cause premature failure of the flash part). Only the 'AUXx' files can be posted to with this function.

Syntax

```
a_lib.DBDeleteAndPost(table)

table:          Contains the following items:
numlines:       How many lines the record contains (required)
dest:           The destination file ("aux1", "aux2", etc) (required)
1..n:           Indexed record data as ASCIIIZ data (required)
```

Returns

Returns 'true' if the record was successfully posted, or 'nil' if not.

Example

```
-- create a table
a = {}
-- two-line record
a.numlines = 2
-- fill in line 1
a[1] = timestamp
-- fill in line 2
a[2] = record_hash
-- post the record
a_lib.DBDeleteAndPost(a)
```

a_lib.DBDeleteRecords**Description**

Deletes records from a database file. Oldest records are always deleted first.

Syntax

```
a_lib.DBDeleteRecords(file, numrecs)
a_lib.DBDeleteRecords(file, "all")

file:           The file that records are to be deleted from
numrecs:        How many records to delete from the file
"all":          Specifies that all records are to be deleted
```

Returns

Returns how many records were deleted, or 'nil' if the function was unsuccessful.

Example

```
-- get count of records in file
print(a_lib.DBGetRecordCount("file1"))
1281
-- delete 10 records
count = a_lib.DBDeleteRecords("file1", 10)
print(count)
10
-- delete all records
count = a_lib.DBDeleteRecords("file1", "all")
print(count)
1271
```

a_lib.DBGetRecord**Description**

Retrieves a record from a database file.

Syntax

```
a_lib.DBGetRecord(file, recnum)

file:           The file that records are to be deleted from
recnum:         Zero-based number of the record to retrieve
```

Returns

Returns the record data as a string, and the record length; returns 'nil' if unsuccessful or a record is not available.

Example

```
-- get the first record in FILE1
rec, length = a_lib.DBGetRecord("file1", 0)
-- print record
print(rec)
100300039          5718  385          7004    0
print(length)
65
```


a_lib.DBGetRecordCount**Description**

Retrieves the count of records in a database file, or the entire database.

Syntax

```
a_lib.DBGetRecordCount(file)
a_lib.DBGetRecordCount()

file:                The file to return the record count for; if not specified,
                      returns record count for entire database
```

Returns

Returns the record count, or 'nil' if unsuccessful.

Example

```
-- get count of records in file
print(a_lib.DBGetRecordCount("file1"))
1281
-- get count of records in entire database
print(a_lib.DBGetRecordCount())
13112
```

a_lib.DBLockFile, a_lib.DBUnlockFile**Description**

Locks or unlocks a database file. Locking a database file prevents records from being polled or deleted by another script or process.

Syntax

```
a_lib.DBLockFile(file)
a_lib.DBUnlockFile(file)

file:                The file to be locked or unlocked
```

Returns

Returns 1 if successful, or 'nil' if unsuccessful.

a_lib.DBPostRecord**Description**

Posts a record to the database. The record can be posted directly to the database, or it can be routed through the data filters and/or data alarms.

Syntax

```
a_lib.DBPostRecord(table)

table:           Contains the following items:
numlines:        How many lines the record contains (required)
dest:            The destination file ("file1", "alarms", etc) (required)
time:            Timestamp (seconds since Epoch) (optional)
serial:          Serial number (optional)
do_filter:       Use data filters (true/false) (optional, default is false)
do_alarm:        Use data alarms (true/false) (optional, default is false)
1..n:           Indexed record data as ASCIIIZ data (required)
```

Returns

Returns 'true' if the record was successfully posted, or 'nil' if not.

Example

```
-- create a table
a = {}
-- two-line record
a.numlines = 2
-- destination is file 2
a.dest = 2
-- fill in the timestamp
a.time = os.time()
-- fill in line 1
a[1] = "this is line 1, jack\r\n"
-- fill in line 2
a[2] = "and here is line 2, jill\r\n"
-- post the record
a_lib.DBPostRecord(a)
```

Miscellaneous Functions

a_lib.AccessSetting

Description

Reads or modifies a setting.

Syntax

```
a_lib.AccessSetting(setting_key)

setting_key:    Setting key name, plus equals sign and new value if modifying
```

Returns

Returns a string containing the value of the setting if successful, 'nil' if not.

Example

```
-- read a setting
print(a_lib.AccessSetting("sys.sitename"))
Data-Link
-- modify a setting
print(a_lib.AccessSetting("sys.sitename = Yakkity Yack"))
Yakkity Yack
```

a_lib.CheckMessages

Description

Checks for IPC message from the system or another script.

Syntax

```
a_lib.CheckMessages()
```

Returns

Returns the message ID of the received message, and the message string if any. Returns 'nil' if no message was received. There are several messages that could be sent to a script from the system. A well-behaved script should call CheckMessages() periodically and handle these messages appropriately:

Message ID	Purpose
13808	Terminate. The script should do any necessary cleanup and then shut down gracefully using the a_lib.Exit() function.
13819	Yield device. A passthrough session is being initiated to a port that is currently allocated by the script. The script can close the device or terminate to allow the passthrough session to proceed, but it is not required to.

Example

```
-- check for message
message_id = a_lib.CheckMessages()
-- if it is shutdown request
if message_id == 13808 then
    -- do graceful shutdown...
end
```

a_lib.Decrypt**Description**

Decrypts ciphertext that was generated using the `a_lib.Encrypt()` function.

Syntax

```
a_lib.Decrypt(ciphertext, length)
ciphertext:      String containing the ciphertext
length:          Length of ciphertext string
```

Returns

Returns the decrypted data as a string, and the data length.

Example

```
a-- initialize encryption
my_key = "yaddayadda"
a_lib.InitEncryption(my_key, #my_key)
-- encrypt a message
message = "Hello world!"
ciphertext, ciphertext_length = a_lib.Encrypt(message, #message)
-- print the encrypted message
print(ciphertext)
<this will yield a bunch of garbage characters>
-- decrypt the message
decrypted_message = a_lib.Decrypt(ciphertext, ciphertext_length)
-- print it out
print(decrypted_message)
Hello world!
```

a_lib.Encrypt**Description**

Encrypts data using the Blowfish encryption algorithm.

Syntax

```
a_lib.Encrypt(plaintext, length)
plaintext:      String containing the data to encrypt
length:          Length of plaintext string
```

Returns

Returns the encrypted data as a string, and the data length.

Example

```
a-- initialize encryption
my_key = "yaddayadda"
a_lib.InitEncryption(my_key, #my_key)
-- encrypt a message
message = "Hello world!"
ciphertext, ciphertext_length = a_lib.Encrypt(message, #message)
-- print the encrypted message
print(ciphertext)
<this will yield a bunch of garbage characters>
-- decrypt the message
decrypted_message = a_lib.Decrypt(ciphertext, ciphertext_length)
-- print it out
print(decrypted_message)
Hello world!
```

a_lib.Exit

Description

Terminates the script.

Syntax

```
a_lib.Exit(result)
result:          Result code to indicate the exit status of the script
```

Returns

None.

Example

```
-- if some operation failed
if SomeOperation() ~= true then
  -- terminate with error (user-defined error code)
  a_lib.Exit(3)
end
-- otherwise do some other stuff...
-- and then terminate normally (0 is the usual 'normal' result)
a_lib.Exit(0)
```

a_lib.HashFinalize**Description**

Finalizes MD5 hash value.

Syntax

```
a_lib.HashFinalize()
```

Returns

Returns a 32-character ASCII string containing the hash value.

Example

```
-- initialize hash function
a_lib.HashInit()
-- traverse string array 'lines'
for i,l in pairs(lines) do
    --- update hash with current line
    a_lib.HashUpdate(l)
end
-- finalize hash
hash = a_lib.FinalizeHash()
-- print it out
print(hash)
971CCDF7813648A532D8682B39A60CF9
```

a_lib.HashInit**Description**

Initializes MD5 hashing function.

Syntax

```
a_lib.HashInit()
```

Returns

None.

Example

```
-- initialize hash function
a_lib.HashInit()
-- traverse string array 'lines'
for i,l in pairs(lines) do
    --- update hash with current line
    a_lib.HashUpdate(l)
end
-- finalize hash
hash = a_lib.FinalizeHash()
-- print it out
print(hash)
971CCDF7813648A532D8682B39A60CF9
```

a_lib.HashUpdate**Description**

Updates MD5 hash.

Syntax

```
a_lib.HashUpdate(string)

string:      String value to update hash with; as a Lua string, it can
             contain binary values
```

Returns

None.

Example

```
-- initialize hash function
a_lib.HashInit()
-- traverse string array 'lines'
for i,l in pairs(lines) do
    --- update hash with current line
    a_lib.HashUpdate(l)
end
-- finalize hash
hash = a_lib.FinalizeHash()
-- print it out
print(hash)
971CCDF7813648A532D8682B39A60CF9
```

a_lib.InitEncryption**Description**

Initialize encryption/decryption functions with a user-specified key.

Syntax

```
a_lib.InitEncryption(key, key_length)
key:      String value to use as encryption/decryption key
key_length:  Length of key string
```

Returns

Returns 1 if successful, nil if not.

Example

```
<<< See example for a_lib.Encrypt function. >>>
```

a lib.PostAudit**Description**

Posts a message to the audit log.

Syntax

```
a_lib.PostAudit(string
)
string:                Message to post
```

Returns

None.

Example

```
-- post message to audit log
a_lib.PostAudit("Script 'Jabba the Hut' posting to audit log.")
```

a lib.PostEvent**Description**

Posts an event to the event-handling queue.

Syntax

```
a_lib.PostEvent(message_text, actions_key)
a_lib.PostEvent(message_text, actions_key, class_offset)
a_lib.PostEvent(message_text, actions_key, class_offset, trap_number)

message_text:          Event message
actions_key:           Setting key that specifies event actions
class_offset:          Event class (1-12)
trap_number:           Trap number to use if trap action is specified
```

Returns

Returns 1 if successful, 'nil' if not.

Example

```
-- set message text
msg = "Cannot communicate with switch."
-- set actions key to use (hijacking data event 100 setting in this ;Example)
key = "event.data[100].actions"
-- set event class to 3 (major)
class = 3
-- post the event
a_lib.PostEvent(msg, key, class)
```


a_lib.SendMessage

Description

Posts a message to another script.

Syntax

```
a_lib.SendMessage(target_script, message_id)
a_lib.SendMessage(target_script, message_id, message)

target_script:      Target script name, or its 1-based settings index
message_id:         Message ID (used-defined) (message id's greater than
10000 are reserved)
message:            String containing message data; as a Lua string, it can
contain binary values
```

Returns

Returns 1 if the target script is running, or 'nil' if not. Note that there is no guarantee the target script will actually process the message.

Example

```
-- set target script by name
name = "Switch Handler"
-- set message id
msg_id = 5
-- send some text as the message
msg_text = "Manual override"
-- send the message
a_lib.SendMessage(name, msg_id, msg_text)
```

a_lib.SetLED

Description

Controls the state of front panel LEDs on the SL85. Supported LEDs can be set to off, steady on, or flashing at 1 cycle per second.

Syntax

```
a_lib.SetLED(led, state)

led:                Which led to control ("alert1", "alert2", or "alert3")
state:              State to set the LED to ("off", "on", or "flash")
```

Returns

None.

Example

```
-- turn on the alert1 LED
a_lib.SetLED("alert1", "on")
-- make alert2 LED flash
a_lib.SetLED("alert2", "flash")
```

a_lib.Sleep**Description**

Suspend script activities for specified amount of time.

Syntax

```
a_lib.Sleep(time_in_milliseconds)

time_in_milliseconds:   How much time to sleep, in milliseconds
```

Returns

None.

Example

```
-- wait for 5 seconds before further actions
a_lib.Sleep(5000)
```

a_lib.Relay**Description**

Sets a relay output to a given state.

Syntax

```
a_lib.Relay(slot, relay, state)
a_lib.Relay(slot, relay, state, duration)

slot:           Eventsensor slot (0-16; 0 for internal)
relay:          Relay number on eventsensor (1-10)
state:          State to set relay to: "Closed", "Open", "Active", "Inactive"
duration:       Number of seconds to hold active state (optional, only
applies to active state)
```

Returns

Returns 1 if the command is successful, or 'nil' if not.

Example

```
-- set internal relay 3 to 'closed' state for 5 seconds
print(a_lib.Relay(0, 3, "closed", 5))
```

Command Reference

User Interface Commands

Note: The HELP command can give helpful context sensitive information for most commands.

Command	Summary	Syntax	Description
BYE	Disconnect from unit	BYE	Disconnect a processor session.
EXIT	Exit command processor	EXIT	Ends the console session.
HELP	Show help menu	HELP [<i>command</i>]	Displays a list of commands or context sensitive help for a specific command.
PING	Ping IP address	PING <i>target_address</i>	Performs a standard network ping function on the specified IP address.
RESTART	Restart unit	RESTART	Reset the system, same as pressing the physical reset button.
SENSORS or !	Display status of internal or external sensors	SENSORS or !	Display the status of internal or external sensors
STATUS or ?	Display status screen	STATUS or ?	Display the status screen
STATUSW or STATUS WIRELESS or ?WIRE or ?WIRELESS	Display status of wireless modem	STATUSW or STATUS WIRELESS or ?WIRE or ?WIRELESS	Display the status of the wireless modem

Setup Commands

Command	Summary	Syntax	Description
BYPASS	Access serial ports	BYPASS [<i>port_number</i>]	Provide pass-through terminal access between the user and the input port.
SK	Set/get key	SK [KEY[= <i>value</i>]]	Set or get a single key See Setting Keys for more information.
SK GET	Read keys	SK GET [X A [CUSTOM] [<i>filter</i>]]	SK GET initiates a download of Setup menu options. See Setting Keys for more information.
SK HERE	Manage individual keys	SK HERE	SK HERE allows you to set or get individual keys interactively. See Setting Keys for more information.
SK LOG	Show SK error log	SK LOG	SK LOG outputs a list of any errors generated during an SK set. See Setting Keys for more information.
SK SET	Set keys	SK SET [X A]	SK SET puts the unit in bulk settings key upload mode. See Setting Keys for more information.
SETUP	Enter setup menu	SETUP	Opens the setup menu.

System Commands

Command	Summary	Syntax	Description
COLDSTART	Cold boot unit	COLDSTART	Resets the same settings as the DEFAULT command and then reboots the unit.
DEFAULT	Restore factory defaults	DEFAULT	Resets all settings to factory default values, except does not change the following settings: <ul style="list-style-type: none"> • IP address • Subnet mask • Router address • Serial port baud rate and data format • Data alarm fields • Data alarm settings • Action queue Does not affect record data
DOMAIL	Test emails	DOMAIL	Sends a test email to all defined email addresses.
DOPAGE	Test pagers	DOPAGE	Sends a test page to all defined pagers.
DOTRAP	Test traps	DOTRAP	Sends a test trap to all defined trap managers.
PUSHNOW	Initiate an immediate FTP push of data	PUSHNOW	Initiates an immediate FTP push of data
PUSHTEST	Test connectivity to the FTP server	PUSHTEST	Tests connectivity to the FTP server
TYPE	Print events file contents	TYPE [EVENTS AUDIT]	Print the contents of the Events or Audit file.
VER	Print unit version	VER	Displays unit hardware and software versions as well as the product and version build.

Wireless Modem

The wireless modem expansion card supports the same features as connecting directly to the S550 interface, including Telnet, FTP, SSH, and so on. It also supports PPP routing, which allows communication with devices connected to one of the local Ethernet interfaces.

The wireless EDGE modem is for use in SiteBoss products with firmware version 2.00.240 and above.

The wireless GPRS modem is for use in SiteBoss products with firmware version 2.00.330 and above

Installation

If installing the wireless modem for the first time (not factory installed), follow these installation instructions:

- Make sure the the host S550 is powered down.
- Insert your SIM card into the slot on the wireless modem module, with the contacts on the bottom, using the card outline printed on the circuit board as a guide.
- Remove the two screws from any of the expansion port covers on the back panel of the host unit and set the port cover aside. Carefully slide the wireless modem card into the plastic rails inside the expansion port and push the card in all the way. Replace the two screws previously removed so the card is held securely in the port.
- Screw the rubber GMS antenna (or cable to an external antenna) to the SMA connector on the modem. The unit should not be powered up without an antenna connected to the modem.
- Power up the host unit.

Setup

In addition to installing an activated SIM card in the wireless modem card, certain settings on the host unit need to be configured for the wireless connection to work. These settings can be configured via either Setting Keys or the Setup Menus as described below. Changing any of these settings should be done with **net.wireless.mode** set to OFF, otherwise unexpected behavior may occur.

Setting Keys

Following are the Setting Keys used to configure the wireless modem card. All of the Setting Keys below can also be configured in the Setup menus listed in parenthesis after each.

net.wireless.mode (Setup -> Modem Settings -> Wireless Modem Settings)

Enables or disables the wireless modem. Possible values are OFF (disable modem), PERMANENT-EDGE (maintain "always-on" connection with EDGE modem), and PERMANENT-GPRS (maintain "always-on" connecion with GPRS modem). The default setting is OFF.

net.wireless.apn (Setup -> Modem Settings -> Wireless Modem Settings)

The Access Point Name (APN) as defined by your wireless provider. Default setting is "".

net.wireless.pin (Setup -> Modem Settings -> Wireless Modem Settings)

The PIN associated with the SIM card, if any.

net.wireless.idletimeout (Setup -> Modem Settings -> Wireless Modem Settings)

The period of inactivity, in minutes, after which the modem connection is recycled. The allowed range is 3-255 minutes. The default setting is 5 minutes. The purpose of this setting is to allow the modem to get reset after a period of time to ensure the modem connection is working properly.

net.wireless.pppusername (Setup -> Modem Settings -> Wireless Modem Settings)

net.wireless.ppppassword (Setup -> Modem Settings -> Wireless Modem Settings)

Used to set the login credentials for the PPP session.

net.ppprouting.enable (Setup -> Network Settings -> PPP Settings -> IP Routing)

This setting controls whether the unit routes IP traffic from PPP to an Ethernet interface specified by the destination IP address's subnet. On products which have DIP switches, this setting is mechanically locked with a DIP switch for added security. On products with this feature but without DIP switches, there is no way to lock this.

net.eth.nat (Setup -> Network Settings -> Ethernet Settings -> Ethernet n Settings)

This setting controls whether the unit does Network Address Translation (NAT) on routed frames egressing the unit on the specified interface. That is, when PPP routing is operating and forwarding frames received on the PPP interface (which can be the same thing as the wireless modem interface), the unit rewrites the source IP address of forwarded frames leaving the unit to the IP address of the ethernet interface on which they leave. If this setting is disabled then forwarding may still happen since it is governed only by the PPP routing settings, but the source IP address of the forwarded frames is not rewritten.

net.wireless.defaultrouteenable (Setup -> Modem Settings -> Wireless Modem Settings)

When ON, the wireless interface is set as the default route when connected (which is either never, or all the time, with our current options). When OFF, the wireless interface will not become the default route when connected. The default is OFF. For a change to this setting to take effect and if the wireless link is already up, the wireless link must be restarted. While it is possible to detect a change to this setting and automatically restart the wireless link, it is possible that an ongoing session (such as a web session, which would not be seen as an ongoing connection) could get interrupted. To avoid this restart the wireless connection, using the **wireless restart** command. This brings down the wireless link, and it automatically comes back up with the new setting in effect.

Setup Menu

All of the **net.wireless** settings above can be accessed in the setup menu at: Modem Setting -> Wireless Modem

```
SiteBoss 550 - Wireless Modem Settings
A) Mode                               [OFF]
B) APN                                []
C) PIN                                []
D) Idle Timeout (minutes)             [5]
E) Band (GPRS only)                   [DUAL-850/1900]
F) PPP/Wireless User Name              []
G) PPP/Wireless Password               [*****]
H) Default Route Enable                [OFF]
```

Operation

With **net.wireless.mode** set to PERMANENT-EDGE or PERMANENT-GPRS (depending on the type of modem installed), the unit attempts to maintain a connection to the wireless network at all times. If the connection goes down for any reason, including inactivity, the unit immediately attempts to reconnect. When there is no activity on the link for longer than the inactivity timeout (see below), the connection is terminated and immediately restarted. If **net.wireless.mode** is set to OFF, wireless modem operations are terminated immediately (there may be up to a minute's delay if certain operations are pending).

The **wireless restart** command causes the wireless modem to terminate the connection and restart it based on the current settings; this is useful if a setting other than "mode" is changed.

The default setting for the wireless connection is to NOT be the default route for outbound IP frames. A static route must be entered for any frame to be sent out on the wireless connection. If **Default Route Enable** is changed to ON for the wireless connection, then all IP frames that do not match an existing static route will be sent out on the wireless connection. For situations where the wireless modem is the only means of off-net access, **Default Route Enable** should be set to ON.

The front-panel MODEM-W LED shows the status of the wireless modem. If **net.wireless.mode** is set to OFF then the LED should remain unlit. When **net.wireless.mode** is set to PERMANENT-EDGE or PERMANENT-GPRS, the LED flashes once per second while the modem is attempting to establish a network connection. Once the connection is established, the LED blinks every 3 seconds.

Status Commands

On all products, the current status of the wireless connection can be displayed using the “**?w**” or “**statusw**” commands. (Note that “**?wire**” or “**?wireless**” or “**statusw**” or “**status wireless**” are also valid commands.) The unit will respond with: “**Wireless modem status: <state>**” Possible states are:

:not installed	wireless card not detected
:not enabled	net.wireless.mode=OFF
:connecting	attempting to establish connection *
:connected	connection established, no active TCP session
:active	connection established, one or more active TCP sessions
:idle	which it may be for only a moment between sessions


* if it says “Connecting” most of the time, there is a problem and it would be advisable to contact Asentria Tech Support to check the wireless modem log.

Troubleshooting Commands

For troubleshooting, user either the “**?w log**” or “**statusw log**” command. (Note that “**?wire log**” or “**?wireless log**” or “**statusw log**” or “**status wireless log**” are also valid commands. The word “log” must be preceded by a space.) Contact Asentria Tech Support if troubleshooting is required as the log data probably will not be useful to the user.

ADSL Modem

SiteBoss units that are ADSL-modem-equipped can connect to the Internet via ADSL. This means that the unit can reach Internet hosts and have an Internet IP address but the address is completely firewalled so you will not be able to, for example, ping the unit's DSL interface IP address.

 **Note:** Full ADSL modem functionality is only available on SiteBoss products with the "SitePath" build (version 2.03.000 or greater). If there is any question about whether your unit has the SitePath build, contact Asentria Technical Support (support@asentria.com) or 206-344-8800.

Installation

If installing the ADSL modem for the first time (not factory installed), follow these installation instructions:

- Make sure the host unit (e.g. SiteBoss device) is powered down.
- Remove the two screws from any of the expansion port covers on the back panel of the host unit and set the port cover aside. Carefully slide the ADSL modem card into the plastic rails inside the expansion port and push the card in all the way. Replace the two screws previously removed so the card is held securely in the port.
- Power up the host unit.

Description of ADSL

ADSL (Asymmetric Digital Subscriber Line) is a technology where data is modulated onto higher frequencies of copper telephone lines not used for voice in such a way that upstream and downstream data rates differ. Certain Asentria SiteBoss units can have an ADSL modem expansion card installed to provide an interface to a line. The machine on the other end of the line is a DSLAM (Digital Subscriber Line Access Multiplexer). DSLAMs exist typically inside telephone company central offices (COs) but also exist in standalone hutches (remote DSLAMs).

The abbreviations "DSL" and "ADSL" are used interchangeably in this documentation; where "DSL" is written, "ADSL" also applies unless the difference is explicitly specified.

Certain terms and acronyms are used throughout this guide that may require further explanation. These are hyper-linked to the [Glossary](#) at the end of the guide.

Configuration

The ADSL modem can be configured via two methods in the SiteBoss or TeleBoss unit: [command line menus](#) or [Setting Keys](#). For simplicity, only the Setting Keys method is discussed in this guide. However, as you are working through the configurations you are welcome to also use the related Command Line menus (Setup -> Network Settings -> DSL Settings) or web-interface menus in your SiteBoss or TeleBoss unit to view or configure specific settings.

There are four ways to configure ADSL depending on the specifications from your ADSL and ISP providers. In some cases the ADSL provider and ISP provider are the same. For simplicity and unless otherwise specified, "ADSL provider" means the entity that provides all settings required for the unit to use the Internet over the ADSL.

The key datum to get from your ADSL provider is what type of addressing is to be used: **PPPoA** ([PPP](#) over [ATM](#)), **PPPoE** ([PPP](#) over Ethernet), **Static**, or **DHCP**. Make note of this, then proceed with configuring the ADSL modem as described below.

Set the value of the [net.dsl.type](#) Setting Key to either **PPPoA**, **PPPoE**, **Static**, or **DHCP** as instructed by your ADSL provider. This is the most important DSL setting since its value determines what other DSL settings are applicable to the DSL configuration. Each of these connection protocols requires specific settings, so refer to the paragraph below for the protocol you will be using. But first, there are some settings that must be configured regardless of how [net.dsl.type](#) is set.

Required Settings Regardless of Connection Protocol**net.dsl.vpi**

This specifies the [VPI](#) (Virtual Path Identifier) used on the DSL interface. This is provided for you by your DSL provider and is required for DSL operation. Values are: **0** to **4095**

net.dsl.vci

This specifies the [VCI](#) (Virtual Channel Identifier) for the DSL interface. This is provided for you by your DSL provider and is required for DSL operation. Values are: **0** to **65535**.

net.dsl.encap

This controls whether the encapsulation is [LLC](#) (Logical Link Control) or [VCM](#) (Virtual Channel Multiplexed). This is provided for you by your DSL provider and is required for DSL operation. Values are **LLC** or **VCM**.

Settings for PPPoA or PPPoE**net.dsl.username**

This specifies the PPP username for the DSL interface. This is provided for you by your DSL provider. Values are text strings up to 64 characters.

net.dsl.password

This specifies the PPP password for the DSL interface. This is provided for you by your DSL provider. Values are text strings up to 64 characters.

Settings for Static**net.dsl.mode**

This controls whether the DSL is set up for Bridged mode or Routed mode. This is provided for you by your DSL provider. Values are **BRIDGED** or **ROUTED**.

net.dsl.ip

This is the public IP address of the unit in the case where the DSL link is active. This is essentially inaccessible from the outside world because it is completely firewalled on the unit. This is provided for you by your DSL provider. Value is a dotted quad IP address.

net.dsl.mask

This controls the mask used on the DSL interface. This is provided for you by your DSL provider. It is applicable only when net.dsl.type is STATIC. Value is a dotted quad subnet mask.

net.dsl.router

The router for the DSL interface. This is provided for you by your DSL provider. This is applicable only when net.dsl.type is STATIC. Value is a dotted quad IP address.

net.dns

This specifies Domain Name System addresses to use. This is provided for you by your DSL provider. Value is a dotted quad IP address.

Settings for DHCP

If **net.dsl.type** is DHCP then no additional settings need to be configured.

Activation

Once the DSL interface is configured it must be activated. This happens automatically or manually according to how the Start Mode setting is configured:

net.dsl.startmode Set this to MANUAL to require user intervention to raise the DSL interface, or to let a [VPN](#) (if it is configured to use DSL) raise the DSL interface when the VPN needs to use DSL. Set this to AUTO to tell the unit to automatically raise the DSL interface upon boot. Values are **MANUAL** or **AUTO**. Default setting is MANUAL.

Manual Activation

net.dsl.command Set this to 1 to manually activate the DSL interface, and set this to 0 to manually deactivate the DSL interface.

In manual activation the DSL interface will not activate unless some purpose requires it: either you tell it to activate or your ADSL-based VPN, when it is being raised, tells it to activate. If you tell the interface to activate then do this by

setting **net.dsl.command=1**. The unit returns COMPLETE, meaning it has started the activation process; it does not mean that the interface is ready to use yet. Activation is a multistep process and may take a minute or two to complete.

If the VPN tells the interface to activate, then activation happens when the VPN raises.

Read **net.dsl.command** (or **net.dsl.status**) to check the status of the DSL interface.

net.dsl.command=0 when the DSL interface is not activated
net.dsl.command=1 when DSL activation is in process
net.dsl.command=2 when the DSL interface is trained but not yet fully activated
net.dsl.command=3 when the DSL interface is fully activated (ready to use for network traffic)

If the interface doesn't activate, then first check if anything about the configuration on the unit is invalid. Then check this configuration against what was specified by the ADSL provider.

Automatic Activation

In automatic activation the unit raises the DSL interface upon boot and keeps it up until it is explicitly deactivated by the user by setting **net.dsl.command=0**.

Once the interface is activated you can use it as an outbound-only interface. It is completely firewalled to the Internet. The only traffic allowed in is traffic associated with existing connections, meaning all connections must originate from unit. Pinging (ICMP), TCP, and UDP traffic is the only traffic allowed and this traffic must originate from the unit.

Data on the ADSL connection can be viewed with the **net.dsl.info.*** key branch:

net.dsl.info.isp.ip

Read this key to see what IP address the DSL interface is using with the ISP.

net.dsl.info.isp.linktime

Read this key to see how long the unit has been connected to the ISP (i.e., how long the unit has had Internet access) since the connection was started.

net.dsl.info.isp.status

Read this key to see whether the unit is connected to the ISP; it returns "Connected" or "Not Connected". Another key that gives the same information in a different format is **net.dsl.status**.

net.dsl.info.isp.discreason

Read this key to see why, if available, DSL connectivity was lost.

net.dsl.info.link

Read this key to see whether the unit has DSL connectivity (as opposed to ISP connectivity shown with **net.dsl.info.isp.status**).

net.dsl.info.speed

Read this key to see the speed of the link (provided there is DSL connectivity, as shown with **net.dsl.info.link**).

net.dsl.info.ver.sw

Read this key to see the ADSL modem software version.

net.dsl.info.ver.fw

Read this key to see the ADSL modem firmware version.

net.dsl.info.ver.atm

Read this key to see the ADSL modem ATM driver version.

net.dsl.info.ver.dslhal

Read this key to see the ADSL modem DSL HAL version.

net.dsl.info.ver.sarhal

Read this key to see the ADSL modem SAR HAL version.

net.dsl.info.ver.pump

Read this key to see the ADSL modem data pump version.

net.dsl.info.updated

Read this key to see the last date/time at which the values in the **net.dsl.info.*** key hierarchy were last updated. These values are updated when directed by the user (by setting **net.dsl.command** to 20) or every few seconds by the unit until the ADSL modem is connected to the ISP (at which time it doesn't update until directed by the user or ISP connectivity is lost).

DSL Status

net.dsl.status is a read-only key that displays a value that reflects the current state of the DSL interface. Values are an integer ≥ 0 .

- **0** means it is not activated (the unit is not talking to the modem, no address is usable with the ISP, the DSL is not [trained](#))
- **1** means the interface is in an intermediate level of availability: there is no address usable with the ISP and the DSL is not [trained](#), but the unit **can** talk (but not necessarily **is** talking) to the modem.
- **2** means the interface is in an intermediate level of availability, moreso than value "1": there is no address usable with the ISP but the DSL **is** [trained](#) and the unit has good communication with its DSL modem.
- **3** means the interface is fully activated: DSL is [trained](#) and there is an address usable with the ISP.

These values are analogous to modem LEDs seen on some DSL routers: power, "link", "DSL", "Internet". 0 can be thought of as "power", 1 can be thought of as "link", 2 can be thought of as "DSL", and 3 can be thought of as "Internet".

Connectivity

When the interface is activated it can be used for Internet connectivity. The simplest way to use it is as ADSL gateway via the DSL routing function (see [DSL Routing](#) section).

Deactivation

Deactivation means the unit is no longer connected to the ISP provider via ADSL. Deactivate by setting **net.dsl.command=0**. When the DSL interface is deactivated the line may still be [trained](#).

ADSL specifications

- Full rate ANSI T1.413 Issue2, ITU-T G.992.1 and ITU-T G.992.2 standards compliant
- ITU G.992.3, ITU G.992.5 and READSL2 ADSL2/2+ standards compliant
- Annex M and Annex L specification
- Downstream and upstream data rates up to 24Mbps and 1Mbps
- Reach length up to 22Kft.
- Dying Gasp functionality
- OAM F4/F5 loop back
- VC and LLC multiplexing
- Multiple protocols over AAL5 (RFC 2684 / RFC 1483)
- PPPoA (RFC 2364)
- PPPoE (RFC 2516)
- UBR, CBR, rt-VBR and nrt-VBR traffic shaping QoS

DSL Routing

DSL routing is used to make the unit route, and do network address translation (NAT) on, NAT-capable traffic (TCP, UDP, and ICMP) from the unit's Ethernet ports to the unit's DSL peer, and hence on to the Internet. For example, a PC that uses one of the unit's Ethernet addresses as its default router can browse the web via the unit's DSL connection. The DSL interface is firewalled such that only traffic related to already-existing-outgoing connections is allowed in.

Configuration

The following Setting Keys need to be configured:

net.dsl.startmode

Set this to AUTO to tell the unit to automatically raise the DSL interface upon boot. Set this to MANUAL to require user intervention to raise the DSL interface, or to let a VPN (if it is configured to use DSL) raise the DSL interface when the VPN needs to use DSL. Values are **MANUAL** or **AUTO**. Default setting is MANUAL.

net.default.router

This setting allows you to select the default router (gateway) for the unit. Each network interface has a router setting which you can configure; this is the machine on that interface to which frames will be sent if they do not route to the local network of that interface. However the unit uses only one of those configured routers at this time. As you configure router settings the unit will choose a default router for you. This is available for you to see (and override) via this **net.default.router** setting. The values you may choose for this setting (i.e., router addresses) must be in the set of routers which you have specified, or the special value, "DSL", which means that the DSL interface peer is the default router. For DSL Routing, set **net.default.router=DSL**.

The unit uses a routing table to determine how to send any outbound IP frame. Each entry in the routing table tells the unit how to send a frame whose destination address matches a rule in the routing table. Routing table entries are examined from most-restrictive to least-restrictive, so the default routing table entry is the last entry in the table since it is the least restrictive. It is the catch-all route: it tells the unit how to send a frame when it doesn't know how else to send it. The only routes on the unit at this time are network interface routes and the default route. Network interface routes tell the unit how to send a frame bound for a machine on one of the unit's local networks (subnets). These routes are automatically configured when you configure the address of a network interface. If an outbound frame is destined for a machine off all local networks then it is sent according to what the default route specifies. The default route specifies the default router to use for these frames.

If you have configured only one router for all of your network interfaces then you don't have to worry about this setting: the unit configures it for you and there is nothing you can override it with. The default router is engaged as soon as it is configured.

net.dsl.routing.enable

Set this to ON to make the unit forward frames received on either Ethernet interface (and not addressed to the unit) out the DSL interface. Frames are NAT-ed as they leave the DSL interface. Frames arriving on the DSL interface not associated with existing connections are blocked (the unit is firewalled). Note that the unit's default router must be set to DSL (**net.default.router=DSL**) for DSL routing to work. Set this to OFF to make the unit not do this. Values are: **ON** or **OFF**. Default is OFF.

net.dsl.override

Set this to a non-zero value to enable ADSL web configuration access on the TCP port specified by the value. Set this to 0 to disable web configuration access. Values are: **0** to **65535**. Default is 0.

net.dsl.cmd

This has the same behavior as **net.dsl.command**.

net.dsl.status

Upon read this returns 0, 1, 2 or 3. Refer to the [net.dsl.status](#) description above for further details.

DSL Routing Example

- 1) Configure the unit so it sits on an Ethernet network.
- 2) Enter the following keys to configure the unit for routing:
`net.dsl.startmode=manual`
`net.default.router=dsl`
`net.dsl.routing.enable=on`
- 3) Say the DSL provider sent you these settings:
`PPPoA (VCM)`
`VPI: 0`
`VCI: 38`
`Username: dsluser`
`Password: dslpassword`
- 4) Enter the following Setting Keys to configure the unit accordingly:
`net.dsl.type=pppoa`
`net.dsl.mode=vcm`
`net.dsl.vpi=0`
`net.dsl.vci=38`
`net.dsl.username=dsluser`
`net.dsl.password=dslpassword`
- 5) Enter the following function key to raise the DSL interface:
`net.dsl.cmd=1`
- 6) Upon setting this key to 1 the unit begins the process of raising the DSL interface. You can query the status of the DSL interface by reading the [net.dsl.status](#) function key. To lower the DSL interface, set:
`net.dsl.cmd=0`
- 7) After a minute or two this key (or the [net.dsl.status](#) key) will return 3. If something went wrong then it will stay at 1 or 2 in which case the configuration should be rechecked.
- 8) To make the interface raise upon boot, enter:
`net.dsl.startmode=auto`
- 9) Test the connection by pinging an Internet host from the unit. Once it is verified good, proceed to configure machines which will use the unit as a DSL router. On these machines set their default router to the unit's Ethernet IP address (address that is on the same subnet as these machines). Optionally you can configure this same address as a DNS server for these machines. Test the routing connection by pinging an Internet host from these machines.

DSL Glossary

ATM

Asynchronous Transfer Mode is a network technology based on transferring data in cells or packets of a fixed size. The cell used with ATM is relatively small compared to units used with older technologies. The small, constant cell size allows ATM equipment to transmit video, audio, and computer data over the same network, and assure that no single type of data hogs the line.

DHCP

Dynamic Host Configuration Protocol, a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network.

DSLAM

A **Digital Subscriber Line Access Multiplexer** is a mechanism at a phone company's central location that links many customer DSL connections to a single high-speed [ATM](#) line. When the phone company receives a DSL signal, an ADSL modem with a splitter detects voice calls and data. Voice calls are sent to the PSTN (Public Switched

Telephone Network), and data are sent to the DSLAM, where it passes through the ATM to the Internet, then back through the DSLAM and ADSL modem before returning to the customer's PC or networked-device.

LLC and VCM

Logical Link Control and **Virtual Channel Multiplexing** are methods of encapsulating data on an ATM communication link. Encapsulation is the process of storing cells from the foreign protocol inside PPP frames.

PPP

Point-to-Point Protocol is a method of connecting a PC or networked-device to the Internet.

Setting Keys

A Setting Key is a "<setting> = <value>" statement. <setting> is a series of keywords that describe a particular function of the unit, or setting. These keywords are separated by periods, for example [net.dsl.startmode](#). The current value of a Setting Key can be obtained by typing **sk <setting>** at the command line and pressing the Enter key. A new value for a Setting Key can be set by typing **sk <setting> = <value>** and pressing the Enter key. The value must be valid for that particular Setting Key, and the unit will respond with COMPLETE when it is accepted. If the value is invalid, the unit will respond with Invalid Value. Contact Asentria Tech Support for more information on Setting Keys if necessary.

Signal-to-noise ratio

Signal-to-noise ratio is an electrical engineering concept defined as the ratio of a signal power to the noise power corrupting the signal. In less technical terms, signal-to-noise ratio compares the level of a desired signal to the level of background noise. The higher the ratio, the less obtrusive the background noise is.

Trained

This refers to the general ability of a modem to adjust itself to optimize the communication channel. When a modem modulates data on a line, the communication infrastructure degrades the data. Some of this degradation is due to noise and some of it is due to the modem's own echo. Part of training the modem (also sometimes referred to as "training the line") involves having the modem select optimal [signal-to-noise ratio](#) as well as teaching the modem what its own "voice" (its echo) sounds like on the line. A modem receives not only data from the other modem but also its own echoes, like when you yell to someone across a canyon and listen for their response; training helps the modem separate its own echos from the signal from the other modem.

VCI

A **Virtual Channel Identifier** is a unique identifier which indicates a particular virtual circuit on a network. It is a 16-bit field in the header of an [ATM](#) cell. The VCI, together with the [VPI](#) (Virtual Path Identifier) is used to identify the next destination of a cells as it passes through a series of ATM switches on its way to its destination.

VPI

Virtual Path Identifier refers to an 8-bit (user to network packets) or 12-bit (network-network packets) field within the header of an [ATM](#) cell. The VPI, together with the [VCI](#) (Virtual Channel Identifier) is used to identify the next destination of a cell as it passes through a series of ATM switches on its way to its destination. VPI is useful to reduce the switching table for some Virtual Circuits which have common path.

VPN

Virtual Private Network is a network that is tunneled (the virtual part), typically across a public network, and secured (the private part).

Battery Module

The SiteBoss 550 is available with an optional battery backup that provides backup power for the unit in the event of power loss.

Setup

Ensure the front panel battery enable/disable switch is in the 'enable' position. There is no other setup associated with using the battery module, nor are there any settings related to it.

Operation

As long as the front panel battery enable/disable switch is in the 'enable' position, the battery will be available in case of power loss. The amount of time that the host unit can run off battery power depends on various things including the state of battery charge at the time, and the number and type of optional devices installed in the host unit.

If the unit is running on battery power, and the front panel battery enable/disable switch is changed to the 'disable' position, the host unit will immediately shut down.

The host unit cannot be started up from the battery. This is because battery relay (which connects the battery power to the system) is open when no power is applied; it gets closed once the unit starts up and the battery manager application runs. Only at that point does battery power become available.

The status of the battery module can be determined from the command processor via the battery status command.

Basic Status

```
>status battery
Battery Status

Enable switch position: ON
Running on battery: YES (0:05:13)
```

Note that the command can also be invoked in a more abbreviated format such as "**? battery**", "**statusb**" or even "**?b**".

When the charging current goes below 100mA, the charging voltage is switched from high (7.35 volts) to low (6.85 volts).

When running on battery power, if the battery voltage falls below 5.435 volts, the unit shuts down. Several warning messages are sent to all open command processors as the battery voltage gets low.

Appendices

User Rights Table

The following tables contain the rights available to each access level within the user profiles.

Command Permissions

Command	None	View	Admin1	Admin2	Admin3	Master
ADDLF			X	X	X	X
BYE	X	X	X	X	X	X
COLDSTART						X
DEFAULT						X
DELETE			X	X	X	X
DIR		X	X	X	X	X
DOMAIL		X	X	X	X	X
DOPAGE		X	X	X	X	X
DOTRAP		X	X	X	X	X
EXIT	X	X	X	X	X	X
FTP		X	X	X	X	X
GET		X	X	X	X	X
HELP	X	X	X	X	X	X
MODEMTALK						X
PING			X	X	X	X
RELOADALL	X	X	X	X	X	X
RESTART			X	X	X	X
RZ			X	X	X	X
SET			X	X	X	X
SETUP			X	X	X	X
SK		X	X	X	X	X
STATUS, ?		X	X	X	X	X
SUPPORT		X	X	X	X	X
TESTTIME		X	X	X	X	X
TYPE		X	X	X	X	X
VER		X	X	X	X	X

Setup Menu Permissions

Settings	View	Admin1	Admin2	Admin3	Master
Most settings	View	X	X	X	X
Authentication				View	X
Passwords					X
Event log	View	View	View	X	X
Audit log	View	View	View	X	X
PPP dial username		View	View	View	X
PPP dial password					X
Caller ID				View	X

Control Characters

Some of the following control characters may be used in various functions within the S550, including CRC mode for AsentriaAlarms and the Escape Key.

Char	Dec	Hex	Control Key	Control Action
NUL	0	00	^@	Null
SOH	1	01	^A	Start of heading
STX	2	02	^B	Start of text
ETX	3	03	^C	End of text
EOT	4	04	^D	End of transmission
ENQ	5	05	^E	Enquiry
ACK	6	06	^F	Acknowledge
BEL	7	07	^G	Bell
BS	8	08	^H	Backspace
HT	9	09	^I	Horizontal tab
LF	10	0A	^J	Line feed
VT	11	0B	^K	Vertical tab
FF	12	0C	^L	Form feed
CR	13	0D	^M	Carriage return
SO	14	0E	^N	Shift Out
SI	15	0F	^O	Shift In
DLE	16	10	^P	Data link escape
DC1	17	11	^Q	XON
DC2	18	12	^R	Device control 2
DC3	19	13	^S	XOFF
DC4	20	14	^T	Device control 4
NAK	21	15	^U	Negative acknowledge
SYN	22	16	^V	Synchronous idle
ETB	23	17	^W	End transmission block
CAN	24	17	^X	Cancel
EM	25	19	^Y	End of medium
SUB	26	1A	^Z	Substitute
ESC	27	1B	^[Escape
FS	28	1C	^\	File separator
GS	29	1D	^]	Group Separator
RS	30	1E	^^	Record Separator
US	31	1F	^_	Unit Separator

Internal Modem Guidelines

The internal modem supplied with this product complies with Part 68 of the FCC Rules and Regulations. The labeling on the modem provides the FCC Registration number and the Ringer Equivalence Number (REN) for the modem. This information is also listed below. You must provide, upon request, this information to your telephone company.

The REN is useful to determine the quantity of devices you may connect to a telephone line and still have all of these devices ring when the number is called. In most, but not all areas, the sum of the RENs of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices you may connect to a line, as determined by the REN, you should contact the local telephone company to determine the maximum REN for your calling area.

If the modem causes harm to the telephone network, the telephone company may temporarily discontinue your service. If possible, they will notify you in advance. If advance notification is not possible, you will be notified as soon as possible.

Your telephone company may make changes in its facilities, equipment, operations or procedures that could affect proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

If you experience trouble with the modem, contact Asentria at (206) 344-8800 for information on obtaining service or repairs. The telephone company may ask you to disconnect the device from the network until the problem has been corrected or until you are sure that the device is not malfunctioning.

This device may not be used on coin service lines provided by the telephone company (this does not apply to private coin telephone applications which use standard lines). Connection to party lines is subject to state tariffs.

Modem	FCC ID	REN
2400 Baud Modem	EUD-5U9-BRI4480	0.8B
33.6K Baud Radicommm Modem	406CHN-31735-PT-E REN 1.1B	1.1B
33.6K Baud OmniModem	6KMUSA-34184-MME REN 0.9B	0.9B
33.6K Baud MultiModem	AU7-USA-46014-MD-E	0.1B

Canadian Department of Communications

NOTICE: The Canadian Department of Communications Label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protections that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The Load Number (LN) assigned to each terminal device denotes the percentage of total load to be connected to a telephone loop, which is used by the device, to prevent overloading.

The termination of a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all the devices does not exceed 100. The load number of this unit is five.

This digital apparatus does not exceed the Class A limits for Radio noise emissions from digital apparatus set out in the interference-causing equipment standard entitled "Digital Apparatus", ICES-003 of the Department of Communications.

AVIS: - L'étiquette du ministère des Communications du Canada identifie le matériel homologué. Cette étiquette certifie que le matériel est conforme à certaines normes de protection, d'exploitation et de sécurité des réseaux de télécommunications. Le Ministère n'assure toutefois pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit s'assurer qu'il est permis de le raccorder aux installations de l'entreprise locale de télécommunication. Le matériel doit également être installé en suivant une méthode acceptée de raccordement. Dans certains cas, les fils intérieurs de l'entreprise utilisés pour un service individuel à ligne unique peuvent être prolongés au moyen d'un dispositif homologué de raccordement (cordon prolongateur téléphonique interne). L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêche pas la dégradation du service dans certaines situations. Actuellement, les entreprises de télécommunication ne permettent pas que l'on raccorde leur matériel à des jacks d'abonné, sauf dans les cas précis prévus par les tarifs particuliers de ces entreprises.

Les réparations de matériel homologué doivent être effectuées par un centre d'entretien Canadien autorisé désigné par le fournisseur. La compagnie de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur ou à cause de mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit s'assurer que tous les fils de mise à la terre de la source d'énergie électrique, des lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

Avertissement. - L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours à un service d'inspection des installations électriques, ou à un électricien, selon le cas.

L'indice de charge (IC) assigné à chaque dispositif terminal indique, pour éviter toute surcharge, le pourcentage de la charge totale qui peut être raccordée à un circuit téléphonique bouclé utilisé par ce dispositif. La terminaison du circuit

bouclé peut être constituée de n'importe quelle combinaison de dispositif, pourvu que la somme des indices de charge de l'ensemble des dispositifs ne dépasse pas 100. L'indice de charge de cet produit est 5.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur : "Appareils Numériques", NMB-003 édictée par le ministre des Communications.

Warranty Information

Asentria Corporation hereby warrants that it will, as the buyers sole remedy, repair or replace, at its option, any part of the S550 which proves to be defective by reason of improper materials or workmanship, without charge for parts or labor, for a period of 12 (twelve) months. This warranty period commences on the date of first retail purchase, and applies only to the original retail purchaser.

To obtain service under this warranty, you must obtain, by telephone, postal letter, or email, a return authorization number from Asentria Technical Support. This authorization number may be obtained by contacting Asentria Technical Support at the address and/or phone number below. The defective unit is to be returned to Asentria with shipping prepaid, and the return authorization number must be clearly marked on the outside of the package containing the defective unit.

The dealer's bill of sale or other satisfactory proof of the date of purchase may be required to be presented in order to obtain service under this warranty.

This warranty applies if your S550 fails to function properly under normal use and within the manufacturer's specifications. This warranty does not apply if, in the opinion of Asentria Corporation, the unit has been damaged by misuse; neglect; or improper packing, shipping, modification, or servicing by other than Asentria or an authorized Asentria Service Center.

In no event shall Asentria Corporation be liable for any loss, inconvenience or damage, whether direct, incidental, consequential or otherwise, with respect to the S550. Asentria Corporation's liability shall be limited to the purchase price of the S550. No warranty of fitness for purpose, or of fitness of the S550 for any particular application is provided. It is the responsibility of the user to determine fitness of the S550 for any particular application or purpose.

This warranty gives you specific legal rights. These rights may vary from state to state, as some states do not allow limitations on liability.

You may request information on how to obtain service under this warranty by contacting Asentria Technical Support at the address and phone number below:

Asentria Technical Support
1200 North 96th St.
Seattle, WA 98103
206.344.8800
support@asentria.com